Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nostalgia NCIT3PLSBK

Nostalgia 3-Quart Iced Tea & Coffee Brewing System Instruction Manual

Brand: **Nostalgia** | Model: **NCIT3PLSBK**





The Nostalgia 3-Quart Iced Tea & Coffee Brewing System in black, featuring a double-insulated pitcher and strength selector dial.

Product Overview

The Nostalgia 3-Quart Iced Tea & Coffee Brewing System is designed for convenient preparation of iced beverages at home. This versatile system allows you to brew gourmet iced coffees, iced lattes, iced teas, lemonade, and flavored water in minutes. It features a removable filter basket for ground coffee, loose leaf tea, or tea bags, and a strength selector dial to customize your brew. The 3-quart double-insulated pitcher keeps drinks cold for hours, and the unit includes an automatic shut-off for safety and convenience.

Key Features

- **Ultimate Brewing:** Enjoy smooth, delicious drinks at home! Brews the best iced coffees, iced lattes, iced tea, lemonade, flavored water & more!
- **3-Quart Capacity:** Plastic pitcher holds up to 12 cups and has a large handle for easy lifting and pouring. Includes a three-position lid that turns for free pouring, pouring with ice guard or closed.
- **Filter Basket & Shower Head:** The removable filter basket works with fresh ground coffee, tea bags and loose leaf teas, while the shower head is designed for complete saturation and optimal flavor extraction.

- **Strength Selector Dial:** Choose your desired flavor strength using the strength selector dial - ranging from 1 to 8.
- **Flavor Enhancer:** Add lemon, herbs and other sweeteners to the flavor extraction chamber to further enhance the flavors.
- **Auto Shut Off:** When the brewing is done the unit is programmed to automatically shut off.
- **Simple Operation:** Avoid having to deal with a complicated control panel - there is only one push-button to power on.
- **Tidy Storage:** Convenient cord storage in bottom of unit.
- **Double-Wall Insulation:** Clear double-wall construction keeps drinks cold for hours.

Setup and Assembly

Before first use, wash all removable parts (pitcher, lid, filter basket) in warm, soapy water. Rinse thoroughly and dry. Ensure the main unit is unplugged and placed on a stable, flat surface.

1. Place the 3-quart pitcher securely on the base of the brewing system.
2. Open the lid of the main unit and ensure the removable filter basket is properly seated.
3. Plug the unit into a standard electrical outlet.



The filter basket and shower head are designed for optimal extraction and easy cleaning.

Operating Instructions

Follow these steps to brew your favorite iced beverages:

1. **Fill Pitcher with Water:** Fill the 3-quart pitcher with fresh, cold water up to the indicated 'WATER' line.
2. **Add Water to Reservoir:** Pour the water from the pitcher into the water reservoir located at the back of the main unit.
3. **Add Ingredients:** Place your desired amount of fresh ground coffee, loose leaf tea, or tea bags into the removable filter basket. For enhanced flavors, add ingredients like lemon slices, herbs, or sweeteners to the flavor extraction chamber.
4. **Add Ice to Pitcher:** Fill the pitcher with ice cubes up to the indicated 'ICE' line. Place the lid securely on the pitcher, ensuring the correct pouring position (free pour, ice guard, or closed).
5. **Select Strength:** Use the strength selector dial on the front of the unit to choose your preferred brew strength (from 1 to 8).

6. **Start Brewing:** Press the power button located on the side of the unit. The brewing process will begin automatically.
7. **Automatic Shut-Off:** The unit will automatically shut off once the brewing cycle is complete.



The strength selector dial allows for precise control over your beverage's intensity.



Enhance your drinks by adding fruits, herbs, or sweeteners to the flavor extraction chamber.

Official Product Video: Nostalgia Ice Tea Maker Black

Watch this official video for a visual guide on setting up and operating your Nostalgia Iced Tea & Coffee Brewing System.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your brewing system.

1. **Unplug and Cool:** Always unplug the unit from the electrical outlet and allow it to cool completely before cleaning.
2. **Remove Filter Basket:** Carefully remove the filter basket and discard any used coffee grounds or tea bags. Rinse the filter basket under warm running water.
3. **Clean Pitcher and Lid:** Wash the 3-quart pitcher and its lid in warm, soapy water. These parts are typically top-rack dishwasher safe, but hand washing is recommended for best results.
4. **Wipe Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing the unit.

Troubleshooting

If you encounter any issues with your Nostalgia Brewing System, refer to the following common troubleshooting tips:

- **Unit Not Turning On:** Ensure the unit is properly plugged into a working electrical outlet. Check if the power button is fully pressed.
- **Weak Brew:** Adjust the strength selector dial to a higher setting. Ensure you are using the recommended amount of coffee grounds or tea bags for the desired strength.
- **Overflowing Pitcher:** Verify that the pitcher is placed correctly on the base and that the water level in the reservoir does not exceed the maximum fill line. Ensure the ice level in the pitcher is not above the 'ICE' line.
- **Slow Brewing:** Check for any blockages in the filter basket or shower head. Ensure the unit is clean and free from mineral buildup.
- **Leaking:** Ensure all removable parts, especially the filter basket and pitcher, are correctly assembled and seated. Check for any cracks or damage to the pitcher.

For persistent issues, please refer to the full user manual or contact customer support.

Specifications

Attribute	Value
Brand	Nostalgia
Color	Black
Product Dimensions	10.55"D x 6.59"W x 14.84"H
Special Feature	Manual
Coffee Maker Type	Coffee Infuser
Filter Type	Reusable
Style	Black
Specific Uses For Product	Coffee brewing
Included Components	Ice tea maker
Model Name	3-Quart Iced Tea & Coffee Brewing
Number of Items	1
Manufacturer	Nostalgia
UPC	810061705901
Item Weight	5.2 pounds
ASIN	B09N4Q3XTH

Attribute	Value
Country of Origin	China
Item model number	NCIT3PLSBK
Date First Available	December 6, 2021

Warranty and Support

For detailed warranty information and customer support, please refer to the official user manual or contact Nostalgia customer service.

- **Protection Plans:** Extended protection plans are available for purchase. Options include 3-Year Protection Plan and 4-Year Protection Plan.
- **User Manual:** A comprehensive user manual in PDF format is available for download.Download User Manual (PDF)
- **Brand Store:** Explore more products and information from Nostalgia.Visit Nostalgia Store

© 2024 Nostalgia. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09N4Q3XTH

More documents and user manuals: **https://manuals.plus/**