

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [EASTROCK](#) /

› [EASTROCK Drum Throne with Backrest Instruction Manual - Model: drum throne with backrest](#)

## EASTROCK drum throne with backrest

# EASTROCK Drum Throne with Backrest Instruction Manual

Model: drum throne with backrest

## PRODUCT OVERVIEW

---

The EASTROCK Drum Throne with Backrest is a BIFMA, SGS, and TUA certified heavy-duty drum chair designed for drummers. It features a motorcycle-style saddle seat with memory foam for comfort, a height-adjustable air cylinder, and double-braced legs with enlarged anti-slip pads for stability. The backrest is also adjustable to provide ergonomic support during long practice sessions.

# Soft drum stool, not easy to scratch



Image: The EASTROCK Drum Throne with Backrest, showcasing its ergonomic design and sturdy construction.

## PACKAGE CONTENTS

The package includes the following components:

- 1 x Drum Seat (Motorcycle Style)
- 1 x Backrest
- 1 x Support Base (Drum Throne Base)
- Screws for backrest attachment



Image: Components of the drum throne, including the seat, backrest, and base.

## ASSEMBLY INSTRUCTIONS

1. **Prepare the Base:** Place the drum throne base on a flat, stable surface. Ensure the double-braced legs are fully extended

for maximum stability. Tighten any locking screws on the base to secure the legs. Remove the protective cap from the top of the base post.



Image: Close-up of the drum throne base, highlighting the stable anti-slip rubber pads and double-brace support.

2. **Attach the Backrest to the Seat:** Locate the backrest and the drum seat. The screw for fixing the backrest is typically taped to the inside of the box or the leg of the drum throne. Align the backrest attachment with the designated holes on the underside of the drum seat. Secure the backrest using the provided screws. Note: The backrest is designed with two adjustment holes; only one bolt needs to be tightened for initial setup. The extra hole is for adjustment options.

# Air Cylinder Design with Adjustable Height



Image: The drum seat and backrest, showing the attachment mechanism. The backrest dimensions are 13.2 inches (33.5 cm) wide and 7.5 inches (18.5 cm) high.

3. **Mount the Seat onto the Base:** Align the red part on the base post with the hole position at the bottom of the stool. Insert the assembled seat (with backrest) onto the support base. Ensure it is firmly seated.

## Assembly Video Guide:

Your browser does not support the video tag.

Video: Step-by-step instructions for installing the drum throne with backrest. This video demonstrates how to assemble the base, attach the backrest to the seat, and then mount the seat onto the base.

## OPERATING INSTRUCTIONS

### Height Adjustment:

The drum throne features an airlift cylinder design for easy height adjustment. The adjustable height ranges from 18.5 inches to 24.4 inches (approximately 30.1 inches to 36.2 inches with backrest). To adjust the height:

1. Sit on the stool.
2. Locate the adjuster lever beneath the seat.

3. Move the adjuster lever up or down to raise or lower the seat to your desired height.
4. Release the lever to lock the height in place.



Image: The drum throne illustrating its adjustable height range from 30.1 inches to 36.2 inches using an air cylinder design.

### Height Adjustment Video Guide:

Your browser does not support the video tag.

Video: Demonstration of how to adjust the height of the drum throne using the lever.

### Backrest Adjustment:

The backrest can be adjusted for optimal ergonomic support. Loosen the screws that secure the backrest to the seat, adjust the backrest to your preferred position (up/down or forward/backward), and then tighten the screws firmly to secure it.

## MAINTENANCE

To ensure the longevity and proper function of your drum throne, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the seat and backrest with a damp cloth to remove dust and dirt. Avoid harsh chemicals that may damage the leather finish.
- **Tighten Fasteners:** Periodically check and tighten all screws and knobs, especially those on the base and backrest, to maintain stability.
- **Storage:** Store the drum throne in a dry environment away from extreme temperatures.

## TROUBLESHOOTING

If you encounter any issues with your drum throne, consider the following common solutions:

- **Wobbling or Instability:** Ensure all leg braces are fully extended and the locking screws on the base are securely tightened. Check the connection between the seat and the base, ensuring the post is fully inserted and any locking mechanisms are engaged.
- **Backrest Movement:** If the backrest feels loose, verify that the screws attaching it to the seat are tightened. The backrest has adjustment holes; ensure one bolt is firmly tightened.
- **Height Adjustment Issues:** If the height adjustment mechanism is stiff or not functioning smoothly, ensure the adjuster lever is fully engaged or disengaged as needed. Check for any obstructions around the air cylinder.

For persistent issues, please contact EASTROCK customer support.

## SPECIFICATIONS

Feature	Detail
Product Dimensions	15"D x 17"W x 20"H
Color	Black
Brand	EASTROCK
Size	Saddle
Style	Motorcycle
Furniture Finish	Leather
Seat Height (Adjustable)	18.5" to 24.4" (approx. 30.1" to 36.2" with backrest)
Leg Style	Straight, Double Braced
Product Care Instructions	Wipe with Damp Cloth
Assembly Required	Yes
Number of Pieces	3 (Seat, Backrest, Support Base)
Item Weight	16.96 pounds
Max Weight Capacity	350 pounds
Certifications	BIFMA, SGS, TUA

## SAFETY INFORMATION

- Ensure the stool is used on a stable, level surface.
- Do not exceed the maximum weight limit of 350 pounds.

- Adjust the seat height as needed to maintain proper posture and reduce strain.
- Regularly inspect all components for wear or damage. Do not use if any part is compromised.

## WARRANTY AND SUPPORT

---

For warranty information, product support, or to purchase replacement parts, please contact EASTROCK customer service through their official channels or visit the [EASTROCK Store on Amazon](#).