Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Roberts Radio Revival Uno BT Bleu pastel

Roberts Revival Uno BT DAB+/FM/Bluetooth Portable Radio User Manual

Model: Revival Uno BT Bleu pastel



Image: Front view of the Roberts Revival Uno BT portable radio, showcasing its sky blue finish, gold grille, and classic design with a top handle.

Introduction

The Roberts Revival Uno BT is a compact and stylish portable radio that blends classic 1950s retro design with modern functionality. This model, inspired by the iconic Revival RD70 and iStream3, offers enhanced sound quality and versatile connectivity options, including DAB+, FM, and Bluetooth. Designed to be a perfect fit for a bedside table or smaller room, it also features dual alarms, a sleep timer, a dimmable display, and a 3.5mm headphone output.



Image: The Roberts Revival Uno BT radio in a home setting, demonstrating its compact size and aesthetic appeal on a wooden cabinet.

Setup

1. **Unpacking:** Carefully remove the radio and all accessories from the packaging. Ensure all components listed in the "Specifications" section are present.
2. **Powering On:**
   - **Mains Power:** Connect the supplied AC adapter to the DC IN socket on the back of the radio and then plug it into a wall outlet.
   - **Battery Power (Optional):** The radio can also be powered by batteries (not included). Open the battery compartment on the bottom and insert the required batteries, observing polarity.
3. **Antenna Adjustment:** Extend the telescopic antenna fully for optimal DAB+ and FM reception. Adjust its position for the best signal.
4. **Initial Setup:** Upon first power-on, the radio may prompt you to select a language and perform an auto-scan for DAB+ stations. Follow the on-screen instructions.

Operating Instructions

Controls Overview



Image: Top view of the Roberts Revival Uno BT radio, highlighting the control panel with buttons for Favourite, Mode, Menu, AutoTune, Info/Dimmer, Preset, Volume, and Tuning dials, along with the display screen.

- **Volume Dial:** Rotate to adjust the audio volume. Press to power On/Off.
- **Tuning Dial:** Rotate to navigate menus or tune stations. Press to select.
- **Favourite Button:** Access your saved favourite stations.
- **Mode Button:** Switch between DAB+, FM, Bluetooth, and Aux-in modes.
- **Menu Button:** Access system settings and options for the current mode.
- **AutoTune Button:** Initiate an automatic scan for radio stations.
- **Info/Dimmer Button:** Cycle through display information or adjust display brightness.
- **Preset Button:** Save or recall radio station presets.
- **Aux In (3.5mm Jack):** Connect external audio devices.

DAB+ Radio Operation

1. Press the **Mode** button until "DAB" is displayed.
2. The radio will automatically scan for available DAB+ stations. If not, press **AutoTune**.
3. Rotate the **Tuning** dial to browse through the list of available stations. Press the dial to select a station.
4. To save a preset: Tune to the desired station, press and hold the **Preset** button. Rotate the **Tuning** dial to select a preset number, then press to confirm.
5. To recall a preset: Press the **Preset** button briefly, rotate the **Tuning** dial to select the preset number, then press to confirm.

FM Radio Operation

1. Press the **Mode** button until "FM" is displayed.
2. To auto-scan: Press and hold the **AutoTune** button. The radio will scan and stop at the next strong station.
3. To manual tune: Rotate the **Tuning** dial to adjust the frequency in small increments.
4. Saving and recalling presets works the same as for DAB+ radio.

Bluetooth Mode

1. Press the **Mode** button until "Bluetooth" is displayed. The radio will enter pairing mode, indicated by a flashing Bluetooth icon on the display.
2. On your Bluetooth device (e.g., smartphone, tablet), enable Bluetooth and search for "Roberts Uno BT".
3. Select "Roberts Uno BT" from the list of available devices to pair. Once connected, the Bluetooth icon on the radio's display will become solid.
4. You can now play audio from your device through the radio.

Aux-in Mode

1. Connect an external audio device (e.g., MP3 player) to the **Aux In** 3.5mm jack on the radio using a suitable audio cable (not supplied).
2. Press the **Mode** button until "Aux In" is displayed.
3. Control playback and volume from your connected external device.

Alarm Clock and Sleep Timer

- **Setting Alarms:** The Revival Uno BT supports two independent alarms. Access alarm settings via the **Menu** button. Follow the on-screen prompts to set alarm time, source (DAB/FM/Buzzer), and frequency.
- **Setting Sleep Timer:** The sleep timer allows the radio to turn off automatically after a set period. Access this feature via the **Menu** button and select the desired duration.
- **Display Dimmer:** Press the **Info/Dimmer** button repeatedly to cycle through different display brightness levels.
- **Headphone Output:** Connect 3.5mm headphones to the headphone jack for private listening. The radio's speaker will be muted.

Maintenance

- **Cleaning:** Wipe the radio with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- **Storage:** If storing the radio for an extended period, disconnect it from the mains power and remove any batteries to prevent leakage. Store in a cool, dry place.
- **General Care:** Avoid exposing the radio to extreme temperatures, humidity, direct sunlight, or dusty environments. Do

not block ventilation openings.

Troubleshooting

Problem	Possible Cause / Solution
No power	Ensure the AC adapter is securely connected to both the radio and the power outlet. Check if batteries are inserted correctly and are not depleted.
Poor radio reception (DAB+/FM)	Fully extend and adjust the telescopic antenna. Try repositioning the radio. Perform an auto-scan for stations. Check for local interference.
Bluetooth device cannot pair	Ensure the radio is in Bluetooth mode and in pairing state. Make sure Bluetooth is enabled on your device and it's within range (approx. 10 meters). Try unpairing and re-pairing.
No sound from Aux-in	Ensure the radio is in Aux-in mode. Check the audio cable connection. Verify the volume level on both the radio and the connected external device.
Display is too dim or off	Press the **Info**/**Dimmer** button to adjust brightness. Check if the radio is in standby mode.

Specifications

Feature	Detail
Brand	Roberts Radio
Model Number	Revival Uno BT Bleu pastel
Color	Sky Blue
Connectivity Technology	Bluetooth
Special Features	Portable, Alarm Clock, Sleep Timer, Dimmable Display
Compatible Devices	MP3 Player, Headphones
Product Dimensions	21L x 8.8W x 13.8H centimeters
Tuning Technology	DAB+
Supported Radio Bands	FM
Power Source	Cable Electric (Mains)
Included Components	AC Adapter, Quick Start Guide
Manufacturer	Roberts
Country of Origin	China

Warranty and Support

Roberts Radio products are designed for reliability and performance.

- **Spare Parts Availability:** Spare parts for this product are available for up to 5 years from the date of purchase.
- **Software Updates:** Information regarding guaranteed software updates is not available.
- For further assistance, technical support, or warranty claims, please refer to the contact information provided in your Quick Start Guide or visit the official Roberts Radio website.

© 2024 Roberts Radio. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09N7JD6MX

More documents and user manuals: **https://manuals.plus/**