

[Manuals.plus](#) /

› [GLOBO](#) /

› GLOBO 6-Bulb LED Smoked Glass Suspension Light, Matte Black Metal Instruction Manual

GLOBO 15345LM6

GLOBO 6-Bulb LED Smoked Glass Suspension Light

Model: 15345LM6

1. INTRODUCTION

This manual provides essential instructions for the safe installation, operation, and maintenance of your GLOBO 6-Bulb LED Smoked Glass Suspension Light, Model 15345LM6. Please read this manual thoroughly before installation and retain it for future reference.

The GLOBO suspension light features a matte black metal plate with six suspended smoked glass shades of varying shapes. It includes six replaceable E14 LED filament bulbs, each 4W, providing 470 lumens of warm white light (2700K). The light is dimmable via a standard wall switch.

2. SAFETY INSTRUCTIONS

WARNING: Electrical installation should only be performed by a qualified electrician. Always disconnect power at the main circuit breaker before installation, maintenance, or bulb replacement.

- Ensure the mounting surface can support the weight of the fixture (6.51 kg).
- Do not connect the fixture to an ungrounded electrical system.
- Use only E14 bulbs with a maximum wattage of 40W per bulb. The included LED bulbs are 4W each.
- Avoid touching bulbs with bare hands during operation or immediately after turning off, as they may be hot.
- Do not modify the fixture in any way.
- Keep packaging materials out of reach of children.
- This product is rated IP20, suitable for indoor use only. Do not expose to moisture or extreme temperatures.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, contact your retailer.

- 1x GLOBO Suspension Light Fixture (Matte Black Metal Plate)
- 6x Smoked Glass Shades (various shapes)
- 6x E14 LED Filament Bulbs (4W, 470lm, 2700K Warm White)
- Mounting Hardware (screws, anchors, wire connectors)
- Instruction Manual

4. SETUP AND INSTALLATION

This fixture is designed for ceiling mounting. Professional installation is recommended.

4.1 Pre-Installation

1. **Turn off power:** Locate the circuit breaker controlling the light fixture's location and turn it off. Verify power is off using a voltage tester.
2. **Unpack:** Carefully remove all components from the packaging. Keep packaging materials for disposal.
3. **Inspect:** Check all parts for any damage. Do not proceed with installation if any part is damaged.

4.2 Mounting the Fixture

1. Attach the mounting bracket to the ceiling junction box using the provided screws. Ensure it is securely fastened.
2. Connect the electrical wires:
 - Connect the fixture's live wire (usually black or brown) to the ceiling's live wire.
 - Connect the fixture's neutral wire (usually white or blue) to the ceiling's neutral wire.
 - Connect the fixture's ground wire (usually green/yellow or bare copper) to the ceiling's ground wire.

Secure all connections with wire connectors.

3. Carefully tuck the wires into the junction box.
4. Attach the fixture's canopy to the mounting bracket, securing it with the provided screws or nuts.

4.3 Installing Bulbs and Shades

1. Gently screw the E14 LED bulbs into the lamp holders. Do not overtighten.
2. Attach each smoked glass shade to its respective lamp holder. Ensure they are securely fastened but do not apply excessive force.



Image 1: Overall view of the GLOBO suspension light with dimensions. The fixture measures 80cm in length, 34cm in depth, and has a maximum height of 120cm.



Image 2: Technical drawing showing detailed dimensions of the GLOBO suspension light, including individual shade diameters (e.g., 16.5cm, 18.5cm, 15.8cm) and the ceiling plate (80x24cm).

5. OPERATING INSTRUCTIONS

Once installation is complete and verified, restore power at the circuit breaker.

- **Turning On/Off:** Use your standard wall light switch to turn the fixture on or off.
- **Dimming Function:** The included LED bulbs are dimmable in 3 steps via a traditional wall switch. To cycle through the brightness levels (100%, 50%, 25%), quickly toggle the wall switch off and on.



Image 3: The GLOBO suspension light with all six bulbs illuminated, showcasing the smoked glass shades and matte black finish.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your light fixture.

- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth to wipe the metal parts and glass shades. Do not use abrasive cleaners, solvents, or polishes, as these can damage the finish.
- **Bulb Replacement:** Ensure power is off and bulbs have cooled before attempting to replace them. Unscrew the old E14 bulb and screw in a new one. Use only E14 LED bulbs, maximum 40W.
- **Inspection:** Periodically check for any loose connections or signs of wear. If any issues are found, consult a qualified electrician.




Image 4: A close-up view highlighting the different shapes and smoked glass finish of the individual shades.

7. TROUBLESHOOTING

If you encounter issues with your GLOBO suspension light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Faulty bulb.	Check circuit breaker. Verify all wire connections (ensure power is off). Replace bulb(s).
Light flickers.	Loose bulb. Incompatible dimmer switch (if applicable). Faulty bulb.	Tighten bulb(s). Ensure dimmer switch is compatible with LED bulbs. Replace bulb(s).
Dimming function not working.	Incorrect operation of wall switch. Non-dimmable bulbs installed.	Ensure quick toggling of the wall switch. Verify that only dimmable E14 LED bulbs are used.

If the problem persists after trying these solutions, consult a qualified electrician or contact GLOBO customer support.

8. SPECIFICATIONS

- **Brand:** GLOBO
- **Model Number:** 15345LM6
- **Material:** Metal (matte black), Glass (smoked)
- **Dimensions (L x W x H):** 80 cm x 34 cm x 120 cm (max height)
- **Item Weight:** 6.51 kg
- **Number of Bulbs:** 6
- **Bulb Type:** E14 LED Filament (replaceable)
- **Included Bulbs:** 6x 4W LED, 470 lumens each
- **Total Luminous Flux:** 2820 lumens (6 x 470 lm)
- **Color Temperature:** 2700 Kelvin (Warm White)
- **Max Wattage per Bulb:** 40W
- **Voltage:** 230V
- **Dimmable:** Yes, 3-step dimming via wall switch
- **Protection Rating:** IP20
- **Protection Class:** 1
- **Certifications:** Energy Star
- **Installation Type:** Ceiling Mount / Semi-flush mount
- **Specific Uses:** Indoor lighting for kitchen, living room, dining room, hallway, bar.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official GLOBO website. Keep your proof of purchase for any warranty claims.



Image 5: The GLOBO Lighting logo, representing the brand.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09N7K71N1>

More documents and user manuals: <https://manuals.plus/>