

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Tupperware](#) /
- › [Tupperware Swing Box 450 ml Food Storage Containers - User Manual](#)

Tupperware Swing Box

Tupperware Swing Box 450 ml Food Storage Containers

User Manual

1. PRODUCT OVERVIEW

Thank you for choosing Tupperware Swing Box 450 ml food storage containers. This set of two black containers is designed for efficient and durable food preservation. Each container has a capacity of 450 ml and features a secure lid to keep your food fresh longer.



Image 1: Two Tupperware Swing Box 450 ml containers with lids on, ready for use.

Key Features:

- **High-Quality Material:** Made from superior, resistant, and durable materials for long-term use.
- **Extended Food Freshness:** Intelligent storage solutions in specially designed containers help food last longer.
- **Eco-Friendly Design:** Robust and easy-to-use products that minimize disposable plastic use and reduce food waste.
- **Innovative Eco+ Material:** Made from renewable raw materials, focusing on minimal natural resource use, waste reduction, reuse, and recycling.
- **Precision Manufacturing:** Containers are crafted with care, precision, and controlled quality.

2. SETUP AND FIRST USE

Before using your Tupperware Swing Box containers for the first time, it is recommended to wash them thoroughly.

Initial Cleaning:

1. Separate the container body from its lid.
2. Wash both parts with warm soapy water.
3. Rinse thoroughly with clean water.
4. Allow to air dry completely or dry with a clean cloth before first use.



Image 2: Tupperware containers with lids removed, illustrating components for cleaning.

3. OPERATING INSTRUCTIONS

These containers are designed for convenient food storage in your refrigerator, pantry, or for transport.

Using Your Containers:

- **Filling:** Place your food items into the container. Avoid overfilling to ensure a proper seal.
- **Sealing:** Place the lid firmly onto the container. Press down on the edges of the lid until it is securely sealed.
- **Stacking:** The containers are designed to be stackable, optimizing space in your storage area.
- **Microwave Use:** These containers are microwave safe. When microwaving, ensure the lid is slightly ajar or removed to allow steam to escape.





Image 3: Tupperware containers stacked, showing efficient storage.

4. MAINTENANCE AND CARE

Proper care will ensure the longevity and performance of your Tupperware containers.

Cleaning:

- **Dishwasher Safe:** Your Tupperware Swing Box containers are dishwasher safe. Place them on the top rack for best results.
- **Hand Washing:** For hand washing, use a soft sponge or cloth with warm soapy water. Avoid abrasive cleaners or scrubbers that could scratch the surface.
- **Drying:** Ensure containers and lids are completely dry before storing to prevent odors or mildew.



Image 4: A single Tupperware Swing Box container, illustrating its design for easy cleaning.

5. TROUBLESHOOTING

Most issues with food storage containers are minor and easily resolved.

Common Concerns:

- **Lid Not Sealing:** Ensure the container rim and lid are clean and free of food debris. Press firmly around all edges of the lid.
- **Stains or Odors:** For stubborn stains or odors, create a paste with baking soda and water, apply it to the affected area, let it sit for a few hours, then wash thoroughly. Sunlight can also help remove odors.
- **Warping:** Avoid placing hot containers directly into cold water or vice-versa, as extreme temperature changes can cause warping. Always ensure lids are vented when microwaving.

6. SPECIFICATIONS

Feature	Detail
Brand	Tupperware
Model Number	Swing Box
Material	Plastic
Capacity (per container)	450 Milliliters
Product Dimensions (L x W x H)	12 x 11 x 8 cm
Item Weight (per container)	87 grams (approx.)
Container Shape	Rectangular
Dishwasher Safe	Yes
Microwave Safe	Yes
Included Components	Lid

7. WARRANTY AND SUPPORT

Tupperware products are known for their quality and durability. For any questions, concerns, or warranty information regarding your Tupperware Swing Box containers, please refer to the official Tupperware website or contact their customer support directly. Keep your purchase receipt as proof of purchase. For more information, visit the official [Tupperware website](#).