

[manuals.plus](#) /

› [Best Choice Products](#) /

› [Best Choice Products Large 50-inch 70-Piece Train Table Instruction Manual \(Model SKY6343\)](#)

Best Choice Products SKY6343

Best Choice Products Large 50-inch 70-Piece Train Table Instruction Manual

Model: SKY6343

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Best Choice Products Large 50-inch 70-Piece Train Table. Please read this manual thoroughly before assembly and use to ensure safe and proper operation. Retain this manual for future reference.



Image: The assembled 50-inch train table featuring a complete train track layout, various buildings, vehicles, and accessories.

IMPORTANT SAFETY INFORMATION

- **WARNING:** Not for children under 3 years old. Small parts may present a choking hazard.
- Adult supervision is recommended during play.
- Ensure all parts are securely fastened during assembly to prevent instability.
- Keep packaging materials away from children to avoid suffocation risks.
- Regularly inspect the table and accessories for any damage or loose parts. Discontinue use if damage is found.

PACKAGE CONTENTS

Verify that all components listed below are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Train Table Frame (Wooden components)
- Reversible Tabletop Panels
- Hardware Pack (screws, connectors, etc.)
- 70-Piece Accessory Set, including:
 - Toy Train and various train track pieces
 - Buildings (e.g., fire station, police station, hospital)
 - Vehicles (e.g., helicopter, cars)
 - Trees, signs, and other landscape elements
- Assembly Guide

70-accessory Set!

Comes with everything a child needs to play, including exceptionally-detailed trains, tracks, and accessories!



Image: A collection of the 70 accessories included with the train table, such as train tracks, a toy train, buildings, and various small landscape items.

ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 30-60 minutes with two adults. A Phillips head screwdriver (not included) is required. Follow the steps in the included Assembly Guide for detailed diagrams.

- 1. Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts against the package contents list.
- 2. Assemble Table Frame:** Follow the diagrams in the Assembly Guide to connect the wooden side panels and support beams using the provided hardware. Ensure all screws are tightened securely, but do not overtighten.
- 3. Install Storage Drawer:** Assemble the storage drawer components as per the instructions and slide it into the designated slot in the table frame.
- 4. Place Tabletop Panels:** Position the reversible tabletop panels onto the assembled frame. Ensure they sit flush and are stable.
- 5. Arrange Accessories:** Once the table is assembled, you can arrange the 70-piece accessory set, including train tracks, buildings, and other elements, to create your desired play environment.

OPERATING INSTRUCTIONS

Imaginative Play

The 50-inch play space encourages children to develop their imagination by creating various scenarios and layouts for their trains and other toys. The included 70-piece accessory set provides a rich environment for creative storytelling and role-playing.



Image: A child happily engaged in imaginative play with the train table, arranging buildings and trains.

Reversible Tabletop

The tabletop features two distinct surfaces: one with colorful artwork depicting roads and landscapes for train play, and a plain green surface. To switch surfaces, carefully lift the tabletop panels and flip them over to the desired side. This allows for versatile play options beyond just trains, such as arts and crafts or block building.

Reversible Table Top

Choose between colorful artwork
and a green surface




Image: A visual representation of the reversible tabletop, highlighting the ability to switch between a detailed play scene and a plain green surface.

Multipurpose Use

Beyond train activities, the table can be utilized for a variety of other creative and educational activities. The plain green side of the reversible top is ideal for:

- Arts and crafts projects
- Building with blocks or other construction toys
- Assembling puzzles
- General play space

Multipurpose Table



Blocks



Arts & Crafts



Puzzles



Image: The train table configured for multipurpose use, showcasing blocks, art supplies, and puzzle pieces on its surface.

Storage Drawer

The integrated storage drawer provides a convenient space to store train accessories, art supplies, or other small toys when not in use, helping to keep the play area tidy.



Built To Last

Durably designed with a large, wood frame for kids to play for years to come



Image: A close-up of the train table showing its built-in storage drawer, partially open to reveal storage space.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the table and accessories with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Storage:** Store the table in a dry environment away from direct sunlight and extreme temperatures to prevent warping or fading of the wood.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary. Inspect wooden parts for splinters or cracks and accessories for any small broken pieces.
- **Accessory Care:** The cardboard buildings included in the accessory set are delicate. Handle them with care to prevent tearing. Consider storing them separately if frequent assembly/disassembly is expected.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Missing parts or damaged components upon arrival.	Shipping damage or packaging error.	Contact Best Choice Products customer support immediately for replacement parts.
Table feels wobbly after assembly.	Screws not fully tightened or uneven surface.	Ensure all assembly screws are securely tightened. Place the table on a flat, level surface.
Tabletop panels do not sit flush.	Improper placement or obstruction.	Lift and reposition the panels, ensuring no debris is underneath. Check that the table frame is assembled correctly.
Cardboard accessories tear easily.	Delicate material.	Handle cardboard buildings and signs with care. Consider purchasing more durable plastic alternatives if frequent handling is expected.

PRODUCT SPECIFICATIONS

Model Number: SKY6343

Product Dimensions: 50" (L) x 25" (W) x 15.5" (H)

Item Weight: 45 pounds

Material: Wood construction

Recommended Age: 36 months - 18 years

Accessory Count: 70 pieces



Image: A diagram illustrating the length (50 inches), width (25 inches), and height (15.5 inches) of the assembled train table.

WARRANTY AND CUSTOMER SUPPORT




Best Choice Products stands behind the quality of its products. For specific warranty details, please refer to the documentation included with your purchase or visit the official Best Choice Products website.

If you encounter any issues, require replacement parts, or have questions regarding your train table, please contact Best Choice Products customer support. Contact information can typically be found on the product packaging or the brand's official website.

You can also visit the [Best Choice Products Store on Amazon](#) for more information and support resources.

© 2025 Best Choice Products. All rights reserved.

Related Documents - SKY6343

	<p><u>Best Choice Products Train Table Instruction Manual - SKY6343</u></p> <p>Comprehensive instruction manual for the Best Choice Products Train Table (Model SKY6343), detailing assembly steps, parts list, hardware, tools, and accessory guide for this playset.</p>
	<p><u>Best Choice Products Kitchen Playset Instruction Manual</u></p> <p>Comprehensive instruction manual for assembling the Best Choice Products Kitchen Playset, including parts lists, hardware details, and step-by-step assembly instructions for models SKY5969, SKY6009, SKY6346, SKY6850, SKY6851, SKY6852, and SKY6853.</p>
	<p><u>Best Choice Products Cottage Kitchen Playset Instruction Manual</u></p> <p>Detailed instruction manual for assembling the Best Choice Products Cottage Kitchen Playset, including parts list, tools required, and assembly steps. Model numbers: SKY8535, SKY8536, SKY8537, SKY8538, SKY8539.</p>
	<p><u>Best Choice Products Kitchen Playset Instruction Manual</u></p> <p>Comprehensive instruction manual for the Best Choice Products Kitchen Playset, including assembly steps, parts list, hardware guide, and safety information. Model numbers: SKY5969, SKY6009, SKY6346, SKY6850, SKY6851, SKY6852, SKY6853, SKY8147, SKY8148, SKY8149.</p>
	<p><u>Best Choice Products Kids Kitchen Playset Instruction Manual (SKY4954 + SKY5967)</u></p> <p>Comprehensive instruction manual for assembling the Best Choice Products Kids Kitchen Playset, models SKY4954 and SKY5967. Includes parts list, hardware details, step-by-step assembly instructions, safety warnings, and warranty information.</p>
	<p><u>Best Choice Products 110-Piece Magnetic Building Tiles - Building Examples</u></p> <p>Explore creative building possibilities with the Best Choice Products 110-Piece Multicolor Magnetic Building Tiles. This guide showcases various examples of structures that can be created, encouraging imagination and skill development in children aged 3-8.</p>

