



[Manuals.plus](#) /

› [JISULIFE](#) /

› JISULIFE Mini Handheld Fan (Model: Handheld Fan Life1) User Manual

JISULIFE Handheld Fan Life1

JISULIFE Mini Handheld Fan User Manual

Model: Handheld Fan Life1 (JLUSFA20DUCK)

1. INTRODUCTION

Thank you for choosing the JISULIFE Mini Handheld Fan. This compact and portable fan is designed to provide personal cooling with convenience. Featuring a 2000 mAh rechargeable battery and three-speed settings, it is suitable for various indoor and outdoor environments. Please read this manual carefully before use to ensure proper operation and maintenance.



Image 1.1: The JISULIFE Mini Handheld Fan, yellow in color, showcasing its compact design.

2. SAFETY PRECAUTIONS

To prevent damage to the product or injury to yourself and others, please observe the following safety guidelines:

- Do not insert fingers or any objects into the fan blades or protective grille.
- Keep the fan away from water or other liquids. Do not use in wet environments.
- Do not disassemble, repair, or modify the fan. Contact customer support if service is required.
- Keep out of reach of children. This product is not a toy.
- Use only the provided charging cable or a certified USB-C cable for charging.
- Do not expose the fan to extreme temperatures or direct sunlight for extended periods.
- Ensure the fan is turned off before cleaning or storing.

3. PACKAGE CONTENTS

Please check the package for the following items:

- JISULIFE Mini Handheld Fan (Model: Handheld Fan Life1)
- USB-C Charging Cable
- Lanyard (may be pre-attached or included separately)
- User Manual

4. PRODUCT OVERVIEW

The JISULIFE Mini Handheld Fan features a simple and functional design for ease of use.



Image 4.1: Detail of the power button located on the fan's top surface.



Image 4.2: Detail of the USB-C charging port for convenient power input.

Key features include:

- **Power Button:** Controls power on/off and fan speed settings.
- **USB-C Charging Port:** For recharging the internal battery.
- **Protective Grille:** Covers the fan blades for safety.
- **Lanyard Eyelet:** Allows attachment of a lanyard for easy carrying.

Like Summer Breeze Free and Quiet

Adopt ultra-quiet brushless motor to minimize noise



Image 4.3: Illustration of the fan's ultra-quiet brushless motor, designed to minimize noise during operation.

5. CHARGING THE FAN

The fan is equipped with a built-in 2000 mAh rechargeable battery. Before first use, it is recommended to fully charge the fan.

1. Locate the USB-C charging port on the fan.
2. Connect the provided USB-C cable to the fan's charging port.
3. Connect the other end of the USB-C cable to a USB power source (e.g., computer, wall adapter, power bank).
4. The charging indicator light (if present) will illuminate during charging and turn off or change color when fully charged.
5. A full charge typically takes approximately 3 hours.

Built-in 2000mAh Battery

Bring cool breeze day and night



2000mAh



USB-C Fast-Recharged



Image 5.1: The fan connected to a USB-C cable for charging, indicating its 2000mAh battery capacity.

6. OPERATING INSTRUCTIONS

The fan features three adjustable speed settings.

1. **Power On:** Press the power button once to turn on the fan at Speed 1 (Light Air).
2. **Adjust Speed:**
 - Press the power button a second time for Speed 2 (Soft Breeze).
 - Press the power button a third time for Speed 3 (Gentle Wind).
3. **Power Off:** Press the power button a fourth time to turn off the fan.

3 Speeds Strong Wind

Break through the limitation of size



Image 6.1: Visual representation of the fan's three wind speeds: Light Air, Soft Breeze, and Gentle Wind.

7. MAINTENANCE AND CLEANING

Regular cleaning helps maintain the fan's performance and extends its lifespan.

- Ensure the fan is turned off and disconnected from any power source before cleaning.
- Use a soft, dry cloth to wipe the exterior of the fan.
- To clean the fan blades, gently remove the front grille (if detachable, refer to product design for specific instructions). Use a soft brush or cloth to remove dust.
- Do not use abrasive cleaners, solvents, or immerse the fan in water.
- Store the fan in a cool, dry place when not in use for extended periods.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan using the USB-C cable.
Fan stops working unexpectedly.	Low battery.	Recharge the fan.
Weak airflow.	Fan blades are dirty or obstructed.	Clean the fan blades and grille.
Unusual noise during operation.	Foreign object caught in blades or internal issue.	Turn off the fan immediately. Check for obstructions. If noise persists, discontinue use and contact support.

9. SPECIFICATIONS

Feature	Detail
Brand	JISULIFE
Model Name	Handheld Fan Life1
Model Number	JLUSFA20DUCK
Color	Yellow
Power Source	Battery Powered (2000mAh)
Product Dimensions (D x W x H)	1.38" x 2.4" x 5.3"
Item Weight	0.18 Pounds
Number of Speeds	3
Noise Level	30 Decibels
Wattage	5 watts
Voltage	5 Volts
Charging Port	USB Type C
Material	Plastic
Reusability	Rechargeable

10. WARRANTY AND SUPPORT

JISULIFE products are designed and manufactured to high-quality standards. For warranty information, technical support, or customer service inquiries, please refer to the warranty card included with your product or visit the official JISULIFE website.

You can also visit the [JISULIFE Store on Amazon](#) for more information and contact options.

