Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy FKW102-WN

SoBuy FKW102-WN Mobile Kitchen Storage Cart User Manual

Model: FKW102-WN | Brand: SoBuy

Introduction

The SoBuy FKW102-WN is a versatile mobile kitchen storage cart designed to provide additional storage and workspace in your kitchen. Its robust construction and wheeled design allow for easy repositioning as needed, making it a practical addition to any kitchen environment.

Safety Information

- Do not exceed the maximum weight capacity of 45 kg.
- Exercise caution when moving the cart on uneven surfaces or near liquids to prevent tipping.
- Be careful of sharp edges during assembly.
- Ensure all parts are securely fastened before using the cart.
- Do not allow children to play on, with, or around the cart.

Package Contents

Before beginning assembly, verify that all components are present and undamaged. The package includes:

- All necessary screws and fasteners.
- All wooden panels for the cart structure.
- One drawer assembly.
- One adjustable shelf.
- Four wheels (casters).
- Assembly instructions sheet.

Setup and Assembly

Assembly of the SoBuy FKW102-WN kitchen cart is required. Please follow the detailed assembly instructions provided in the included manual. Ensure you have adequate space and the necessary tools (e.g., screwdriver) before starting.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the diagrams in the assembly manual.

3. Attach the casters (wheels) to the base of the cart. Ensure locking casters are positioned as desired for stability.
4. Assemble the main frame of the cart, securing all panels with the provided screws.
5. Install the drawer slides and assemble the drawer, then insert it into the designated slot.
6. Insert the adjustable shelf into the cabinet section at your preferred height.
7. Attach the cabinet door and handle.
8. Once assembled, gently test the stability and functionality of the cart.



Image: The SoBuy FKW102-WN kitchen cart, fully assembled, positioned in a modern kitchen. It features a white cabinet, a light wood countertop, a single drawer, and a cabinet door, all on wheels.



Image: A four-panel image showing the interior of the SoBuy FKW102-WN kitchen cart. It illustrates various ways to organize items on the adjustable shelf and within the drawer, including kitchen canisters, bottles, and small appliances.

Operating Instructions

The SoBuy FKW102-WN kitchen cart is designed for ease of use and versatility.

- **Mobility:** To move the cart, unlock the casters by flipping the lever on each wheel. Push the cart to your desired location.
- **Stability:** Once the cart is in position, lock the casters to prevent accidental movement. This ensures a stable surface for food preparation or serving.
- **Storage:** Utilize the top drawer for smaller items like utensils, napkins, or kitchen gadgets. The cabinet below, with its adjustable shelf, is suitable for larger items such as pots, pans, small appliances, or pantry staples.
- **Workspace:** The durable top surface can be used as an additional prep area for cooking or as a serving station.



Image: A close-up view of one of the casters (wheels) on the SoBuy FKW102-WN kitchen cart, showing the locking mechanism in the 'OFF' (unlocked) position.



Image: The top drawer of the SoBuy FKW102-WN kitchen cart is shown open, revealing its interior space suitable for storing items like folded cloths or glassware.

Maintenance

Proper care will extend the life and appearance of your kitchen cart.

- **Cleaning:** Wipe all surfaces with a dry cloth. For stubborn stains, use a slightly damp cloth with mild soap, then dry immediately. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Tighten if necessary to maintain stability.
- **Casters:** Keep the wheels free of debris (hair, dust, etc.) to ensure smooth movement.

Troubleshooting

If you encounter any issues with your SoBuy FKW102-WN kitchen cart, refer to the following common solutions:

- **Cart is wobbly:** Ensure all assembly screws are fully tightened. Check that the cart is on a level surface.

- **Wheels not rolling smoothly:** Inspect casters for any trapped debris (e.g., hair, lint) and remove it. Ensure the caster locks are disengaged.
- **Drawer sticking:** Check that the drawer slides are properly aligned and free of obstructions. Ensure the drawer is not overloaded.
- **Door not closing properly:** Verify that the hinges are correctly installed and tightened. Check for any obstructions inside the cabinet.

If problems persist, please contact customer support.

Specifications

Model Number	FKW102-WN
Brand	SoBuy
Material	Medium Density Fiberboard (E1), Manufactured Wood, Rubberwood (top finish)
Dimensions (L x W x H)	68 cm x 46 cm x 90 cm
Item Weight	19.2 kg
Maximum Weight Capacity	45 kg
Number of Drawers	1
Number of Shelves	1
Color	White
Style	Modern
Assembly Required	Yes



Image: A diagram illustrating the dimensions of the SoBuy FKW102-WN kitchen cart, showing a height of 90cm, a width of 46cm, and a depth of 68cm.

Warranty and Support

For warranty information, details on returns, or to obtain customer support, please refer to the documentation included with your purchase. You may also visit the official SoBuy website or contact their customer service department directly for assistance with your FKW102-WN kitchen cart.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09NBS4XH7

More documents and user manuals: **https://manuals.plus/**