

[Manuals.plus](#) /

› [WEEMSBOX](#) /

› WEEMSBOX T7 Wired Gaming Mouse User Manual

WEEMSBOX T7

WEEMSBOX T7 Wired Gaming Mouse User Manual

Model: T7 | Brand: WEEMSBOX

INTRODUCTION

Thank you for choosing the WEEMSBOX T7 Wired Gaming Mouse. This high-precision gaming mouse is designed to enhance your gaming and everyday computing experience with its adjustable DPI, programmable buttons, and vibrant RGB lighting. This manual provides detailed instructions to help you set up, operate, and maintain your new gaming mouse.





Image: The WEEMSBOX T7 Wired Gaming Mouse, showcasing its ergonomic design and vibrant blue RGB lighting elements.

PACKAGE CONTENTS

- 1 x WEEMSBOX T7 Wired Gaming Mouse
- 1 x User Manual

SETUP GUIDE

The WEEMSBOX T7 Gaming Mouse is designed for plug-and-play convenience. Follow these simple steps to get started:

1. **Connect the Mouse:** Locate an available USB port on your computer (PC or Laptop). Insert the USB connector of the WEEMSBOX T7 Gaming Mouse firmly into the USB port.
2. **Driver Installation (Automatic):** Your operating system (Windows 10, Windows 8, Windows 7, Windows XP, VISTA) will automatically detect and install the necessary drivers. No manual driver installation is typically required for basic functionality.

3. **Software Installation (Optional for Customization):** For advanced customization, including programming buttons and adjusting RGB lighting effects, you may need to download and install the dedicated software from the official WEEMSBOX website. *Note: Apple computers (Mac OS) do not support the mouse's customized (programmable) functions, though normal functions can still be used.*



Image: A hand operating the WEEMSBOX T7 mouse, highlighting its wired connection and compatibility with various operating systems.

OPERATING INSTRUCTIONS

DPI Adjustment

The mouse features adjustable DPI (Dots Per Inch) settings, allowing you to change cursor sensitivity on the fly. This is crucial for different tasks, from precise aiming in games to fast navigation on your desktop.

- Press the **DPI+** button (usually located behind the scroll wheel) to increase DPI.
- Press the **DPI-** button (usually located behind the scroll wheel) to decrease DPI.
- The mouse supports DPI levels from 1200 to 7200. Common settings include 1200, 2400, 3500, 5500, and 7200 DPI.

5 ADJUSTABLE DPI

Press the button to switch DPI

2400
DPI

3500
DPI

5500
DPI

1200
DPI

7200
DPI



Image: Visual representation of the five adjustable DPI settings available on the WEEMSBOX T7 Gaming Mouse.

Freely Adjust for Better Gaming Control



Image: A graphic detailing the various adjustable parameters including DPI, polling rate, mouse sensitivity, scrolling speed, and double-click speed.

Programmable Buttons

The WEEMSBOX T7 features 7 programmable buttons, allowing for extensive customization to suit your gaming style or workflow. Customization requires the official software.

- **Left Button:** Standard left-click.
- **Right Button:** Standard right-click.
- **Middle Button (Scroll Wheel Click):** Standard middle-click.
- **Forward Button:** Default for navigating forward in web browsers or file explorers.
- **Backward Button:** Default for navigating backward in web browsers or file explorers.
- **DPI+ Button:** Increases DPI sensitivity.
- **DPI- Button:** Decreases DPI sensitivity.

Using the software, you can assign macros, media controls, keyboard functions, and more to these buttons.

7 PROGRAMMABLE BUTTONS

Driver is downloadable via our website





Image: The mouse displayed next to its software interface, illustrating the extensive customization options for its 7 programmable buttons.



Image: A clear diagram indicating the location and default function of each of the mouse's buttons.

RGB Backlighting

The WEEMSBOX T7 features vibrant RGB LED backlighting with 16 million color options, enhancing your setup's aesthetics. The lighting effects can be customized or turned off via the dedicated software.



Image: The mouse displayed with various RGB backlight colors, demonstrating the 16 million color options.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your WEEMSBOX T7 Gaming Mouse, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the mouse regularly. For stubborn dirt or grime, slightly dampen the cloth with water or a mild electronics cleaner. Avoid harsh chemicals or abrasive materials.
- **Sensor Care:** Keep the optical sensor on the underside of the mouse clean and free from dust or debris. Use a cotton swab or compressed air if necessary.
- **Cable Management:** Avoid sharp bends or excessive pulling on the USB cable to prevent damage.
- **Storage:** When not in use, store the mouse in a clean, dry environment away from extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your WEEMSBOX T7 Gaming Mouse, please refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Mouse not responding	Loose USB connection, faulty USB port, driver issue.	<p>Ensure the USB cable is securely plugged into a working USB port.</p> <p>Try a different USB port on your computer.</p> <p>Restart your computer.</p> <p>Check Device Manager (Windows) for any driver errors and update/reinstall drivers if necessary.</p>
Cursor erratic or not moving smoothly	Dirty optical sensor, unsuitable mouse pad surface.	<p>Clean the optical sensor on the underside of the mouse.</p> <p>Use the mouse on a clean, uniform surface or a high-quality mouse pad.</p>
Programmable buttons not working	Software not installed or configured correctly, Mac OS.	<p>Ensure the WEEMSBOX customization software is installed and running.</p> <p>Verify button assignments within the software.</p> <p>Remember that programmable functions are not supported on Mac OS.</p>
RGB lighting not working or stuck	Software setting, power issue.	<p>Check RGB settings in the WEEMSBOX customization software.</p> <p>Unplug and replug the mouse.</p>

SPECIFICATIONS

Feature	Detail
Brand	WEEMSBOX
Model Number	T7
Connectivity Technology	USB Wired
Movement Detection Technology	Optical
DPI Range	1200-7200 DPI (Adjustable)
Programmable Buttons	7 Buttons
Backlighting	Breathing RGB LED (16 Million Colors)
Product Dimensions	4.7 x 2.8 x 0.04 inches
Item Weight	10.2 ounces
Compatibility	Windows 10, Windows 8, Windows 7, Windows XP, VISTA (Mac OS for basic functions only)
Manufacturer	Lizsword
Date First Available	December 9, 2021

WARRANTY AND SUPPORT

WEEMSBOX products are designed for durability and performance. For specific warranty details and support inquiries, please refer to the warranty information provided with your purchase or visit the official WEEMSBOX website.

If you require technical assistance or have questions not covered in this manual, please contact WEEMSBOX customer support through their official channels.