

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Fossil](#) /
- › [Fossil Men's Neutra Quartz Stainless Steel and Leather Chronograph Watch User Manual](#)

Fossil FS5907

Fossil Men's Neutra Quartz Stainless Steel and Leather Chronograph Watch User Manual

Model: FS5907 | Brand: Fossil

INTRODUCTION

This manual provides essential information for the operation, maintenance, and care of your Fossil Men's Neutra Quartz Stainless Steel and Leather Chronograph Watch. Designed with precision and style, this timepiece embodies Fossil's commitment to quality and durability.





Front view of the Fossil Neutra Quartz Watch, showcasing its blue sunray dial and stainless steel bracelet.

KEY FEATURES

- **Design:** 42mm Neutra Moonphase with a blue sunray dial, moonphase multifunction movement, and stainless steel bracelet. Inspired by mid-century architecture, featuring simple proportions, symmetry, a sculpted case, and a blend of brushed and polished finishes.
- **Case & Movement:** 42mm case, 22mm band width, hardened mineral crystal lens resistant to scratches, Moonphase movement with multifunction analog display.
- **Dial:** Round silver stainless steel case with a blue sunray dial, an opening for a sun/moon graphic disc, and silver accents.
- **Watch Band:** Silver, durable stainless steel bracelet band with a secure fold-over clasp closure. Links

can be removed for a customized fit. Interchangeable with all Fossil 22mm watch straps.

- **Water Resistance:** Up to 50 meters (165 feet), suitable for short periods of recreational swimming and showering, but not for diving or snorkeling (5 ATM).



Detailed view highlighting the sculpted case and symmetrical dial layout for clear readability.

SETUP

Setting Time and Date

1. **Pull out the Crown:** Gently pull the crown (the knob on the side of the watch) to position 2 for setting the date, or position 3 for setting the time.
2. **Set the Date:** In position 2, turn the crown clockwise or counter-clockwise to adjust the date.
3. **Set the Time:** In position 3, turn the crown to move the hour and minute hands. Ensure you set the correct AM/PM for the moonphase function.
4. **Push in the Crown:** Once set, push the crown back into position 1 to start the watch.

Adjusting the Moonphase

The moonphase sub-dial typically advances with the time. To ensure accuracy, set the time and date first. The moonphase indicator will cycle through its phases over approximately 29.5 days. If the moonphase is incorrect, you may need to advance the time manually until the correct moon phase is displayed, or consult the detailed user manual for specific adjustment procedures.


Adjusting the Bracelet

The stainless steel bracelet features removable links for a customized fit. It is recommended to have a professional jeweler or watch repair service adjust the bracelet to prevent damage. The band is interchangeable with any 22mm Fossil watch strap.

MEN'S CASE SIZE GUIDE

Wrists come in all sizes. Use this handy guide to find the right watch for you!

Print on 8.5 x 11 paper at 100% scale.



Fossil's general case size guide, illustrating different watch diameters and case thicknesses to help determine fit.

OPERATING THE WATCH

Your Neutra Moonphase watch features a multifunction analog display. The sub-dials typically indicate the day of the week, date, and moonphase. The main hands display hours, minutes, and seconds.

- **Time Display:** The large hour, minute, and second hands indicate the current time.
- **Day of Week Sub-dial:** One sub-dial displays the current day of the week (e.g., MON, TUE).
- **Date Sub-dial:** Another sub-dial indicates the current date (1-31).
- **Moonphase Sub-dial:** This sub-dial shows the current phase of the moon, cycling through new moon, first quarter, full moon, and last quarter.

For detailed instructions on specific sub-dial adjustments beyond basic time setting, please refer to the comprehensive user manual available online or via the provided PDF links.



The Fossil Neutra watch worn on a wrist, demonstrating its fit and appearance.

MAINTENANCE

Water Resistance

Your watch is water resistant up to 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming and showering. However, it is **not** suitable for diving, snorkeling, or high-impact water sports. Avoid operating the crown or pushers when the watch is wet to prevent water ingress.

Cleaning

To maintain the appearance of your watch:

- Wipe the case and crystal with a soft, damp cloth.
- For the stainless steel bracelet, use a soft brush with mild soapy water, then rinse thoroughly and dry with a soft cloth.
- Avoid using harsh chemicals, solvents, or abrasive cleaners.

Battery Replacement

This watch is powered by a quartz movement and requires a battery. When the battery runs low, the watch may stop or lose accuracy. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance integrity.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch has stopped or is losing time.	Low battery.	Replace the battery. Contact a professional watch repair service.
Date or day is incorrect.	Needs manual adjustment.	Pull the crown to position 2 and adjust the date/day. Ensure AM/PM is correct.

Problem	Possible Cause	Solution
Moonphase is incorrect.	Needs manual adjustment or time was set incorrectly.	Advance the time manually until the correct moon phase is displayed, or consult the full user manual.
Condensation inside the crystal.	Temperature change or water ingress.	If minor, it may dissipate. If persistent or significant, seek professional service immediately to prevent damage.

SPECIFICATIONS

Attribute	Value
Product Dimensions	1.65 x 0.87 x 0.43 inches
Item Model Number	FS5907
Weight	3.53 ounces
Department	Mens
Batteries	1 Product Specific battery (included)
Date First Available	December 9, 2021
Manufacturer	Fossil
Water Resistance	50m (165ft) / 5 ATM
Case Size	42mm
Band Width	22mm
Lens Material	Hardened Mineral Crystal

WARRANTY AND SUPPORT

Fossil watches typically come with a limited warranty covering manufacturing defects. For specific warranty terms and conditions, please refer to the official Fossil website or the documentation included with your

purchase.

For further assistance, including detailed operating instructions, warranty claims, or repair services, please visit the official Fossil support website or contact their customer service. You can also refer to the digital user guides:

- [User Guide \(PDF\)](#)
- [User Manual \(PDF\)](#)



The Fossil Watch Tin

For over three decades, we've created thousands of designs that have become as much a part of the Fossil brand as the products themselves. Inspired by vintage graphics and our curious and creative spirit, they're collected, coveted and well-known for sparking interesting conversations.

Fossil watch tins, which often contain product documentation and serve as collectible packaging.

© 2025 Fossil. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.