

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [tectake](#) /

› [tectake Wicker Bistro Set Hamburg Instruction Manual](#)

tectake Hamburg

tectake Wicker Bistro Set Hamburg Instruction Manual

Model: Hamburg

1. INTRODUCTION

This manual provides essential information for the safe and proper use, maintenance, and care of your tectake Wicker Bistro Set Hamburg. This compact and elegant outdoor furniture set is designed for balconies, terraces, and gardens, offering a comfortable seating solution with a space-saving design.



Image: The tectake Wicker Bistro Set Hamburg, featuring two chairs and a glass-top table, displayed in an outdoor setting.

2. SAFETY INSTRUCTIONS

- **Tipping Hazard:** There is a potential tipping risk if chairs are overloaded or used improperly. Always ensure the chairs are stable and used correctly.
- **Weight Limits:** Do not exceed the maximum load capacity for the chairs (100 kg per chair) and the table (50 kg).
- **Glass Top Care:** Handle the glass table top with care to prevent breakage. Avoid placing excessively hot items directly on the glass without protection.
- **Outdoor Use:** While the set is weather-resistant, it is recommended to use a protective cover during harsh weather conditions or prolonged periods of non-use to prevent material fatigue and discoloration.
- **Assembly:** This set is delivered assembled. Do not attempt to disassemble or modify the structure, as this may compromise its stability and safety.

3. PACKAGE CONTENTS

Your tectake Wicker Bistro Set Hamburg package includes:

- 2 x Wicker Chairs with Cushions
- 1 x Wicker Table with Glass Top

4. SETUP

The tectake Wicker Bistro Set Hamburg is delivered fully assembled. No additional assembly steps are required. Simply unpack the set and place it in your desired outdoor location.

For space-saving storage, the chairs can be neatly pushed under the table when not in use. This compact design makes it ideal for smaller balconies or patios.



Image: The bistro set demonstrating its space-saving feature, with chairs neatly tucked under the table.

5. OPERATING THE SET

The bistro set is designed for comfortable outdoor seating. Place the chairs and table in a stable, level area. The comfortable, water-repellent seat cushions provide enhanced comfort. The glass table top offers a stable surface for drinks and small items.

6. MAINTENANCE

6.1 Cleaning

- **Wicker Frame:** Clean the polyrattan weave with a soft cloth, mild soap, and water. Rinse thoroughly and allow to air dry. Avoid abrasive cleaners or harsh chemicals.
- **Glass Top:** The glass table top can be cleaned with standard glass cleaner and a soft cloth. It is removable for easier cleaning.
- **Cushions:** The seat cushion covers are water-repellent, removable, and washable. Follow the care instructions on the cushion label for washing. Ensure cushions are completely dry before storing to prevent mold or mildew.



Image: Close-up of water beading on the water-repellent cushion fabric, highlighting its easy-care properties.

6.2 Storage

To prolong the lifespan and maintain the appearance of your bistro set, especially the polyrattan and cushions, it is recommended to use a protective cover when the set is not in use for extended periods or during adverse weather conditions. Store cushions indoors in a dry place during winter months.

7. TROUBLESHOOTING

- **Instability:** Ensure the set is placed on a flat, level surface. Check for any debris under the feet of the chairs or table.
- **Damage:** If you notice any damage to the frame, wicker, or glass, discontinue use and contact customer support for assistance.

8. SPECIFICATIONS

| Feature | Detail |
|--------------------------------------|---|
| Brand | tectake |
| Model Name | Hamburg |
| Color | Black |
| Style | Modern |
| Material | Aluminum frame, Polyrattan weave, Glass table top, Polyester cushions |
| Assembly Required | No (delivered assembled) |
| Total Item Weight | 10.6 kg |
| Chair Load Capacity | 100 kg per chair |
| Table Load Capacity | 50 kg |
| Approx. Chair Dimensions (L x W x H) | 42.5 x 47.5 x 70 cm (Chair 1), 42.5 x 48 x 70 cm (Chair 2) |
| Approx. Table Dimensions (L x W x H) | 58.5 x 48.5 x 73.5 cm |
| Glass Plate Dimensions (L x W x H) | 53.5 x 43.7 x 0.5 cm |



Image: Detailed product information including dimensions, materials, and load capacities for the bistro set.

9. WARRANTY & SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Ensure you have your purchase details and product model number (Hamburg) available when contacting support.

