



Manuals.plus /

› Smoby /

› Smoby Children's House Jolie Model 810721 Instruction Manual

Smoby 810721

Smoby Children's House Jolie (Model 810721) Instruction Manual

Your guide to assembly, operation, and maintenance.

1. INTRODUCTION

The Smoby Children's House Jolie is an outdoor playhouse designed to provide a fun and imaginative play environment for children. This durable playhouse features a passage door, two windows with red slats, and sliding windows. It is constructed with solid and sturdy materials and includes anti-UV treatment for enhanced durability against sun exposure. This manual provides essential information for the safe assembly, operation, and maintenance of your playhouse.



Image 1.1: The Smoby Children's House Jolie, an outdoor playhouse for children.

2. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before assembling and using the Smoby Children's House Jolie. Failure to follow these instructions may result in injury.

- **Adult Supervision:** Always ensure children are supervised by an adult when playing in or around the playhouse.
- **Assembly:** Adult assembly is required. Keep small parts and packaging materials away from children during assembly.
- **Placement:** Place the playhouse on a flat, level, and stable outdoor surface, away from any hazards such as fences, trees, or other structures. Ensure adequate clear space around the playhouse.
- **Hazard Avoidance:** Keep the playhouse away from open flames, heat sources, and electrical outlets.
- **Inspection:** Regularly inspect the playhouse for any signs of wear, damage, or loose components. Do not

use if damaged.

- **Age Recommendation:** This playhouse is recommended for children aged 24 months to 10 years.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all components listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Wall panels (various sizes)
- Roof sections
- Door panel
- Window frames and slats
- Fasteners (screws, clips, etc.)
- Instruction Manual (this document)

Note: Specific quantities and types of fasteners may vary. Refer to the detailed parts list provided in the physical packaging.

4. SETUP AND ASSEMBLY

Follow these general steps for assembling your Smoby Children's House Jolie. For detailed, step-by-step instructions and diagrams, refer to the assembly guide included in your product packaging.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and identify each part using the provided parts list.
2. **Assemble the Base:** Begin by connecting the base panels or the lower sections of the wall panels to form the foundation of the playhouse. Ensure these connections are secure and stable.
3. **Attach Wall Panels:** Connect the remaining wall panels, ensuring they slot correctly into place and are aligned. Secure them with the provided fasteners.
4. **Install Door and Windows:** Insert the door panel into its designated opening. Attach the window frames and slide the window slats into position.
5. **Secure the Roof:** Place the roof sections onto the assembled walls, ensuring they fit snugly and are securely fastened.
6. **Final Check:** Once assembled, double-check all connections, screws, and fasteners to ensure they are tight and secure. The playhouse should be stable and free of any wobbly parts.



Image 4.1: Children enjoying the assembled Smoby Children's House Jolie.

5. OPERATING INSTRUCTIONS

The Smoby Children's House Jolie is designed for simple and intuitive use by children within the recommended age range.

- **Entry and Exit:** Children can easily enter and exit the playhouse through the passage door. Ensure the door operates smoothly and does not stick.
- **Window Operation:** The windows feature sliding slats. Children can slide these slats to open or close the windows, allowing for ventilation and interactive play.
- **Imaginative Play:** Encourage children to engage in imaginative role-playing and creative activities within the playhouse.

6. MAINTENANCE

Regular maintenance will help prolong the life of your Smoby Children's House Jolie and ensure continued safe play.

- **Cleaning:** Clean the playhouse periodically with a damp cloth and mild soap. Rinse thoroughly with water. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the plastic and its anti-UV treatment.
- **Inspection:** Conduct routine inspections of the entire structure. Check for any cracks, breaks, or sharp edges on the plastic components. Ensure all screws and fasteners remain tight. Tighten any loose connections immediately.
- **UV Protection:** The playhouse features anti-UV treatment to resist fading and degradation from sun exposure. However, extreme prolonged exposure to harsh weather conditions may still affect its appearance and structural integrity over time.
- **Storage:** If possible, consider storing the playhouse indoors or covering it during periods of extreme weather (e.g., heavy snow, strong winds) to further extend its lifespan.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your playhouse.

- **Issue:** Parts do not fit together during assembly.
Solution: Verify that you are using the correct parts according to the assembly diagram. Ensure components are oriented correctly. Sometimes, a gentle but firm push is needed to snap parts into place.
- **Issue:** The assembled playhouse feels unstable or wobbly.
Solution: Re-check all fasteners and connections to ensure they are securely tightened. Confirm that the playhouse is placed on a completely flat and level surface. Uneven ground can cause instability.
- **Issue:** Door or windows are stiff or difficult to operate.
Solution: Check for any obstructions in the tracks or hinges. Clean the areas with a damp cloth to remove dirt or debris. A small amount of silicone-based lubricant (avoid oil-based) can be applied to sliding parts if necessary, but ensure it is safe for children's toys.

8. SPECIFICATIONS

Feature	Detail
Model Number	810721
Product Dimensions (L x W x H)	43.31 x 38.58 x 50 inches (110 x 98 x 127 cm)
Item Weight	31.4 pounds (14.24 kg)
Recommended Age	24 months - 10 years
Material	Durable plastic with anti-UV treatment
Features	Passage door, 2 windows with red slats, sliding windows



Image 8.1: Dimensional diagram of the Smoby Children's House Jolie.

9. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or to obtain replacement parts, please contact Smoby customer service directly. It is recommended to retain your proof of purchase (receipt) as it may be required for warranty claims.

Please refer to the contact information provided on the product packaging or the official Smoby website for the most up-to-date support details.