

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [InnoGIO](#) /

› [InnoGIO GIOwarm Smart Digital Bottle Warmer & Sterilizer User Manual \(Model GIO-935PINK\)](#)

## InnoGIO GIO-935PINK

# InnoGIO GIOwarm Smart Digital Bottle Warmer & Sterilizer

Model: GIO-935PINK

[Safety Information](#)   [Product Overview](#)   [Setup](#)   [Operating](#)  
[Modes](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. SAFETY INFORMATION

Please read all instructions carefully before using the InnoGIO GIOwarm Smart Digital Bottle Warmer & Sterilizer. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always keep the appliance out of reach of children.
- Do not immerse the base unit in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only accessories recommended by the manufacturer.
- Always check the temperature of the warmed food or milk before feeding your baby.
- This appliance is for household use only.
- Exercise caution when handling hot steam and hot water.

## 2. PRODUCT OVERVIEW

The InnoGIO GIOwarm Smart is a versatile device designed to warm baby bottles, food, and sterilize baby accessories. It features a compact design and an intuitive digital control panel.



Image: The InnoGIO GIOWarm Smart Digital Bottle Warmer and Sterilizer, shown next to its product packaging. The device is white with a clear top cover and a digital control panel on the front. The packaging displays the product name and features.

## Components:

1. Main Unit (Base with heating plate and control panel)
2. Transparent Cover
3. Basket/Lift-out tray (for bottles/accessories)
4. Measuring Cup (may be included for water measurement)

## 3. SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, clean all parts that will come into contact with milk or food. Wipe the main unit with a damp cloth. Wash the transparent cover and basket in warm soapy water, then rinse thoroughly.
3. **Placement:** Place the main unit on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit.

4. **Power Connection:** Plug the power cord into a suitable electrical outlet. The device will typically emit a beep and the display may light up briefly.

## 4. OPERATING MODES

The GIOwarm Smart offers 5 distinct operating modes, accessible via the intuitive digital control panel.

### 4.1. Quick Heating Mode

This mode is designed for rapidly heating milk or baby food to a desired temperature.

1. Place the bottle or food jar into the basket and then into the main unit.
2. Add the appropriate amount of water (refer to the manual for specific quantities based on bottle size/food volume).
3. Select the "Quick Heating" mode on the control panel.
4. Adjust the target temperature (e.g., 37°C for milk) using the temperature controls.
5. The device will begin heating and automatically shut off once the target temperature is reached.
6. Carefully remove the bottle/jar using the basket handle and check the temperature before feeding.

### 4.2. Keep Warm Mode

This mode maintains a constant temperature for a prolonged period, ideal for night feedings.

1. Follow steps 1-2 from Quick Heating Mode.
2. Select the "Keep Warm" mode.
3. Set the desired holding temperature. The device will heat to this temperature and then maintain it.

### 4.3. Defrost Mode

Safely defrosts frozen breast milk or baby food.

1. Place the frozen item (e.g., breast milk bag, food jar) into the basket.
2. Add water to the main unit as specified for defrosting.
3. Select the "Defrost" mode. The device will gently thaw the contents.
4. Once defrosted, the item can be further warmed if needed using Quick Heating or Breast Milk Warming mode.

### 4.4. Breast Milk Warming Mode

This mode uses a gentle heating process to preserve nutrients in breast milk.

1. Place the bottle with breast milk into the basket.
2. Add water to the main unit.
3. Select the "Breast Milk Warming" mode. This mode typically operates at a lower, controlled temperature (e.g., 37°C) to avoid overheating.
4. The device will gently warm the milk. Always check the temperature before feeding.

### 4.5. Sterilization Mode

This mode uses steam to sterilize bottles, pacifiers, and other small baby accessories, eliminating up to 99.9% of bacteria.

1. Ensure items to be sterilized are clean and rinsed.

2. Place bottles (upside down) and other accessories into the basket.
3. Add the recommended amount of water (e.g., 100-120ml) to the main unit. Do not overfill.
4. Place the transparent cover securely on the unit.
5. Select the "Sterilization" mode. The device will generate steam to sterilize the contents.
6. Once the cycle is complete, the device will automatically shut off. Allow items to cool before carefully removing them.

## 5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance ensure optimal performance and longevity of your InnoGIO GIOWarm Smart.

### 5.1. Daily Cleaning

- Always unplug the appliance and allow it to cool completely before cleaning.
- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaning agents.
- Wash the transparent cover and basket in warm soapy water, then rinse thoroughly and air dry.
- Empty any remaining water from the heating plate after each use.

### 5.2. Descaling

Mineral deposits (limescale) can build up on the heating plate, especially in areas with hard water. Descaling the unit regularly (e.g., once a month or as needed).

1. Mix 50ml of white vinegar with 100ml of cold water.
2. Pour the mixture onto the heating plate.
3. Allow it to soak for 30 minutes to 1 hour, or until the limescale dissolves. Do not turn on the appliance during this process.
4. Pour out the mixture and rinse the heating plate thoroughly with clean water.
5. Wipe dry with a clean cloth.

## 6. TROUBLESHOOTING

If you encounter issues with your InnoGIO GIOWarm Smart, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Not plugged in; power outlet issue; damaged cord.	Ensure the plug is securely inserted. Test the outlet with another appliance. Check the power cord for damage.
Milk/food not warming.	Insufficient water; incorrect mode selected; limescale buildup.	Add the correct amount of water. Select the appropriate warming mode. Descaling the heating plate.
Sterilization not effective.	Insufficient water; cover not sealed properly; items not clean before sterilization.	Add the recommended amount of water. Ensure the cover is tightly closed. Pre-clean items thoroughly.

Problem	Possible Cause	Solution
Error message on display.	Specific error code (refer to full manual); overheating.	Unplug the device, wait 10 minutes, then plug it back in. If the error persists, contact customer support.

## 7. SPECIFICATIONS

**Model:** GIO-935PINK

**Brand:** InnoGIO

**Power Consumption:** 400 W

**Adjustable Temperature Range:** 35°C to 100°C

**Dimensions:** Approximately 28 x 11 x 11 cm (Height x Width x Depth)

**Material Composition:** Synthetic material

**ASIN:** B09NCCPRQF

## 8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official InnoGIO website. Keep your proof of purchase for warranty claims.

**Manufacturer:** InnoGIO

**Website:** [www.innogio.com](http://www.innogio.com) (Note: This is a placeholder URL. Please refer to your product documentation for the correct support contact information.)