

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [JBL](#) /

> [JBL Flip 6 Portable Bluetooth Speaker User Manual](#)

## JBL JBLFLIP6GREN

# JBL Flip 6 Portable Bluetooth Speaker User Manual

Model: JBLFLIP6GREN

## INTRODUCTION

---

This manual provides essential instructions for setting up, operating, and maintaining your JBL Flip 6 portable Bluetooth speaker. Please read this manual thoroughly to ensure proper use and to maximize your audio experience.



Image: The JBL Flip 6 portable Bluetooth speaker, shown in green, featuring its cylindrical design and fabric grille.

## WHAT'S IN THE BOX

---

Upon unboxing your JBL Flip 6, verify that all the following components are included:

- JBL Flip 6 Portable Bluetooth Speaker
- USB Type-C Cable
- Quick Start Guide
- Warranty Card
- Safety Sheet



Image: The JBL Flip 6 speaker displayed within its retail packaging, alongside its included accessories.

## SETUP

---

### 1. Charging the Speaker

Before initial use, fully charge your JBL Flip 6.

1. Connect the provided USB Type-C cable to the charging port on the speaker.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included).
3. The LED indicator will show charging status. A full charge provides up to 12 hours of playtime.

### 2. Power On/Off

- To power on, press the **Power button** located on the speaker.
- To power off, press and hold the **Power button** again.

### 3. Bluetooth Pairing

Connect your JBL Flip 6 to a Bluetooth-enabled device for wireless audio streaming.

1. Power on the JBL Flip 6.
2. Press the **Bluetooth button** on the speaker. The LED indicator will flash, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "JBL Flip 6" from the list of devices to connect.

5. Once connected, the Bluetooth LED will remain solid. You can connect up to two devices simultaneously.



Image: Top view of the JBL Flip 6 speaker, highlighting the power, Bluetooth, volume, and play/pause control buttons.

## OPERATING INSTRUCTIONS

---

### Basic Playback Controls

- **Play/Pause:** Press the Play button once.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Skip Track:** Double-press the Play button to skip to the next track.

### JBL PartyBoost

Amplify your listening experience by connecting multiple JBL PartyBoost compatible speakers.

1. Ensure both JBL speakers are powered on.
2. Press the **PartyBoost button** on the first speaker.
3. Press the **PartyBoost button** on the second speaker.
4. The speakers will connect automatically, playing audio in sync.

### JBL Portable App

Download the JBL Portable app for additional features and to customize your audio settings, including equalization.

- Search for "JBL Portable" in your device's app store.
- Install the app and follow the on-screen instructions to connect to your Flip 6.

### Waterproof and Dustproof Usage (IP67)

The JBL Flip 6 is rated IP67, meaning it is resistant to dust and can be submerged in water up to 1 meter for 30 minutes.

- Ensure the charging port cover is securely closed before exposing the speaker to water or dust.
- After exposure to water, dry the speaker thoroughly before charging.
- Avoid exposing the speaker to saltwater or other chemicals.



Image: The JBL Flip 6 speaker positioned next to a swimming pool, demonstrating its waterproof capability.

## MAINTENANCE

---

### Cleaning

- Gently wipe the speaker with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- Ensure the speaker is completely dry before charging or storing.

### Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, charge the battery to approximately 50% to preserve battery health.

## TROUBLESHOOTING

---

If you encounter issues with your JBL Flip 6, refer to the following common solutions:

Problem	Solution
Speaker does not power on	Ensure the battery is charged. Connect the speaker to a power source using the USB Type-C cable.
Cannot pair via Bluetooth	Ensure the speaker is in pairing mode (Bluetooth LED flashing). Disable and re-enable Bluetooth on your device. Forget "JBL Flip 6" from your device's Bluetooth settings and attempt to pair again. Move the speaker closer to your device.
No sound or low volume	Increase the volume on both the speaker and your connected device. Ensure the speaker is properly paired and connected. Check if the audio source is playing.
PartyBoost not connecting	Ensure both speakers are JBL PartyBoost compatible. Press the PartyBoost button on both speakers within a few seconds of each other. Ensure speakers are within close proximity.

## SPECIFICATIONS



Image: The JBL Flip 6 speaker with its approximate dimensions (length, height, depth) indicated.

Feature	Detail
Model Name	JBLFLIP6GREN
Brand	JBL
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Speaker Type	Portable Bluetooth Speaker
Maximum Output Power	30 Watts
Frequency Response	20 KHz (upper limit, typical for full range)
Battery Life	Up to 12 hours
Waterproof Rating	IP67 (Waterproof and Dustproof)
Dimensions (L x W x H)	17.8 x 7.2 x 6.8 cm (approx. 7.0 x 2.8 x 2.7 inches)
Weight	550 Grams (approx. 1.21 lbs)

Feature	Detail
Control Method	App, Buttons
Power Source	Battery Powered





Image: An exploded diagram illustrating the internal components of the JBL Flip 6, including the racetrack-shaped driver, tweeter, and passive radiators for enhanced sound and deep bass.

## WARRANTY AND SUPPORT

---

### Warranty Information

The JBL Flip 6 comes with a full warranty, typically covering manufacturing defects for a period of 12 months from the date of purchase. Please refer to the included Warranty Card for specific terms and conditions.

For details regarding returns or defective products, consult the retailer's policy or the official JBL support channels.

### Customer Support

For further assistance, technical support, or warranty claims, please visit the official JBL support website or contact their customer service.

[Visit JBL Support](#)

