

[Manuals.plus](#) /

› [SortWise](#) /

› SortWise Expandable Clothes Rack (Model SW-MHJ-0329G2) Instruction Manual

SortWise SW-MHJ-0329G2

SortWise Expandable Clothes Rack Instruction Manual

Brand: SortWise | **Model:** SW-MHJ-0329G2

PRODUCT OVERVIEW

The SortWise Expandable Clothes Rack is a versatile and mobile storage solution designed for organizing garments and accessories in various living spaces. Its adjustable design allows for customization to fit different clothing lengths and room layouts, while integrated shelves provide additional storage for shoes and other items. Equipped with wheels, it offers easy mobility and includes brake locks for stability.



Image: The SortWise Expandable Clothes Rack shown in a room, laundry area, balcony, and shower room, highlighting its versatile use.

SETUP AND ASSEMBLY

The SortWise Expandable Clothes Rack is designed for hassle-free, tool-free installation. Follow these steps to assemble your rack:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list (refer to the assembly diagram below).
2. **Assemble the Base:** Connect the base rods and secure them according to the diagram.
3. **Attach Vertical Poles:** Insert the vertical support poles into the designated slots on the base.
4. **Install Hanging Rods:** Attach the main hanging rod to the top of the vertical poles. Ensure all connections are firm.
5. **Attach Wheels:** Screw the four smooth-rolling wheels into the base. For better braking, install wheels with brakes diagonally.

opposite each other.

INSTANT ACCESS, NO MORE MESS



Before storage



After storage

Image: Detailed assembly diagram showing the step-by-step process for setting up the clothes rack.

TOOL-FREE INSTALLATION




Image: Close-up view demonstrating the tool-free installation and clip-on mechanism for securing components.

Assembly Video

Your browser does not support the video tag.

Video: This video demonstrates the assembly process and highlights key features of the clothes rack, including its adjustable design and mobility.

OPERATING INSTRUCTIONS

Maximize the utility of your SortWise Expandable Clothes Rack with its flexible features:

- **Adjustable Height and Length:** The main hanging rod's height can be adjusted from 103cm to 175cm to accommodate

various garment lengths. Both rod ends extend by 20cm, providing extra space for lighter items.

- **Storage Shelves:** Utilize the top and bottom shelves to neatly organize shoes, bags, folded clothes, or storage boxes.
- **Mobility and Stability:** The rack is equipped with four smooth-rolling wheels for easy movement. Engage the brake locks on the wheels to keep the rack securely in place when needed.

HIGHLY ADJUSTABLE LENGTH AND HEIGHT




Image: Illustration of the highly adjustable length and height features of the clothes rack, showing the 20mm extension.



**30% MORE STORAGE WITH
EXTRA TOP SHELF**



Image: The clothes rack featuring an extra top shelf, demonstrating increased storage capacity for items like storage boxes.



Image: Close-up of the 360-degree rotating wheels, emphasizing the rack's easy mobility.

MAINTENANCE

To ensure the longevity and optimal performance of your clothes rack, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down the metal frame and shelves with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Check Connections:** Periodically inspect all connections and screws to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Wheel Care:** Keep the wheels free of dust and debris to ensure smooth rolling. If wheels become stiff, clean them and apply a small amount of silicone lubricant.
- **Weight Distribution:** Distribute clothes evenly across the hanging rod and shelves to prevent strain on any single point and

maintain balance.

TROUBLESHOOTING

If you encounter any issues with your SortWise Expandable Clothes Rack, refer to the following common problems and solutions:

- **Rack is Unstable/Wobbly:**
 - Ensure all assembly screws and connections are securely tightened.
 - Verify that the rack is placed on a flat, even surface.
 - Check if the weight of the clothes is evenly distributed.
- **Wheels Not Rolling Smoothly:**
 - Inspect wheels for any trapped hair, lint, or debris and remove them.
 - Ensure the wheel brake locks are disengaged.
 - Apply a small amount of lubricant to the wheel axles if needed.
- **Adjustable Rods Not Staying in Place:**
 - Ensure the locking mechanisms for height and length adjustments are fully engaged.
 - Avoid exceeding the maximum weight capacity for the extended rod ends.

SPECIFICATIONS

Feature	Detail
Brand	SortWise
Model Number	SW-MHJ-0329G2
Color	Black
Material	Metal
Product Dimensions (D x W x H)	24D x 130W x 175H Centimetres
Adjustable Height	103cm to 175cm
Extended Rod Ends Capacity	Up to 5kg / 11lb (each end)
Main Hanging Rod Capacity	Up to 18kg
Installation Type	Free Standing
Special Feature	Adjustable Height, Mobile with Wheels

PRODUCT SIZE

Maximum Weight Capacity

Top shelf :	40 lb
Bottom shelf:	20 lb
Hanging Rod:	40 lb
Extended Rod:	11 lb




Image: Diagram illustrating the product dimensions and maximum weight capacities for different sections of the rack.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or contact SortWise customer service directly. Contact details are typically available on the product packaging or the manufacturer's official website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question