

MasterPRO 1000864300000

MasterPro by Carlo Cracco Electric Juicer User Manual

Model: 1000864300000

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your MasterPro by Carlo Cracco Electric Juicer. Please read these instructions carefully before first use and retain them for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the appliance is properly assembled before operation.
- Do not use the appliance for anything other than its intended use.
- Close supervision is necessary when any appliance is used by or near children.

PARTS DIAGRAM



Image showing the MasterPro by Carlo Cracco Electric Juicer, featuring a brushed stainless steel body, a black plastic top with a lever arm, and a clear plastic juice collection area.

Key components of your juicer include:

1. **Lever Arm:** For effortless pressing of fruits.
2. **Reamer:** The rotating cone that extracts juice from the fruit.
3. **Filter Basket:** Separates pulp and seeds from the juice.
4. **Juice Collector/Container:** Collects the extracted juice.
5. **Anti-drip Spout:** Prevents juice from dripping after use.
6. **Motor Base:** Contains the motor and electrical components.

SETUP

Follow these steps to set up your juicer for first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash all removable parts (filter basket, reamer, juice collector, lever arm components) in warm, soapy water. Rinse thoroughly and dry. The main motor base should only be wiped with a damp cloth.
3. **Assemble:**
 - Place the motor base on a stable, flat, and dry surface.
 - Position the juice collector onto the motor base.
 - Insert the filter basket into the juice collector.
 - Place the reamer onto the shaft in the center of the filter basket.
 - Ensure the lever arm assembly is securely in place over the reamer.
4. **Connect Power:** Plug the power cord into a suitable electrical outlet.

OPERATING INSTRUCTIONS

To extract juice efficiently:

1. **Prepare Fruit:** Cut citrus fruits (oranges, lemons, grapefruits, limes) in half.
2. **Place Fruit:** Place one half of the fruit, cut-side down, onto the reamer.
3. **Engage Lever:** Gently lower the lever arm over the fruit. The juicer will automatically start when pressure is applied to the reamer.
4. **Extract Juice:** Apply steady, even pressure with the lever arm to extract the juice. The juice will flow through the filter basket into the juice collector. The filter basket will separate pulp and seeds.
5. **Anti-drip Spout:** Ensure the anti-drip spout is in the open position to allow juice to flow into your glass or container. To stop the flow, push the spout upwards to close it.
6. **Repeat:** Lift the lever arm, remove the squeezed fruit half, and repeat the process with the next fruit half.
7. **Finish:** Once juicing is complete, unplug the appliance from the power outlet.

CARE AND MAINTENANCE

Proper cleaning ensures the longevity and hygiene of your juicer:

1. **Unplug:** Always unplug the juicer from the power outlet before cleaning.
2. **Disassemble:** Carefully remove the lever arm, reamer, filter basket, and juice collector from the motor base.
3. **Cleaning Removable Parts:**
 - Wash the reamer, filter basket, and juice collector in warm, soapy water immediately after use to prevent pulp from drying and sticking. A brush may be helpful for cleaning the filter mesh.
 - Rinse all parts thoroughly under running water.
 - **Important:** These parts are not dishwasher safe. Hand washing is required.
 - Dry all parts completely before reassembling or storing.
4. **Cleaning Motor Base:** Wipe the exterior of the motor base with a soft, damp cloth. Do not immerse the motor base in water or any other liquid.
5. **Storage:** Store the assembled or disassembled juicer in a clean, dry place away from direct sunlight and heat.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; power outage; improper assembly.	Ensure the power cord is securely plugged into a working outlet. Check your household's circuit breaker. Verify all parts are correctly assembled.
Poor juice extraction or reamer stops.	Too much pressure applied; fruit too large; filter basket clogged.	Apply gentle, even pressure. Ensure fruit halves fit properly on the reamer. Clean the filter basket if it appears clogged.
Juice leaks from the spout.	Anti-drip spout not fully closed.	Ensure the anti-drip spout is pushed fully upwards to the closed position.
Excessive noise or vibration.	Improper assembly; unstable surface.	Check that all components are correctly assembled and securely locked in place. Ensure the juicer is on a stable, flat surface.

If the problem persists after attempting these solutions, please contact customer support.

PRODUCT SPECIFICATIONS

- Brand: MasterPRO
- Model Number: 1000864300000
- Dimensions (L x W x H): 38 x 30 x 56 cm
- Weight: 2.14 Kilograms
- Capacity: 1.8 Liters
- Power: 100 Watts
- Material: Stainless Steel
- Special Feature: Juicer function with lever arm
- Care Instructions: Hand wash removable parts. Wipe motor base with damp cloth. Not dishwasher safe.





WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official MasterPro website. You may also contact your retailer for assistance.

For further inquiries, please visit: www.masterpro.com



Related Documents

	<p><u>MasterPRO Electric Pressure Cooker BGMP-9092 User Manual</u></p> <p>Comprehensive user manual for the MasterPRO electric pressure cooker by Carlo Cracco (Model BGMP-9092), covering components, operation, safety guidelines, technical specifications, features, and care instructions.</p>
	<p><u>MasterPRO BGMP-9089 Cordless Water Kettle User Manual</u></p> <p>Comprehensive user manual for the MasterPRO BGMP-9089 cordless water kettle, detailing components, safety precautions, operating instructions, cleaning procedures, and descaling methods.</p>
	<p><u>Manuale di Istruzioni Friggitrice ad Aria MasterPRO BGMP-9175</u></p> <p>This document provides comprehensive instructions for the MasterPRO BGMP-9175 Air Fryer, covering safety precautions, product composition, operation, cleaning, maintenance, and troubleshooting. It includes cooking guidelines and settings for various foods.</p>
	<p><u>MasterPRO BGMP-9140 Wi-Fi Thermo Cooker: User Manual and Operation Guide</u></p> <p>Comprehensive user manual for the MasterPRO BGMP-9140 Wi-Fi Thermo Cooker by Carlo Cracco. Includes setup, operation, safety instructions, cleaning, and accessory details.</p>