

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Little Tikes](#) /
- › [Little Tikes Classic Cook's Kitchen with Island Instruction Manual](#)

### Little Tikes 659997

# Little Tikes Classic Cook's Kitchen with Island Instruction Manual

Model: 659997

Brand: Little Tikes

## 1. INTRODUCTION

---

The Little Tikes Classic Cook's Kitchen with Island is a durable playset designed for interactive, 360-degree role play. It includes both a kitchen unit and a separate island, allowing multiple children to engage in imaginative cooking and serving activities. This playset features realistic elements such as easy-to-use knobs, lights, and sounds, along with opening doors for the fridge, oven, and dishwasher, providing ample storage space. It comes with a variety of accessories to enhance the play experience.

## 2. PRODUCT OVERVIEW

---

### Key Features:

- Interactive 360-degree design for imaginative role play.
- Opening doors on the refrigerator, oven, and dishwasher for realistic play and storage.
- Easy-to-use knobs, lights, and sounds for an engaging experience.
- Durable construction.
- Suitable for multiple children to play simultaneously.

### What's in the Box:

- Kitchen with Island playset.
- 16 pieces of accessories, including pots, pans, a butcher block, and various play food items.




Image: The complete Little Tikes Classic Cook's Kitchen with Island playset, showing the main kitchen unit and the separate island, with a child interacting with the island.

### 3. SETUP

Assembly is required for this product. Please follow the detailed instructions provided in the packaging. For quick and easy assembly, 3D interactive instructions are available through the BILT app.

# Assembly



POWERED BY **BILT INTELLIGENT INSTRUCTIONS**<sup>®</sup>

Image: Graphic indicating assembly requires 2 people, approximately 2 hours and 30 minutes, and involves 71 steps.

FOR QUICK &  
EASY ASSEMBLY

FIND 3D INSTRUCTIONS  
FOR THIS PRODUCT IN

**BILT.**<sup>®</sup>

DOWNLOAD THE FREE APP



Image: Instructions to download the free BILT app for quick and easy 3D assembly instructions, with App Store and Google

## 4. OPERATING INSTRUCTIONS

---

The playset is designed with various interactive features to simulate a real kitchen environment:

- **Stove Burners:** Turn the knobs on the stovetop to activate realistic cooking sounds and lights, simulating boiling water or sizzling food.
- **Oven:** Open the oven door to reveal interior lights. Place the included cookie sheet with play cookies inside for pretend baking.
- **Refrigerator & Dishwasher:** The doors on these appliances open and close, providing storage for play food and accessories.
- **Accessories:** Utilize the included pots, pans, butcher block, and play food items to create various culinary scenarios.



Image: A close-up view of the stovetop with play food (steak, egg, bacon) in a frying pan, demonstrating the interactive cooking area.



Image: A child placing a play turkey in the oven, highlighting the functional oven door and interior space.



Image: A child interacting with the refrigerator door on the kitchen island, showing its opening mechanism.

**Your browser does not support the video tag.**

Video: An official product video showcasing the Little Tikes Classic Cook's Kitchen with Island, demonstrating its various features and interactive elements.

## 5. MAINTENANCE

---

- **Cleaning:** Wipe down all surfaces with a damp cloth and mild soap as needed. Avoid abrasive cleaners that may damage the finish.
- **Battery Replacement:** The interactive lights and sounds require batteries. Refer to the assembly instructions for specific battery type and replacement procedures. Ensure batteries are inserted with correct polarity.
- **Storage:** Store the playset in a dry, cool place away from direct sunlight to prevent material degradation.

## 6. TROUBLESHOOTING

---

- **Assembly Difficulties:** If you encounter issues during assembly, double-check the instruction manual for correct part identification and placement. Ensure all screws are properly aligned and tightened. The BILT app provides 3D guidance which can be helpful.
- **Lights/Sounds Not Working:** Verify that batteries are correctly installed and are not depleted. Replace

batteries if necessary. Check for any loose connections if applicable.

- **Loose or Broken Parts:** For any loose or broken components, refer to the manufacturer's customer support for replacement parts or guidance.

## 7. SPECIFICATIONS

---

<b>Product Dimensions</b>	30.71 x 18.7 x 10.24 inches
<b>Item Weight</b>	53.9 pounds
<b>Item Model Number</b>	659997
<b>Manufacturer Recommended Age</b>	36 months - 8 years
<b>Manufacturer</b>	MGA Entertainment
<b>Release Date</b>	July 25, 2022

## 8. WARRANTY & SUPPORT

---

For detailed safety information, warranty details, and customer support, please refer to the complete User's Manual included with your product or visit the official Little Tikes website.