

Blackweb BWA21HO008C

Blackweb 1440p 5 Megapixel USB Webcam User Manual

Model: BWA21HO008C

Brand: Blackweb

1. INTRODUCTION

The Blackweb BWA21HO008C 1440p 5 Megapixel USB Webcam is designed to provide high-quality video and still image capture for your personal computer. It features an integrated adjustable light ring to ensure optimal illumination in various environments, enhancing your communication and recording experience. This manual provides instructions for setting up, operating, maintaining, and troubleshooting your webcam.

2. PRODUCT FEATURES

- Up to 1440p Resolution @ 30 frames per second (fps) for clear video.
- 5 Megapixel still image resolution for high-quality photos.
- Built-in adjustable 3-level LED ring light to provide optimal lighting.
- Adjustable base designed to fit various sizes of computer monitors, laptop screens, or stand on flat surfaces.
- USB plug and play functionality for easy setup without additional drivers.

3. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Blackweb 1440p 5 Megapixel USB Webcam (Model: BWA21HO008C)
- 1 x User Manual

4. SETUP GUIDE

4.1 Physical Setup

1. **Positioning the Webcam:** Open the adjustable base of the webcam. Place the webcam on top of your computer monitor or laptop screen, ensuring the front lip of the base rests securely on the front of the screen and the rear clip holds the back. Alternatively, the base can be folded to allow the webcam to stand on a flat surface such as a desk.
2. **Connecting to Your Computer:** Insert the USB cable from the webcam into an available USB port on your computer.



Image: Side view of the Blackweb webcam demonstrating its adjustable base for mounting on a monitor or laptop screen.



Image: Front view of the Blackweb webcam, highlighting the central lens and the surrounding adjustable light ring.

4.2 Software Setup

The Blackweb BWA21HO008C webcam is a plug-and-play device, requiring no additional driver installation for most operating systems (Windows, macOS, Chrome OS). Upon connecting, your computer should automatically detect and configure the webcam.

1. **Automatic Detection:** Once connected, your operating system should recognize the webcam as a new video device.
2. **Application Selection:** To use the webcam, open your preferred video conferencing software (e.g., Zoom, Microsoft Teams, Skype) or recording application. Navigate to the video/camera settings within the application and select "Blackweb BWA21HO008C" (or similar name) as your video input device.

5. OPERATING INSTRUCTIONS

5.1 Using the Webcam

Once connected and recognized by your system and chosen in your application, the webcam is ready for use in video calls, live streaming, or recording.

- Ensure your chosen application is open and the webcam is selected as the active camera source.
- Adjust the webcam's angle manually to frame your desired view.

5.2 Adjusting the Light Ring

The webcam features a built-in adjustable 3-level LED light ring to improve illumination in low-light conditions.

1. Locate the light control button, typically found on the top or side of the webcam body.
2. Press the button repeatedly to cycle through the brightness levels: Low, Medium, High, and Off. Select the level that best suits your lighting needs.



Image: Angled view of the Blackweb webcam, highlighting the prominent light ring and the camera lens.

6. MAINTENANCE

- **Cleaning:** To clean the webcam lens and body, use a soft, dry, lint-free cloth. Avoid using harsh chemicals, abrasive materials, or excessive moisture, as these can damage the device. Ensure the device is disconnected from your computer before cleaning.
- **Storage:** When not in use, store the webcam in a cool, dry place, away from direct sunlight, extreme temperatures, and high humidity.

7. TROUBLESHOOTING

- **No Image/Video:**
 - Ensure the USB cable is securely connected to both the webcam and your computer.
 - Try connecting the webcam to a different USB port on your computer.
 - Verify that the webcam is selected as the active video input device in your application's settings.
 - Restart your computer.
- **Poor Video Quality:**
 - Ensure adequate lighting in your environment; use the built-in light ring if necessary.
 - Clean the webcam lens with a soft, dry cloth.
 - Confirm your application settings are configured for 1440p resolution if desired and your internet connection is stable if streaming.
- **Light Ring Not Working:**

- Ensure the webcam is connected to a powered USB port.
- Press the light control button multiple times to cycle through all brightness settings.
- If the issue persists, try connecting the webcam to a different USB port or computer.

8. SPECIFICATIONS

Model Number	BWA21HO008C
Video Resolution	Up to 1440p @ 30 fps
Still Image Resolution	5 Megapixel
Connectivity	USB
Special Features	Adjustable 3-level LED light ring, Low Light capability
Compatible Devices	Personal Computer
Color	Black
Dimensions (L x W x H)	16.2 x 10.5 x 5.9 cm (approximate parcel dimensions)
Weight	170 g (approximate parcel weight)







9. SAFETY INFORMATION

- Do not expose the device to water, rain, or excessive moisture.
- Do not attempt to disassemble, modify, or repair the device yourself. Refer all servicing to qualified personnel.
- Keep the device out of reach of children and pets.
- Use only with compatible devices and power sources as specified.
- Avoid placing the webcam in direct sunlight or near heat sources.

10. WARRANTY AND SUPPORT

For warranty information, technical support, or customer service inquiries regarding your Blackweb BWA21HO008C webcam, please refer to the documentation provided at the point of purchase or contact your retailer. You may also visit the official Blackweb support website for further assistance, if available.

Related Documents - BWA21HO008C

	<p>blackweb 32" Smart Soundbar BWC18SB001 Quick Start Guide and Manual</p> <p>Get started with your blackweb 32" Smart Soundbar (Model BWC18SB001). This guide provides setup instructions, connection options, maintenance tips, and troubleshooting for your audio device.</p>
	<p>Quick Start Guide - BWA18SB001 Soundbar</p> <p>Concise guide to setting up and connecting the BWA18SB001 soundbar, including package contents, button identification, connection options, and Bluetooth pairing. Features troubleshooting tips.</p>
	<p>Blackweb BWB15TA223 Portable Charger 8000 mAh Product Guide</p> <p>Official product guide for the Blackweb BWB15TA223 Portable Charger 8000 mAh, covering setup, usage, troubleshooting, safety, and warranty information.</p>
	<p>blackweb™ BWA16AA003 Hi-Fi Bluetooth Stereo with CD Player & FM Radio - Product Guide</p> <p>Comprehensive product guide for the blackweb™ BWA16AA003 Hi-Fi Bluetooth Stereo system, featuring CD playback, FM radio, Bluetooth connectivity, USB charging, and ambient lighting. Includes safety instructions, operation guides, and technical specifications.</p>
	<p>Blackweb 6-Device Universal Remote User Guide (BWB17AV002)</p> <p>Comprehensive user guide for the Blackweb BWB17AV002 6-Device Universal Remote Control, covering setup, programming, features, troubleshooting, FCC information, and warranty details.</p>
	<p>Blackweb BWB17AV002 6-Device Universal Remote Control User Guide</p> <p>Comprehensive user guide for the Blackweb BWB17AV002 6-Device Universal Remote Control, covering setup, programming, features, troubleshooting, and warranty information.</p>