

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Philips](#) /

› [Philips Splay LED Outdoor Wall Lamp with Motion Sensor \(Model 929003188801\) User Manual](#)

Philips 929003188801

Philips Splay LED Outdoor Wall Lamp with Motion Sensor

Model: 929003188801 | Brand: Philips

INTRODUCTION

The Philips Splay LED Outdoor Wall Lamp is designed to provide efficient and reliable outdoor illumination. This manual provides essential information for the safe installation, operation, and maintenance of your device. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

Observe the following safety precautions to prevent injury or damage:

- Installation should be performed by a qualified electrician in accordance with local wiring regulations.
- Disconnect power at the circuit breaker before installation, maintenance, or cleaning.
- Do not attempt to modify the product. Unauthorized modifications may void the warranty and create safety hazards.
- Ensure the product is securely mounted to a stable surface capable of supporting its weight.
- This product is rated IP44 for outdoor use, providing protection against splashing water. It is not suitable for submersion.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Philips Splay LED Outdoor Wall Lamp (1 unit)
- Mounting hardware (screws, wall plugs)
- Instruction Manual (this document)

SETUP AND INSTALLATION

Follow these steps for proper installation:

- Step 1: Choose Location:** Select a suitable outdoor location for the wall lamp. Ensure the mounting surface is flat and stable. Consider the motion sensor's detection range and desired illumination area.
- Step 2: Disconnect Power:** Before starting any electrical work, turn off the main power supply to the installation area at the circuit breaker.
- Step 3: Mount the Fixture:** Use the provided mounting hardware to securely attach the lamp's base to the wall. Mark drilling points, drill holes, insert wall plugs, and fasten the base firmly.



Image Description: The Philips Splay LED Outdoor Wall Lamp is shown mounted on a grey exterior wall, providing downward illumination. The lamp is positioned to the left of a white patio door, with two potted plants on a small wooden table beneath it.

- Step 4: Wire Connections:** Connect the electrical wires from your home's wiring to the lamp's terminals. Ensure correct polarity (Live, Neutral, Earth) according to local electrical codes. Refer to the wiring diagram provided with the product for specific connections.
- Step 5: Secure the Lamp:** Once wiring is complete, attach the lamp body to the mounted base, ensuring all connections are secure and weatherproof.
- Step 6: Restore Power:** Turn the main power supply back on at the circuit breaker.

OPERATING INSTRUCTIONS

The Philips Splay LED Outdoor Wall Lamp features an integrated motion sensor for automatic operation.

Motion Sensor Functionality

- The lamp will automatically turn on when motion is detected within its sensing range.
- It will remain illuminated for a set duration, typically adjustable via controls on the fixture (refer to product-specific labels for adjustment details).
- The lamp will turn off automatically when no motion is detected for the set duration.

Light Output

- The integrated LED provides 800 lumens of cool white light (4000K).
- The light is diffused for broad and even illumination, suitable for various outdoor settings.



Image Description: The Philips Splay LED Outdoor Wall Lamp is shown mounted on a vibrant green background, with a bright cool white light emanating from its LED panel, illustrating its illumination capability.

MAINTENANCE

To ensure optimal performance and longevity of your Philips Splay LED Outdoor Wall Lamp, follow these simple maintenance guidelines:

- **Cleaning:** Periodically clean the lamp's exterior with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electrical components.
- **LED Light Source:** The LED light source in this fixture is integrated and not user-replaceable. Do not attempt to open the lamp housing to access the LEDs.
- **Inspection:** Regularly inspect the lamp for any signs of damage, loose connections, or wear. If any issues are found, disconnect power and consult a qualified electrician.

TROUBLESHOOTING

If you encounter issues with your Philips Splay LED Outdoor Wall Lamp, refer to the following common problems and solutions:

Lamp Does Not Turn On

- **Check Power Supply:** Ensure the circuit breaker for the lamp is in the "ON" position.
- **Verify Wiring:** Confirm that all electrical connections are secure and correctly wired. If unsure, consult a qualified electrician.
- **Motion Sensor Obstruction:** Ensure the motion sensor lens is clean and not obstructed by dirt, debris, or objects.
- **Ambient Light:** The sensor may be designed not to activate in bright ambient light conditions. Test the lamp in darker conditions.

Lamp Stays On Continuously

- **Continuous Motion:** Check if there is constant motion within the sensor's detection range.
- **Sensor Settings:** If adjustable, the sensor sensitivity or duration setting might be set too high.
- **Wiring Issue:** Incorrect wiring can sometimes cause the lamp to remain on. Consult a qualified electrician.

Lamp Flickers

- **Loose Connections:** Disconnect power and check all electrical connections for tightness.
- **Power Fluctuations:** Ensure a stable power supply. If flickering persists across multiple fixtures, consult an electrician.
- **Damaged LED:** If flickering persists after checking connections and power, the integrated LED unit may be faulty. Contact customer support.

TECHNICAL SPECIFICATIONS




Image Description: A line drawing illustrates the key dimensions of the Philips Splay LED Outdoor Wall Lamp. The height is indicated as 240mm, the width as 80mm, and the depth from the wall as 160mm.

Feature	Specification
Brand	Philips
Model Number	929003188801
Light Source Type	Integrated LED
Wattage	12 Watts
Brightness	800 Lumens
Color Temperature	4000K (Cool White)
Special Feature	Motion Sensor, Energy Efficient
Protection Level	IP44 (Splash-proof)
Material	Aluminum

Feature	Specification
Product Dimensions	3.15" L x 6.3" W x 9.45" H (80mm x 160mm x 240mm)
Power Source	AC/DC
Voltage	12 Volts
Item Weight	1.7 pounds (770 Grams)

WARRANTY INFORMATION

This Philips Splay LED Outdoor Wall Lamp is covered by a **5-year warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For full terms and conditions, please refer to the official Philips warranty policy or contact customer support.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please visit the official Philips support website or contact their customer service department.

Official Philips Support: www.philips.com/support