

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PRITOM](#) /

› [PRITOM K10 Android Tablet User Manual](#)

PRITOM K10

PRITOM K10 Android Tablet User Manual

Model: K10

1. INTRODUCTION

Thank you for choosing the PRITOM K10 Android Tablet. This manual provides essential information for the safe and efficient use of your device. Please read it carefully before operating the tablet and retain it for future reference.



Image: The PRITOM K10 tablet displaying its key features including 2.4G WiFi, Kids Mode, Camera, Eye Comfort, Google Play, and SIM Card support.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- PRITOM K10 Android Tablet
- Protective Case with Integrated Stand
- Charging Cable
- Power Adapter
- User Manual (this document)

3. PRODUCT OVERVIEW

The PRITOM K10 tablet features a durable design with a silicone case and an integrated stand for comfortable viewing. Familiarize yourself with the device's physical components.

Match 9"-12.5" Devices



Image: A detailed diagram illustrating the location of the power button, volume controls, reset pinhole, headphone jack, SIM card slot, SD card slot, Type-C charging port, and speakers on the PRITOM K10 tablet.

Protecting while Portable (All-in-One Design)



Image: The PRITOM K10 tablet's durable silicone case and integrated stand, designed to protect the device and provide hands-free viewing.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the tablet. Connect the charging cable to the Type-C port on the tablet and the power adapter to a wall outlet. The battery indicator will show charging status. The tablet features a 6000mAh battery.



Video and Drama



Daily use



Reading



Image: Illustration of the tablet's 6000mAh battery capacity, indicating approximately 6 hours for video, 8 hours for daily use, and 12 hours for reading.

4.2 Power On/Off

- **To Power On:** Press and hold the Power button until the PRITOM logo appears.
- **To Power Off:** Press and hold the Power button, then select 'Power off' from the options on the screen.

4.3 Initial Configuration

Upon first power-on, follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Set up your Google account (optional, but recommended for Google Play access).

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

The PRITOM K10 runs on Android 13. Use touch gestures to navigate:

- **Tap:** Select an item.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out.

5.2 Parental Control (Pritom App)

The pre-installed Pritom App allows parents to manage tablet usage. Features include:

- Setting time limits for tablet use.
- Monitoring app usage.
- Filtering content and managing access to specific applications.



Image: A parent and child interacting with the PRITOM K10 tablet, highlighting the parental control features such as time limits, content filtering, password access, and kid-friendly content.

Kids-Benefit Apps & Google Play

With pre-installed Pritom Kids app, variety of kids-benefit software are available with one click to install. For example, games for different purposes(educational, entertaining, two-player), useful tools(camera, calculator, browser), video resources(shows, learning, Music, Stories). What's more, certified by GoogleMobile Service, numerous apps can be downloaded from Google Play.



Image: The PRITOM K10 tablet showcasing a variety of educational and entertaining apps, alongside a smartphone interface demonstrating the parental control management options.

5.3 Display Settings

The 10.1-inch HD IPS display offers a comfortable viewing experience. To protect your eyes, the tablet includes:

- **Eye Comfort Mode:** Softens screen light to reduce eye strain.
- **Read Mode:** Turns the screen to black and white, similar to an e-reader.

These modes can be activated with a single tap in the quick settings panel.

Stunning IPS Display

10.1
inch

IPS
Touchscreen

178°
Wide Angle



Image: The PRITOM K10 tablet showcasing its 10.1-inch IPS HD display, emphasizing wide viewing angles and clear picture quality.

PRITOM K10 kids tablet

Featured with 10 inch HD IPS display touchscreen, providing wonderful viewing experience for kids with large screen and clear picture. The Silicone Boundary and Anti-Scratch Shell protect the tablet nicely. With Read mode and Eye comfort mode, kids can adjust the light to protect eyes for long time using.



Image: A child using the PRITOM K10 tablet, illustrating the comfortable viewing experience provided by the 10-inch HD IPS display and eye comfort features.

5.4 Google Play and Storage

The PRITOM K10 is Google Mobile Service (GMS) certified, providing full access to the Google Play Store. You can download a wide variety of apps, games, movies, and books.

- The tablet comes with 64GB of internal storage.
- Storage can be expanded up to 512GB using a microSD card (not included) inserted into the SD card slot.

6. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive cleaners or solvents.
- **Software Updates:** Periodically check for system updates in the tablet's settings to ensure optimal performance and security.
- **Battery Care:** Avoid extreme temperatures. Do not allow the battery to fully discharge frequently.

7. TROUBLESHOOTING

Issue	Possible Solution
Tablet does not power on	Ensure the tablet is charged. Press and hold the Power button for 10-15 seconds. If unresponsive, use a pin to press the reset button.
Wi-Fi connection issues	Restart the tablet and your Wi-Fi router. Forget the network in settings and reconnect. Ensure you are within range of the Wi-Fi signal.
Slow performance	Close unused apps. Clear cache for frequently used apps. Consider uninstalling unnecessary apps or moving large files to an SD card. Restart the tablet.

Issue	Possible Solution
Apps not downloading/installing	Check internet connection. Ensure sufficient storage space. Clear Google Play Store cache and data.

8. SPECIFICATIONS

Feature	Detail
Model Name	K10
Operating System	Android 13
Screen Size	10.1 Inches
Screen Resolution	1280x800 Pixels (HD IPS)
Processor	1.6 GHz Quad-Core (Unisoc)
RAM	2 GB
Internal Storage	64 GB (Expandable up to 512GB via microSD)
Wireless Type	802.11n (2.4G WiFi)
Battery Capacity	6000mAh Lithium Polymer
Average Battery Life	6-8 Hours (usage dependent)
Item Weight	2.25 pounds
Product Dimensions	13.2 x 7.9 x 1.57 inches

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official PRITOM website. Keep your proof of purchase for warranty claims.