



Manuals.plus /

- › Sekonda /
- › Sekonda Smartwatch User Manual

Sekonda 1993

Sekonda Smartwatch User Manual

Model: 1993
Brand: Sekonda

1. INTRODUCTION

Thank you for choosing the Sekonda Smartwatch. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully to ensure optimal performance and longevity of your smartwatch.

The Sekonda Smartwatch is designed to enhance your daily life with features such as activity tracking, health monitoring, and smart notifications. Its durable design and long battery life make it a reliable companion for various activities.



Figure 1.1: Sekonda Smartwatch main display, showing current time, steps taken, calories burned, and body temperature.

2. SETUP

2.1 Initial Charging

Before first use, fully charge your Sekonda Smartwatch. Connect the magnetic charging cable to the charging contacts on the back of the watch and plug the USB end into a standard USB power adapter (not included).

- A full charge typically takes approximately 2 hours.
- The battery indicator on the watch screen will show charging progress.

2.2 App Installation

To unlock the full functionality of your smartwatch, download the 'HitFit Pro' application on your smartphone.

- **For Android users:** Search for 'HitFit Pro' on the Google Play Store.
- **For Apple iOS users:** Search for 'HitFit Pro' on the Apple App Store.
- Alternatively, scan the QR code provided in the watch's packaging to directly access the app download page.





Figure 2.1: 'HitFit Pro' app download screen, illustrating options for both Apple App Store and Google Play.

2.3 Device Pairing


Once the 'HitFit Pro' app is installed:

1. Open the 'HitFit Pro' app on your smartphone.
2. Ensure Bluetooth is enabled on your smartphone.
3. Follow the in-app instructions to search for and connect to your Sekonda Smartwatch.
4. Confirm the pairing request on both your smartphone and the smartwatch.

3. OPERATING INSTRUCTIONS

3.1 Basic Navigation

The smartwatch features an interactive round dial. Swipe across the screen or use the side buttons to navigate through menus and functions.



DOWNLOAD THE NEW SEKONDA SMART APP.

Add your devices to the Sekonda Smart Watch App for a whole new world of connected living.





Figure 3.1: Front and side views of the Sekonda Smartwatch, illustrating the interactive display and physical buttons for navigation.

3.2 Daily Activity Tracking

Your smartwatch automatically tracks your daily activity:

- **Steps:** Displays your total steps taken throughout the day.
- **Distance:** Calculates the distance covered based on your steps.
- **Calories:** Estimates active calories burned.
- **Sport Mode:** Select specific activities like walking, running, or climbing to record detailed data during your workout.

3.3 Health Monitoring

- **Heart Rate Monitor:** Continuously or on-demand monitors your heart rate.
- **Sleep Monitor:** Tracks your sleep patterns, differentiating between deep and light sleep.
- **Body Temperature:** Provides an estimate of your body temperature.

3.4 Smart Features

- **Music Control:** Control music playback (skip, pause, volume) on your connected smartphone.
- **Message & Notification Display:** View incoming messages, social media alerts, and email notifications

directly on your watch.

- **Weather Display:** Check local weather conditions and temperature.
- **Phone Finder:** Use your watch to locate your paired smartphone.
- **Remote Photo Capture:** Trigger your smartphone's camera remotely from your watch.

3.5 Customizing Watch Face

Personalize your smartwatch display:

- Press and hold the middle of the home screen to change the watch dial style.
- Over 100 additional dial designs are available for download through the 'HitFit Pro' app.
- You can also upload a personal photo to use as your watch face via the app.





Figure 3.2: Examples of customizable watch faces and a visual representation of the smartwatch's features.

3.6 Additional Features

- **Stopwatch & Countdown Timer:** For precise timing.
- **Alarms:** Set alarms via the app to vibrate on your watch.
- **Hydration Alerts:** Reminders to drink water.
- **Sedentary Alerts:** Reminders to move after periods of inactivity.
- **Do Not Disturb Mode:** Silence notifications during specific times.
- **Multiple Languages:** Supports 9 default languages.

4. MAINTENANCE

4.1 Cleaning

To keep your smartwatch in good condition:

- Wipe the screen and strap regularly with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive materials.
- Ensure the charging contacts are clean and dry before charging.

4.2 Water Resistance (IP68)

The Sekonda Smartwatch has an IP68 water resistance rating. This means it is protected against continuous immersion in water up to a depth of 1.5 meters for a maximum of 30 minutes. It is suitable for daily use, including hand washing and light rain exposure. However, it is not recommended for diving, hot showers, or prolonged submersion in water.

4.3 Battery Life & Charging

The smartwatch offers a battery life of up to 10 days depending on usage. Recharge the device using the provided magnetic USB charging cable when the battery is low.

FEATURES YOU EXPECT :



EXTRA FEATURES WE THINK YOU DESERVE :





Figure 4.1: The back of the smartwatch with charging contacts and sensors, and the watch worn on a wrist.

5. TROUBLESHOOTING

5.1 Connectivity Issues

- **Watch not connecting to app:** Ensure Bluetooth is on for both devices. Restart the app and the watch. Try unpairing and re-pairing the device.
- **Notifications not appearing:** Check app permissions on your smartphone to ensure 'HitFit Pro' has access to notifications. Verify that 'Do Not Disturb' mode is not active on the watch.

5.2 Display Issues

- **Screen unresponsive:** Restart the watch by pressing and holding the power button. Ensure the screen is clean and dry.
- **Watch face not changing:** Ensure the app is connected and try selecting a new watch face from within the 'HitFit Pro' app.

5.3 Battery Issues

- **Watch not charging:** Check that the magnetic charging cable is properly aligned with the contacts on the back of the watch. Try a different USB power source.
- **Short battery life:** Reduce screen brightness, limit background app refresh, and disable unnecessary notifications to extend battery life.

6. SPECIFICATIONS

Feature	Specification
Brand	Sekonda
Model Number	1993
Color	Khaki
Operating System Compatibility	Android 5.1 or above / iOS 10 or above
Screen Size	33 Millimeters (1.3 inches)
Connectivity Technology	USB (for charging), Bluetooth (for data sync)
Wireless Communication Standard	Bluetooth
Special Features	Heart Rate Monitor, Sleep Monitor, Activity Tracker, Email Notifications
Compatible Devices	Smartphone
Battery Composition	Lithium-ion
Memory Storage Capacity	128 MB
GPS	No GPS
Shape	Round
Water Resistance	IP68

7. WARRANTY AND SUPPORT

Information regarding specific warranty terms and customer support contact details for the Sekonda Smartwatch is not available in this manual. Please refer to the product packaging or the official Sekonda website for warranty information and support contacts.