

[Manuals.plus](#) /

› [Barbie](#) /

› Barbie It Takes Two Camping Tent Playset User Manual

Barbie HGC18

Barbie It Takes Two Camping Tent Playset User Manual

Brand: Barbie | Model: HGC18

INTRODUCTION

This user manual provides essential information for the assembly, operation, and care of your Barbie It Takes Two Camping Tent Playset. Designed for imaginative outdoor adventures, this playset includes two Barbie dolls, a spacious fabric tent, and numerous camping-themed accessories. Please read through this manual to ensure proper setup and enjoyment of the product.



Image: The complete Barbie It Takes Two Camping Tent Playset, showcasing the pink tent, two Barbie dolls (Malibu and Brooklyn), two folding chairs, a telescope, a fire pit, two animal figures (bunny and squirrel), and other small accessories like a blanket, lantern, and snacks.

WHAT'S IN THE BOX

The Barbie It Takes Two Camping Tent Playset includes the following components:

- Two Barbie dolls (Barbie 'Malibu' Roberts and Barbie 'Brooklyn' Roberts) wearing fashions and shoes.
- One fabric tent with an awning.
- One string of decorative lights.
- Two animal figures (one bunny, one squirrel).
- Two folding chairs.
- One blanket.
- One telescope.

- One firepit.
- Two hands of cards.
- Two water bottles.
- One flashlight.
- One snack bag.
- Two marshmallow roasters.
- Two pillows.



Image: The playset as packaged, illustrating the included dolls and various accessories.

SETUP AND ASSEMBLY

Follow these steps to assemble your Barbie It Takes Two Camping Tent Playset:

1. **Tent Assembly:** The fabric tent requires assembly similar to a real camping tent. Carefully insert the tent poles into the designated sleeves and secure them into the base. Ensure all poles are fully inserted and stable to prevent the tent from collapsing.
2. **Awning and Lights:** Attach the awning to the front of the tent as indicated in the packaging illustrations. Drape the string lights around the tent or awning for a decorative effect.
3. **Accessory Placement:** Arrange the blanket inside the tent to create a comfortable sleeping area. Set up the two folding chairs outside the tent. Place the firepit nearby.
4. **Telescope Setup:** Assemble the telescope by attaching it to its tripod stand. Position it for stargazing adventures.
5. **Small Accessories:** Distribute the remaining accessories such as water bottles, snacks, marshmallow roasters, cards, and pillows as desired to enhance the camping scene.



**extra-large fabric tent fits 4 dolls
& features a zipper closure, awning
& string lights!**

Image: An assembled pink camping tent with a blue awning, showing a doll chair, a bunny figure, a squirrel figure, a firepit, and a blue plaid blanket with cards and a rainbow pillow inside. Text on image indicates "extra-large fabric tent fits 4 dolls & features a zipper closure, awning & string lights!".

OPERATION AND PLAY FEATURES

The Barbie It Takes Two Camping Tent Playset offers various interactive features for engaging play:

- **Dolls:** Position Barbie 'Malibu' Roberts and Barbie 'Brooklyn' Roberts dolls in various poses to simulate camping activities such as sitting by the fire, looking through the telescope, or resting inside the tent.
- **Tent:** The tent is designed to accommodate up to four dolls, allowing for group camping scenarios. The front flap can be opened and closed.
- **Animal Interaction:** The playset includes two woodland animal figures with special features:
 - *Bunny:* Press down on the bunny's tail to make its ears wiggle.
 - *Squirrel:* Press down on the squirrel's tail to make it appear as if it's munching on an acorn.
- **Accessories:** Utilize the included accessories to create diverse play scenarios. The marshmallow roasters can be held by the dolls over the firepit, and the water bottles fit into the cup holders on the chairs.



Image: Barbie 'Brooklyn' Roberts doll is shown interacting with the telescope, while Barbie 'Malibu' Roberts doll holds a yellow lantern, demonstrating typical play scenarios.

**2 animal pals: press bunny's tail
to wiggle ears & press squirrel's tail
to see it munch the acorn!**



Image: A detailed view of the bunny and squirrel figures. The squirrel is shown with an acorn, and text indicates "press bunny's tail to wiggle ears & press squirrel's tail to see it munch the acorn!".



Image: Two young girls are shown actively playing with the Barbie camping tent playset, demonstrating how children might interact with the dolls and accessories in a home setting.

MAINTENANCE AND CARE

To ensure the longevity of your playset, follow these care instructions:

- **Cleaning:** Wipe down plastic components and fabric tent surfaces with a damp cloth and mild soap if necessary. Allow to air dry completely before storage.
- **Storage:** When not in use, disassemble the tent and store all components in a clean, dry place away from direct sunlight and extreme temperatures.
- **Dolls:** Dolls can be gently wiped clean. Avoid submerging dolls in water or using harsh chemicals.

TROUBLESHOOTING

If you encounter any issues with your playset, refer to the following common solutions:

- **Tent Assembly Difficulty:** If the tent poles do not secure well or the tent feels unstable, ensure that each pole is fully inserted into its corresponding slot in the base and fabric sleeves. Sometimes a firm push is required to click them into place.
- **Animal Features Not Working:** Ensure you are pressing the correct part of the animal (tail for bunny and squirrel) firmly. If the mechanism still does not respond, check for any obstructions.
- **Missing Pieces:** Refer to the "What's in the Box" section. If any components are missing upon initial unboxing, please contact customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	13.56 x 18.08 x 9.57 inches

Item Weight	1.18 pounds
ASIN	B09NLD2MNK
Item Model Number	HGC18
Manufacturer Recommended Age	3 years and up
Release Date	March 19, 2022
Manufacturer	Mattel

Safety Information

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 yrs.

Always supervise young children during play to prevent accidental ingestion of small parts. Ensure all components are used as intended and are not placed in the mouth.

Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact Mattel customer service. You can also visit the official Barbie website for additional resources.

Official Barbie Store: [Barbie Store on Amazon](#)

© 2024 Barbie / Mattel. All rights reserved.

Ask a Question About This Manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

