



[Manuals.plus](#) /

> [UBUYONE](#) /

> UBUYONE Wireless Presenter Remote GX15 Instruction Manual

## UBUYONE GX15

# UBUYONE Wireless Presenter Remote GX15 Instruction Manual

Model: GX15 | Brand: UBUYONE

## INTRODUCTION

Thank you for choosing the UBUYONE Wireless Presenter Remote GX15. This device is designed to enhance your presentations by providing convenient control over slides, a laser pointer, and additional functions. This manual will guide you through the setup, operation, and maintenance of your new presenter remote.



Image: The UBUYONE Wireless Presenter Remote GX15, shown with its USB receiver and an AAA battery.

## PRODUCT FEATURES

- **Plug & Play Multifunctionality:** Combines functions for hyperlink activation, window switching, page navigation (up/down), full-screen mode, and black screen display. No software installation required for most systems (Mac may require simple setup).
- **Extended Control Range:** Equipped with a microchip for a wireless control distance of up to 100 feet (30 meters) and a red laser light range of up to 200 meters (656 feet).
- **Broad Compatibility:** Supports Windows (XP/Vista/7/8/10), Mac OS, Linux, and Android operating systems. Compatible with presentation software such as PowerPoint, Keynote, Prezi, Word, Excel, ACD See, and iWork.
- **Bright Red Laser:** Features a clear red laser light for highlighting key points during presentations.
- **Volume Control:** Integrated volume up and down buttons for audio management during presentations.
- **Portable Design:** Slim and lightweight, designed for easy transport and comfortable handling.



Image: A detailed diagram showing the function of each button on the presenter remote, including page up/full screen, switch windows, page down/black screen, red laser, hyperlink/enter, volume up, volume down, and USB receiver.

# Compatibility

## Support system:

Mac OS, Windows, Linux



## Support software:

Powerpoint, WPS, Keynote, Prize, Excel, Google slide.




Image: The remote in use, highlighting its long control range of up to 100 feet for wireless functions and 328 feet for the laser pointer.

## SETUP INSTRUCTIONS

1. **Install Battery:** Open the battery compartment on the back of the remote. Insert one AAA battery, ensuring correct polarity.

## Volume control



## Small and portable



Image: The remote with its battery compartment open, illustrating the correct placement for the AAA battery.

2. **Retrieve USB Receiver:** The USB receiver is stored magnetically within the remote's base. Gently pull it out.
3. **Connect Receiver:** Plug the USB receiver into an available USB port on your computer or presentation device.
4. **Power On:** Slide the ON/OFF switch on the side of the remote to the 'ON' position. The device is typically plug-and-play and should be recognized automatically by your system.
5. **Mac OS Specific Setup:** For Mac OS, a simple setup might be required upon first connection. Follow any on-screen prompts.

Your browser does not support the video tag.

Video: A demonstration of the UBUYONE Wireless Presenter Remote GX15, highlighting its slim profile and the easy setup process by plugging in the USB dongle. This video is provided by a seller.

## OPERATING INSTRUCTIONS

Once connected, the UBUYONE Wireless Presenter Remote GX15 allows for intuitive control of your presentations.

- **Page Up/Down:** Use the **Up Arrow** and **Down Arrow** buttons to navigate through your presentation slides.

- **Red Laser Pointer:** Press and hold the **Red Dot** button to activate the laser pointer. Release to turn off.
- **Full Screen/Black Screen:** The **Square** button can toggle between full-screen mode and a black screen, depending on the presentation software.
- **Hyperlink/Enter:** The **Rectangle with Line** button functions as an Enter key or to activate hyperlinks within your presentation.
- **Switch Windows:** The **Two Rectangles** button allows you to switch between open applications or windows.
- **Volume Control:** Use the **Volume Up (+)** and **Volume Down (-)** buttons located on the side of the remote to adjust audio levels.

# Mini-receiver, Easy operation

A nice assistant for Presentations



Image: The side of the remote, indicating the volume control buttons.

Your browser does not support the video tag.

Video: A quick review of the UBUYONE Wireless Presenter Remote GX15, demonstrating its ease of use for presentations and highlighting the laser pointer and navigation buttons. This video is provided by a seller.

The UBUYONE Wireless Presenter Remote GX15 offers broad compatibility with various operating systems and presentation software, ensuring seamless integration into your workflow.

- **Operating Systems:** Windows XP, Windows Vista, Windows 7, Windows 8, Windows 10, Mac OS, Linux, Android.
- **Software:** PowerPoint, Keynote, Prezi, Word, Excel, ACD See, iWork.



The image shows a hand holding a white wireless presenter remote with a red laser pointer. The remote has several buttons, including a square, a right arrow, a left arrow, and a power button. The laser pointer is directed at a bar chart on a screen in a meeting room. The chart shows quarterly sales data from 2013 to 2019. The y-axis is labeled '\$ (Millions)' and ranges from 0 to 100. The x-axis shows quarters from Q1-2013 to Q1-2019. The bars are blue, with the Q1-2015 bar highlighted in pink. The values for each bar are: 54.5, 43.0, 35.3, 37.5, 57.8, 45.6, 37.4, 42.1, 74.6, 58.0, 49.8, 71.5.

## Long Range Control

Easily point out what you want to show even from a distance

 **<328FT**  
Light Range

 **<100FT**  
Wireless range

Image: Visual representation of the remote's compatibility with different operating systems and presentation applications.

## MAINTENANCE

- **Battery Replacement:** When the laser pointer or remote functions become weak or unresponsive, replace the AAA battery. Ensure the remote is switched off before replacing the battery.
- **Cleaning:** Wipe the remote with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the remote in a cool, dry place. Always store the USB receiver inside the remote to prevent loss.

## TROUBLESHOOTING

---

- **Remote Not Responding:**
  - a. Ensure the remote is switched 'ON'.
  - b. Check if the AAA battery is correctly installed and has sufficient power. Replace if necessary.
  - c. Verify the USB receiver is securely plugged into your computer's USB port.
  - d. Try plugging the USB receiver into a different USB port.
- **Laser Pointer Not Working:**
  - a. Ensure the remote is 'ON' and the battery is not depleted.
  - b. Confirm you are pressing the correct button for the laser.
- **Limited Range:**
  - a. Ensure there are no significant obstructions between the remote and the USB receiver.
  - b. Avoid using the remote near strong electromagnetic interference.

## SPECIFICATIONS

---

<b>Model Number</b>	GX15
<b>Product Dimensions</b>	5.16 x 0.75 x 0.51 inches
<b>Item Weight</b>	1.16 ounces
<b>Battery Type</b>	1 x AAA battery (included)
<b>Wireless Range</b>	Up to 100 feet (30 meters)
<b>Laser Range</b>	Up to 656 feet (200 meters)
<b>Color</b>	White



Image: Detailed dimensions of the presenter remote and its USB receiver.

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact UBUYONE customer service directly. Keep your purchase receipt for any warranty claims.

For further assistance, visit the official UBUYONE store: [UBUYONE Store on Amazon](#)