

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [V-MODA](#) /

› **V-MODA Rolling Stones x Crossfade 2 Wireless Over-Ear Headphone User Manual**

V-MODA RSTONES-Tattoo

V-MODA Crossfade 2 Wireless Headphones User Manual

Model: RSTONES-Tattoo

1. INTRODUCTION

The V-MODA Crossfade 2 Wireless headphones offer a versatile audio experience, combining both wireless Bluetooth connectivity and pure analog wired mode. Designed for audiophiles, gamers, musicians, and DJs, these headphones deliver high-resolution audio and exceptional comfort for extended listening sessions. The robust construction, featuring a combination of steel and vegan leather, ensures durability, while the foldable design enhances portability.



Image: V-MODA Crossfade 2 Wireless headphones in Tattoo -Black edition, showcasing the unique design.

2. WHAT'S IN THE BOX

Your V-MODA Crossfade 2 Wireless headphones package includes the following items:

- V-MODA Crossfade 2 Wireless Headphones
- Protective Exoskeleton Carry Case
- Kevlar-reinforced 1-button Speakeasy Audio Cable (for wired use)
- V-Micro USB Charging Cable
- User Manual (this document)



Image: The V-MODA Crossfade 2 Wireless headphones alongside their protective case, audio cable, and charging cable.

3. FEATURES

The V-MODA Crossfade 2 Wireless headphones are engineered with advanced features to provide a superior audio experience:

- **Dual-Diaphragm 50mm Drivers:** Deliver V-MODA's signature sound with deep, rich bass and clear highs.
- **Hi-Resolution CCAW Japanese Coils:** Certified by Japan Audio Society (JAS) for Hi-Res Audio when used in wired mode.
- **Bluetooth Connectivity:** Seamless wireless audio experience with a range of up to 33 feet (10 meters).
- **Multi-Point Connection:** Pair with two Bluetooth sources simultaneously (e.g., smartphone and laptop).
- **Pure Analog Wired Mode:** Zero latency audio for critical listening, gaming, and professional use.
- **Extended Battery Life:** Up to 14+ hours of continuous music playback, entertainment, and calls on a single charge.
- **Comfortable Ear Cushions:** Large memory foam ear cushions provide ergonomic comfort and natural noise isolation.
- **SteelFlex Headband:** Durable and flexible headband adapts to your head for a secure and comfortable fit.
- **CliqFold Hinge:** Patented hinge design allows the headphones to fold into a compact size for portability.
- **Built-in Microphone:** Hidden microphone optimized for phone calls and voice recognition.
- **Durable Construction:** Luxuriously crafted with steel and vegan leather, meeting V-MODA's strict durability standards.

4. SETUP

4.1 Charging the Headphones

Before initial use, fully charge your Crossfade 2 Wireless headphones.

1. Connect the V-Micro USB charging cable to the charging port on the left earcup of the headphones.
2. Connect the other end of the USB cable to a powered USB port (e.g., computer, wall adapter).
3. The LED indicator will show charging status. A full charge typically takes about 100 minutes.
4. Once fully charged, the LED indicator will change (refer to the LED indicator section in the full manual for specific light patterns).

4.2 Bluetooth Pairing

To connect your headphones wirelessly to a device:

1. Ensure the headphones are powered off.
2. Press and hold the power button on the right earcup until the LED indicator flashes blue rapidly, indicating pairing mode.
3. On your device (smartphone, laptop, etc.), enable Bluetooth and search for available devices.
4. Select "V-MODA Crossfade 2 Wireless" from the list of found devices.
5. Once connected, the LED indicator will turn solid blue.

For multi-point pairing, connect to the first device, then put the headphones back into pairing mode and connect to the second device. The headphones will remember both connections.

5. OPERATING

5.1 Power On/Off

- To power on: Press and hold the power button until the LED lights up.

- To power off: Press and hold the power button until the LED turns off.

5.2 Wired Mode

For pure analog audio with zero latency, use the included Speakeasy Audio Cable.

- Insert the smaller end of the audio cable into the 3.5mm jack on the right earcup.
- Connect the other end of the cable to your audio source (e.g., phone, computer, audio interface).
- In wired mode, the headphones operate passively, and the battery is not used.

5.3 Controls

The headphones feature intuitive controls on the right earcup:

- **Volume Up/Down:** Use the dedicated volume buttons.
- **Play/Pause:** Press the multi-function button once.
- **Next Track:** Double-press the multi-function button.
- **Previous Track:** Triple-press the multi-function button.
- **Answer/End Call:** Press the multi-function button once during an incoming call or active call.
- **Reject Call:** Press and hold the multi-function button during an incoming call.
- **Activate Voice Assistant:** Press and hold the multi-function button (e.g., Siri, Google Assistant).

Your browser does not support the video tag.

Video: A short promotional video showcasing the V-MODA Crossfade 2 Wireless Rolling Stones Edition headphones, highlighting their design and features.

6. MAINTENANCE

6.1 Cleaning

- Wipe the headphones with a soft, dry cloth.
- For ear cushions, gently wipe with a damp cloth and mild soap if necessary, then dry thoroughly.
- Do not use harsh chemicals or abrasive materials.

6.2 Storage

When not in use, store the headphones in their protective exoskeleton carry case to prevent damage.



Image: The V-MODA Crossfade 2 Wireless headphones folded compactly, ready to be stored in their durable exoskeleton case.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power/won't turn on	Low battery	Charge the headphones using the V-Micro USB cable.
Cannot pair via Bluetooth	Headphones not in pairing mode; device Bluetooth off; too far from device	Ensure headphones are in pairing mode (rapid blue flashing LED). Turn on Bluetooth on your device. Move headphones closer to the device (within 10 meters).

Problem	Possible Cause	Solution
No sound in wired mode	Cable not fully inserted; incorrect cable connection	Ensure the audio cable is securely plugged into both the headphone jack and the audio source.
Poor audio quality	Interference; low battery; source audio quality	Move away from sources of interference. Charge the headphones. Check the quality of your audio source.

8. SPECIFICATIONS

- **Model Name:** Crossfade 2
- **Connectivity Technology:** Wireless (Bluetooth), Wired (3.5mm Jack)
- **Audio Driver Type:** Dual-Diaphragm 50mm Dynamic Driver
- **Frequency Range:** 5 - 40,000 Hz
- **Battery Life:** Up to 14+ Hours (Wireless)
- **Charging Time:** Approximately 100 minutes
- **Bluetooth Range:** 10 Meters (33 feet)
- **Material:** Faux Leather, Memory Foam, Steel
- **Item Weight:** 1.63 pounds
- **Product Dimensions:** 7.2 x 6.1 x 4.4 inches
- **Noise Control:** Sound Isolation
- **Included Components:** Headphones, Protective Case, Cable


9. WARRANTY AND SUPPORT

V-MODA offers a 1-Year Premier Warranty for the Crossfade 2 Wireless headphones, covering manufacturing defects.

Additionally, V-MODA provides an "Immortal Life Replacement Program" where you can get a 50% discount on a replacement pair if your headphones are damaged outside of warranty.

For detailed warranty information, technical support, or to inquire about the Immortal Life Replacement Program, please visit the official V-MODA website or contact their customer support directly.

Visit the [V-MODA Store on Amazon](#) for more products and information.

<p>Crossfade Series</p> <p>WHAT'S THE SOUND DIFFERENCE BETWEEN THE CROSSFADE 12 & CROSSFADE M-80?</p> <p>The Crossfade 12 are an over-the-ear model with a more bassy, wider sound. The Crossfade M-80 are a more compact, over-the-ear model with a more balanced sound.</p> <p>WHAT'S THE SOUND DIFFERENCE BETWEEN THE CROSSFADE 2 & WIRELESS CROSSFADE WIRELESS, CROSSFADE M-100?</p> <p>The Crossfade 2 and the Wireless Crossfade M-100 are both over-the-ear models. The Crossfade 2 has a more bassy sound, while the Wireless Crossfade M-100 has a more balanced sound.</p> <p>My earbuds are too tight, what can I do?</p> <p>If your earbuds are too tight, you can try the following: 1. Check if the earbuds are properly seated in your ears. 2. If they are, try adjusting the earbuds to a more comfortable fit. 3. If they are still too tight, consider switching to a different model or size.</p> <p>I am only getting sound out of one ear on my headphones?</p> <p>What should I do? 1. Check if the earbuds are properly seated in your ears. 2. If they are, try adjusting the earbuds to a more comfortable fit. 3. If they are still only producing sound from one ear, try switching to a different model or size. 4. If the problem persists, please contact our customer support.</p> <p>My 3.5mm Spade/Apple cable/phone/space button is not working, what should I do?</p> <p>If your 3.5mm Spade/Apple cable/phone/space button is not working, please contact our customer support.</p>	<p>V-MODA Crossfade Series: Troubleshooting and Sound Differences</p> <p>Find answers to common questions about V-MODA Crossfade headphones, including sound differences between models, headband adjustments, audio issues, and cable functionality. Learn about replaceable cushions.</p>
	<p>V-MODA S-80 On-Ear Bluetooth Headphones User Manual</p> <p>Comprehensive user manual for the V-MODA S-80 on-ear Bluetooth headphones, covering setup, features, troubleshooting, and support. Learn about pairing, sound customization, and more.</p>
	<p>V-MODA M-200 ANC User Manual: Active Noise Cancelling Headphones</p> <p>Comprehensive user manual for the V-MODA M-200 ANC Active Noise Cancelling Headphones, covering features, package contents, setup, operation, and troubleshooting. Learn how to use your V-MODA M-200 ANC headphones for an optimal audio experience.</p>
	<p>V-MODA M-200 ANC Headphones User Manual: Setup, Features, and Troubleshooting</p> <p>The official user manual for V-MODA M-200 ANC Active Noise Cancelling Headphones. Learn how to set up, use, and troubleshoot your headphones, including pairing, ANC controls, and battery charging.</p>
	<p>V-MODA HEXM-PR True Wireless Earbuds Quick Start Guide</p> <p>Quick start guide for V-MODA HEXM-PR True Wireless Earbuds, covering setup, pairing, and essential information. Learn how to get started with your new earbuds.</p>
	<p>V-MODA Product Safety and Important Notes</p> <p>Comprehensive safety guidelines, warnings, and important usage notes for V-MODA audio products, covering safe listening practices, maintenance, and environmental considerations.</p>