

Manuals.plus /

- › Gevril /
- › Gevril Men's Lenox Swiss Automatic Watch Instruction Manual

Gevril 49003L.1

Gevril Men's Lenox Swiss Automatic Watch Instruction Manual

Model: 49003L.1

INTRODUCTION

Congratulations on your purchase of the Gevril Men's Lenox Swiss Automatic Watch. This timepiece combines classic design with Swiss automatic multifunction movement, offering precision and elegance. This manual provides essential information for the proper setup, operation, and care of your watch to ensure its longevity and optimal performance.





Figure 1: Front view of the Gevri Men's Lenox Swiss Automatic Watch, showcasing its black dial, gold-tone case, and brown leather strap.

SETUP

Winding the Watch

Your Gevri Lenox watch is equipped with a Swiss automatic movement. It is powered by the natural motion of your wrist. If the watch has stopped or its power reserve is low, it can be manually wound.

1. Unscrew the crown (located at the 3 o'clock position) counter-clockwise until it pops out to position 1.
2. Gently turn the crown clockwise approximately 20-30 times. This will initiate the movement and build up a power reserve.
3. Push the crown back in and screw it clockwise to secure it, ensuring water resistance.

Setting Time, Day, Date, and Month



Figure 2: Side view illustrating the watch crown and pushers for adjustments.

1. Setting the Time:

- Unscrew the crown and pull it out to position 3 (farthest out).
- Turn the crown to set the hour and minute hands. Ensure to set the correct AM/PM by advancing the time past 12 o'clock to see if the date changes.
- Once the time is set, push the crown back to position 1 and screw it in.

2. Setting the Date: (Located at 6 o'clock)

- Unscrew the crown and pull it out to position 2 (middle position).

- Turn the crown clockwise to adjust the date.
- Push the crown back to position 1 and screw it in.

3. **Setting the Day:** (Located at 9 o'clock)

- Use the recessed pusher located on the left side of the watch case (around 8 o'clock position).
- Press the pusher repeatedly with a small, non-sharp tool (like a toothpick) until the correct day is displayed.

4. **Setting the Month:** (Located at 3 o'clock)

- Use the recessed pusher located on the right side of the watch case (around 2 o'clock position).
- Press the pusher repeatedly with a small, non-sharp tool until the correct month is displayed.

Important: Avoid setting the date, day, or month between 9:00 PM and 3:00 AM, as this is when the watch's internal mechanisms are engaged in changing the date, and manual adjustment can damage the movement.

OPERATING YOUR WATCH

Wearing the Watch

The Gevriil Lenox watch features a genuine Italian leather strap with a deployment clasp for secure and comfortable wear. Adjust the strap to fit snugly but comfortably on your wrist.



Figure 3: The GevriL Lenox watch comfortably worn on a wrist.

Water Resistance

This watch is water resistant to 50 meters (5 ATM). This rating means the watch is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. It is **not** suitable for swimming, showering, or diving. Always ensure the crown is fully screwed in to maintain water resistance.

MAINTENANCE

Cleaning

To clean your watch, wipe the case and crystal with a soft, dry cloth. For the leather strap, avoid excessive moisture and harsh chemicals. If the strap gets wet, allow it to air dry naturally.

Storage and Care

- Avoid exposing your watch to extreme temperatures (hot or cold), direct sunlight for prolonged periods, or strong magnetic fields.
- Store your watch in its original box or a watch winder when not in use to protect it from dust and scratches.
- Regular servicing by an authorized Gevril service center is recommended every 3-5 years to ensure optimal performance and longevity of the automatic movement.



Figure 4: The Gevri Lenox watch presented in its elegant box.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch stops or runs intermittently.	Insufficient power reserve.	Manually wind the watch by turning the crown clockwise 20-30 times. Wear the watch regularly to keep it wound.
Date/Day/Month does not change or changes at incorrect time.	Time set incorrectly (AM/PM). Date/Day/Month adjusted during restricted hours.	Reset the time, ensuring correct AM/PM. Avoid adjusting date/day/month between 9 PM and 3 AM.
Condensation under crystal.	Exposure to extreme temperature changes or compromised water resistance.	Immediately take the watch to an authorized service center. Do not attempt to dry it yourself.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact Gevril customer support or an authorized service center.

SPECIFICATIONS

Feature	Detail
Model Number	49003L.1
Movement	Swiss Automatic Multifunction
Case Material	316L Stainless Steel
Case Diameter	44mm
Crystal	Anti-reflective Sapphire Crystal
Water Resistance	50 Meters / 5 ATM
Strap Material	Genuine Italian Leather
Functions	Day, Date, Month, Luminous Hands and Markers
Exhibition Case Back	Yes



Figure 5: Rear view of the watch, highlighting the exhibition case back that reveals the automatic movement.

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video 1: A 26-second official product video showcasing the Gevril Men's Lenox Automatic Watch from various angles, highlighting its design and

features.

WARRANTY AND SUPPORT

Your Gevri Men's Lenox Swiss Automatic Watch is covered by a manufacturer's warranty against defects in materials and workmanship. For specific warranty terms, registration, or to obtain service, please refer to the warranty card included with your purchase or visit the official Gevri website.

For further assistance or inquiries, please contact Gevri customer support.

- Official Gevri Website: www.gevri.com
- Gevri Store on Amazon: [Visit the Gevri Store](#)

