



Manuals.plus /

› WOHOMO /

› WOHOMO 26.5-inch C-Shaped End Table (Black) Instruction Manual

## WOHOMO 26.5-inch C-Shaped End Table

# WOHOMO 26.5-inch C-Shaped End Table (Black) Instruction Manual

Model: 26.5-inch C-Shaped End Table | Brand: WOHOMO

## INTRODUCTION

---

Thank you for choosing the WOHOMO 26.5-inch C-Shaped End Table. This manual provides detailed instructions for assembly, safe operation, and maintenance of your new table. Please read this manual thoroughly before assembly and retain it for future reference.



Image: The WOHOMO 26.5-inch C-Shaped End Table in Black, showcasing its design and functionality.

## **SAFETY INFORMATION**

---

Please observe the following safety guidelines to ensure safe use and longevity of your product:

- Always assemble the table according to the provided instructions.
- Do not place heavy objects on the table that exceed the recommended weight limit of 10 pounds (4.5 kg).
- Keep the table away from direct heat sources, such as radiators or fireplaces.
- Avoid prolonged exposure to direct sunlight, which may cause material degradation or discoloration.
- Ensure all screws and fasteners are tightened securely before use and periodically check for looseness.
- Do not stand or sit on the table.
- Use on a flat, stable surface to prevent tipping.

## **PACKAGE CONTENTS**

---

Before assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop (Round)
- Base Frame (C-shaped metal frame with bottom panel)
- Assembly Hardware (Screws, Allen wrench)
- Instruction Manual

## **SPECIFICATIONS**

---

<b>Brand</b>	WOHOMO
<b>Model Name</b>	26.5-inch C-Shaped End Table
<b>Color</b>	Black
<b>Product Dimensions (D x W x H)</b>	17"D x 10"W x 25.6"H (43.2 cm D x 25.4 cm W x 65 cm H)
<b>Item Weight</b>	6.8 Pounds (3.08 kg)
<b>Maximum Weight Recommendation</b>	10 Pounds (4.5 kg)
<b>Frame Material</b>	Metal
<b>Top Material Type</b>	Engineered Wood
<b>Required Assembly</b>	Yes
<b>Recommended Number of People for Assembly</b>	1
<b>Tools Recommended For Assembly</b>	Screw Driver (not included)
<b>Includes All Assembly Tools</b>	No (Allen wrench typically included)



Image: Detailed dimensions of the WOHOMO C-Shaped End Table, showing height, width, and depth measurements.

## SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is straightforward and typically takes one person about 15 minutes. Please follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches. Verify all parts listed in the "Package Contents" section are present.
2. **Attach Tabletop to Frame:** Align the tabletop with the pre-drilled holes on the top section of the C-shaped metal frame. Insert the provided screws and tighten them using the Allen wrench. Do not overtighten.
3. **Secure Base:** Ensure the bottom panel of the C-shaped frame is stable. If there are any additional screws for securing the base to the vertical support, insert and tighten them now.
4. **Final Check:** Once assembled, gently shake the table to ensure it is stable. Tighten any loose screws if necessary.

*Note: A screwdriver may be required for some fasteners, though an Allen wrench is typically included for primary assembly.*

## USAGE INSTRUCTIONS

The WOHOMO C-Shaped End Table is designed for versatile use in various settings:

- **Slide Under Couch/Bed:** The C-shaped design allows the table to slide easily under most sofas, armchairs, or beds, bringing the tabletop closer to you for convenience.
- **Surface for Items:** Use the round tabletop to hold drinks, snacks, remote controls, laptops (within weight limits), books, or other small personal items.
- **Portable Design:** Its lightweight and stable structure makes it easy to move between rooms as needed.
- **Space-Saving:** Ideal for small spaces, providing functional surface area without occupying much floor space.



Image: The C-shaped end table positioned with its base sliding under a sofa, demonstrating its space-saving design.



Image: The C-shaped end table placed beside a bed, illustrating its use as a bedside table.

## MAINTENANCE

---

To keep your WOHOMO C-Shaped End Table in optimal condition:

- **Cleaning:** Wipe the tabletop and frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining, especially on the engineered wood tabletop.
- **Fasteners:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.
- **Protection:** Use coasters for drinks to protect the tabletop surface from moisture rings.

## TROUBLESHOOTING

---

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
Table is wobbly.	Screws are loose; uneven floor surface.	Ensure all assembly screws are securely tightened. Move the table to a flat, even surface.
Difficulty sliding under furniture.	Furniture clearance is too low; carpet interference.	Check the height of your couch/bed clearance against the table's base height (approximately 2.5 inches). Ensure no thick carpets or rugs obstruct the base.
Scratches on tabletop.	Abrasive objects placed directly on surface.	Use coasters or protective mats for items that may scratch the surface.

## **WARRANTY AND SUPPORT**

---

WOHOMO is committed to providing quality products. For specific warranty details, please refer to the purchase documentation or contact WOHOMO customer support directly. If you encounter any issues or have questions regarding your product, please reach out to our customer service team for assistance. You can visit the official WOHOMO store for more information: [WOHOMO Store on Amazon](#)