



Manuals.plus /

› FOPO /

› FOPO S12 12-inch Triple Portable Monitor Instruction Manual

## FOPO S12

# FOPO S12 12-inch Triple Portable Monitor Instruction Manual

Enhance your productivity with a multi-screen setup.

## 1. INTRODUCTION

---

The FOPO S12 12-inch Triple Portable Monitor is designed to expand your laptop's display capabilities, offering two additional 12-inch Full HD 1080P IPS screens. This device aims to significantly improve multitasking efficiency and provide a versatile display solution for various devices and scenarios.

## 2. WHAT'S IN THE BOX

---

- FOPO S12 Triple Portable Monitor (1 unit)
- Power Adapter (1 unit)
- Type-C to Type-C Cables (Video & Power) (2 units)
- HDMI Cables (Video Only) (2 units)
- USB-C to USB-A Cables (Power Only) (2 units)
- Cleaning Cloth (1 unit)
- Screen Protectors (2 units)
- Hook-and-Loop Fastener (1 unit)



Image: All accessories included with the FOPO S12 Triple Portable Monitor.

### 3. PRODUCT OVERVIEW

The FOPO S12 features dual 12-inch IPS screens with Full HD 1920x1080P resolution, offering a 178° viewing angle and 74% NTSC color gamut. It includes a low blue light design to reduce eye fatigue. The monitor is designed with a scalable bracket for stability and adjustable viewing angles up to 235° rotation and 180° display mode for sharing.

## 12 Inch FOPO Triple Portable Monitor

12 inch

13.3"-14"  
laptop

Connect  
Type-C/HDMI

LCD  
IPS Panel

FHD  
Resolution

Plug  
and Play

Image: The FOPO S12 Triple Portable Monitor in use, extending a laptop's display.



Image: Rear view of the monitor showing the adjustable bracket for stability.

## 4. COMPATIBILITY

The FOPO S12 is compatible with most devices including PCs, laptops (13-16 inches), Type-C mobile phones, PS4, Nintendo Switch, and Xbox One. Supported operating systems include Mac, Windows, Linux, Chrome, and Android.

**Attention: This monitor is not compatible with M1 chip MacBooks or Microsoft Surface Pro models. However, it supports M1 Pro and M1 Max chip MacBooks.**

# Finish Connection Easily in 1 Minute

## Step 1 Measure the laptop size

To fit this monitor size, your laptop size **MUST** be within the below range, otherwise choose another model to order.



## Step 2 Choose the connection method

Laptop Port	Connect to monitor ports	Power Supply	Extra Adapter
Full-featured USB-C	Full-featured USB-C	Generally not required If the screen doesn't light up, power it up	No
HDMI	Mini HDMI Cable: mini HDMI to HDMI	<b>Must have power supply</b>	No
mini DP	Mini HDMI Cable: mini HDMI to HDMI Adapter: mini DP to HDMI		Yes
USB-A 3.0 or Above	Mini HDMI Cable: mini HDMI to HDMI Adapter: USB-A to HDMI		Yes
<b>Other ports</b>	Contact Fopo support for a solution before ordering		

\*For power supply, the power adapter should be 5V/2A or above.

Image: Guide for measuring laptop dimensions to ensure compatibility with the FOPO S12 monitor.

## 5. SETUP GUIDE

Follow these steps for initial setup:

- 1. Measure Laptop Size:** Ensure your laptop's screen size is between 13-16 inches, its height is over 8.27 inches, and its thickness is less than 0.28 inches.
- 2. Unfold the Monitor:** Gently unfold the two side screens from the main unit. Extend the central frame to fit your laptop's width.
- 3. Mount to Laptop:** Carefully attach the FOPO S12 to the top of your laptop's display panel. Ensure the clips securely hold the monitor without excessive force.
- 4. Release the Stand:** Extend the integrated stand on the back of the FOPO S12 to support its weight and prevent strain on your laptop's hinges. Adjust the stand length for optimal stability.
- 5. Connect Cables:** Connect the appropriate cables from the FOPO S12 to your laptop. Use Type-C to Type-C cables for video and power if your laptop supports it. For HDMI connections, separate USB-C to USB-A cables are needed for power.

Video: Demonstrates the setup process for the FOPO 12-inch Triple Portable Monitor.

## 6. OPERATING INSTRUCTIONS

### 6.1 Display Modes

The FOPO S12 supports various display modes, including duplication (mirror) and extension. These modes can be configured through your operating system's display settings.

- **Extension Mode:** Extends your desktop across all three screens, allowing for increased workspace.
- **Duplication Mode:** Mirrors your main laptop display onto the external monitors.

## 6.2 On-Screen Display (OSD) Settings

Each monitor has its own OSD menu for adjusting settings such as brightness, contrast, audio volume, and color temperature. Access the OSD menu by pressing the designated menu button on the monitor.

Video: Instructions on how to use the display functions and OSD settings of the FOPO Triple Monitors.

## 7. MOUNTING AND UNMOUNTING

---

The FOPO S12 is designed for easy attachment and detachment. The scalable bracket ensures a secure fit for various laptop sizes.

1. **Mounting:** Extend the frame to match your laptop's width, then carefully place the monitor onto the top edge of your laptop screen. Ensure the clips are firmly attached. Deploy the kickstand for support.
2. **Unmounting:** Before removing the Tri-screen, close your laptop to prevent damage. Extend the frame, then gently lift the monitor off your laptop. Fold the screens inward for compact storage.

Video: Provides tips for properly mounting FOPO monitors to a laptop.

## 8. POWER AND CHARGING

---

The FOPO S12 requires power for operation. It can draw power directly from your laptop via USB-C if your laptop supports power delivery. Alternatively, use the provided power adapter.

If your laptop's charging port is USB-C and the charging adapter's power is between 45W and 68W, you can connect the charging adapter to the monitor's Power Supply Port. The monitor will then transfer power to your laptop via a USB-C to USB-C cable, allowing you to charge your laptop while using the monitor.

Video: Demonstrates how to recharge the laptop battery while using the FOPO monitor.

## 9. SPECIFICATIONS

---

Feature	Specification
Standing Screen Display Size	12 Inches
Screen Resolution	1920x1080 (FHD 1080p)
Panel Type	IPS
Aspect Ratio	16:9
Screen Surface Description	Glossy
Brightness	300 cd/m <sup>2</sup>
Item Weight	5.4 pounds
Product Dimensions (LxWxH)	11.02 x 15.35 x 3.58 inches
Color	Black
Connectivity	USB-C, Mini HDMI

## 10. TROUBLESHOOTING

---

If you encounter issues, please refer to the following common solutions:

- **No Display:** Ensure all cables are securely connected. Verify your laptop's ports support video output. If using HDMI, ensure the USB-C to USB-A cables are connected for power.
- **Display Settings:** Check your operating system's display settings to ensure the monitors are detected and configured for extension or duplication as desired.
- **Power Issues:** Confirm the power adapter is correctly connected and providing sufficient power. If the screen doesn't light up, try connecting the power adapter directly to the monitor.
- **Color/Brightness Issues:** Access the OSD menu on each monitor to adjust brightness, contrast, and color temperature settings.
- **Compatibility Check:** Re-verify your laptop's specifications against the compatibility requirements, especially for M1/M2 chips and Surface Pro models.

Video: Important considerations and tips for using FOPO monitors.

## 11. WARRANTY AND SUPPORT

---

For detailed instructions, troubleshooting, or warranty information, please contact FOPO customer support:

- **Email:** [fopo@afterservice.vip](mailto:fopo@afterservice.vip)
- **Call Center:** +1 833 637 2188 (EST: 09:00-17:00, Monday-Friday)
- **Web:** <https://fopo.afterservice.vip>

