SALAV X3A

SALAV Heavy Duty Commercial Full-Size Garment Steamer

Model X3A Instruction Manual

Introduction

Thank you for choosing the SALAV Heavy Duty Commercial Full-Size Garment Steamer, Model X3A. This steamer is designed for both commercial and home use, offering powerful steam to effectively remove wrinkles, refresh fabrics, and eliminate odors. With its large 3-liter water tank and 1800 watts of power, it provides over 90 minutes of continuous steam for efficient garment care. Please read this manual thoroughly before operating the appliance to ensure safe and optimal performance.



Image: The SALAV Heavy Duty Commercial Full-Size Garment Steamer, Model X3A, in Navy color, showcasing its full assembly.

Setup and Assembly

Follow these steps to assemble and prepare your SALAV Garment Steamer for first use:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in the packing list are present.
2. **Attach Support Bar:** Insert the telescopic aluminum support bar into the base unit. Secure it firmly.
3. **Install Hanger:** Attach the multifunctional hanger to the top of the support bar. Ensure it clicks into place securely. The hanger includes clips for various garments.
4. **Connect Steam Hose:** Connect the steam hose to the steam outlet on the base unit. Twist to lock it in position.
5. **Fill Water Tank:** Remove the 3-liter water tank from the base. Unscrew the cap and fill the tank with distilled water. **Do not use tap water** as it can lead to mineral buildup and damage the unit. Replace and tighten the cap. Insert the filled water tank back into the base unit.

6. **Position Steamer:** Place the steamer on a flat, stable surface. Ensure the power cord is easily accessible to an electrical outlet.




Image: Visual guide for initial setup, showing water tank filling, plugging in, and waiting for warm-up.

Operating Instructions

Operating your SALAV Garment Steamer is straightforward:

1. **Power On:** Plug the steamer into a standard 120V AC outlet. Press the foot pedal power control to turn the unit on. The indicator light will illuminate.
2. **Heat Up:** Allow approximately 45-50 seconds for the steamer to heat up and produce continuous steam.
3. **Hang Garment:** Hang the garment you wish to steam on the multifunctional hanger. Use the integrated clips for pants or skirts if needed.
4. **Steam Garment:** Hold the steam nozzle a few inches away from the fabric. Move the nozzle up and down over the wrinkles. For stubborn wrinkles, gently press the nozzle against the fabric. Always keep the hose extended upwards during use to prevent kinks and ensure proper steam flow.
5. **Using Attachments:** The included fabric brush and pants press attachment can be used to smooth wrinkles, sharpen creases, and remove lint or pet hair. Attach them to the steam nozzle as needed.
6. **Power Off:** When finished, press the foot pedal power control again to turn off the unit. Unplug the steamer from the outlet.



Image: Close-up of the foot pedal, highlighting its hands-free operation for power and steam control.



Image: The multifunctional hanger with integrated clips, designed to hold different types of clothing for steaming.

Image: The 2-in-1 brush creaser attachment, demonstrating its use for detailed garment finishing.

Official Product Video:

Your browser does not support the video tag.

Video: An official product video demonstrating the features and operation of the SALAV X3A Commercial Full-Size Garment Steamer.

Maintenance and Care

Proper maintenance ensures the longevity and efficiency of your steamer:

- **Empty Water Tank:** After each use, always empty any remaining water from the tank. This prevents stagnant water and potential mineral buildup.
- **Descaling:** To prevent mineral buildup, especially if using non-distilled water (though distilled is highly recommended), descale your steamer regularly. Mix a solution of 50% white vinegar and 50% water. Pour it into the water tank and run the steamer until half the solution is used. Turn off, unplug, and let it sit for 30 minutes. Then run the remaining solution through. Finish by running two full tanks of fresh distilled water to rinse.

- **Cleaning Exterior:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners.
- **Storage:** When not in use, store the steamer in a cool, dry place. The telescopic support bar can be collapsed, and the hose can be wrapped for compact storage. The unit features rolling wheels for easy movement.



Image: Illustration demonstrating the effect of descaling on the steamer's internal components, promoting longer steamer life and strong continuous steam.

Troubleshooting

If you encounter issues with your steamer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or very little steam.	• Water tank empty or improperly seated. • Mineral buildup in the heating element. • Steamer not fully heated.	• Refill water tank and ensure it is correctly seated. • Perform descaling procedure (see Maintenance section). • Allow 45-50 seconds for the unit to heat up after turning on.
Water dripping from the steam nozzle.	• Condensation in the hose. • Hose is kinked or held too low. • Mineral buildup.	• Ensure the steam hose is held upright and not kinked. • Allow the steamer to heat up fully before use. • Perform descaling procedure.
Steamer making a clanking noise.	• Low water level. • Mineral buildup.	• Refill the water tank. • Perform descaling procedure.
Power light is off.	• Unit not plugged in. • Power switch (foot pedal) not activated. • Power outage or circuit breaker tripped.	• Ensure the power cord is securely plugged into a working outlet. • Press the foot pedal to turn on the steamer. • Check your home's circuit breaker.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Brand: SALAV

Model Number: X3A

Product Dimensions (L x W x H): 14.5" x 11.42" x 70.5"

Item Weight: 12 pounds

Wattage: 1800 watts

Voltage: 120 volts

Heat Time: 45 seconds

Water Tank Capacity: 3 liters (101.5 oz)

Continuous Steam Time: Over 90 minutes

Included Components: Fabric Brush and Pants Press Attachment

UPC: 810074610407

Warranty Information

The SALAV Heavy Duty Commercial Full-Size Garment Steamer, Model X3A, comes with a **1 Year Limited Warranty**. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included with your product or visit the official SALAV website.

Customer Support

For further assistance, technical support, or to inquire about replacement parts, please contact SALAV customer service. Refer to the contact information provided in your product packaging or on the official SALAV website. When contacting support, please have your model number (X3A) and proof of purchase ready.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question