

NERF NER0226

Nerf Bulls-Eye Digital Target User Manual

Model: NER0226

1. INTRODUCTION

Welcome to the Nerf Bulls-Eye Digital Target user manual. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your new digital target. The Nerf Bulls-Eye Digital Target is designed to enhance your aiming skills with its interactive features, including 6 flip-back targets, a high-scoring bullseye, and an LCD screen for score tracking. It supports both solo and multiplayer gameplay with three distinct game modes.

2. SAFETY INFORMATION

- **Age Recommendation:** This product is suitable for ages 8 years and up. Adult supervision is recommended for younger users.
- **Battery Safety:** Use only the specified battery type (3 AAA batteries). Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity. Remove batteries if the product is not used for an extended period.
- **Target Use:** Use only official Nerf darts with this target. Do not aim at eyes or face.
- **Choking Hazard:** Keep small parts away from young children.

3. PACKAGE CONTENTS

Verify that all components are present in your package:

- One (1) Nerf Bulls-Eye Digital Target unit





Image: The complete Nerf Bulls-Eye Digital Target, featuring a blue base with an LCD screen, a central blue pole, and six orange and grey hexagonal flip-back targets with various point values.

4. SETUP

4.1. Battery Installation

The Nerf Bulls-Eye Digital Target requires 3 AAA batteries for operation. Batteries are included with the product.

1. Locate the battery compartment on the underside of the target base.

2. Using a Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

4.2. Assembly

No assembly is required for the Nerf Bulls-Eye Digital Target. It comes pre-assembled and ready for use after battery installation.




Image: The Nerf Bulls-Eye Digital Target highlighting its key features: a bullseye that lights up and makes sounds for 100 points, six swinging targets, single or multiplayer gameplay, three different game modes, and an LCD screen for score tracking.

5. OPERATING INSTRUCTIONS

5.1. Powering On/Off

Press the power button located on the front of the target base to turn the unit on. Press it again to turn it off.

5.2. Game Modes

The Bulls-Eye Digital Target features three interactive game modes to test your skills:

- **Point Counter:** Accumulate points by hitting the targets. Each target has a designated point value (5, 10, 15, 25, 50, 75). Hitting the top bullseye scores 100 points.
- **Stack 'Em:** This mode challenges players to hit targets in a specific sequence or to achieve a certain score within a time limit.
- **Accuracy Test:** Focus on precision as you attempt to hit specific targets or the bullseye under varying conditions.

The LCD screen on the base will display scores and game information, allowing you to focus on the competition. The target provides lights and sounds feedback upon hitting targets, especially the bullseye.





Image: A close-up view of the Nerf Bulls-Eye Digital Target's base, showing the LCD screen displaying scores and game information, along with the control buttons for selecting game modes and power.



Image: A dynamic shot of the Nerf Bulls-Eye Digital Target, illustrating the flip-back mechanism of the hexagonal targets when hit by a dart.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Nerf Bulls-Eye Digital Target, follow these maintenance guidelines:

- **Cleaning:** Wipe the target surface with a soft, dry cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** Store the target in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the target will not be used for an extended period to prevent leakage.

7. TROUBLESHOOTING

If you encounter issues with your Nerf Bulls-Eye Digital Target, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Target does not power on.	Dead or incorrectly installed batteries.	Check battery polarity. Replace with fresh AAA batteries.
Targets not registering hits.	Darts not hitting targets with enough force; sensor obstruction.	Ensure darts are fired with sufficient velocity. Check for any debris obstructing the target mechanisms.
LCD screen is blank or flickering.	Low battery power; loose battery connection.	Replace batteries. Ensure batteries are securely seated in the compartment.
Sound or lights not working.	Battery issue; internal malfunction.	Replace batteries. If problem persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	NER0226
Dimensions (L x W x H)	22.86 x 33.02 x 50.8 cm
Weight	531 g
Power Source	3 AAA batteries (included)
Material	Foam
Color	Orange/Blue
Operation Mode	Automatic

Feature	Detail
Manufacturer	Hasbro







9. WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official NERF website. If you require technical assistance or have questions not covered in this manual, please contact NERF customer support through their official channels.

For more information and product updates, visit the [NERF Store on Amazon](#).

© 2023 NERF. All rights reserved.

Related Documents - NER0226

	NERF Digital Target User Guide: Setup, Games, and Instructions Comprehensive user guide for the NERF Digital Target (model 11588). Learn how to set up, play, and master the different game modes like Point Counter, Speed Breaker, and Accuracy Blast. Includes battery information, safety warnings, and features.
	Nerf Strike 'N Score Digital Target Game - Instructions and How to Play Official instructions for the Nerf Strike 'N Score Digital Target Game by Wilder Toys Inc. Learn how to set up, play different game modes like Overtime, Red vs Blue, Perfect 100, and Tag Team, and battery information.
	Nerf Ultra One Blaster: Assembly, Loading, and Firing Instructions A comprehensive guide to assembling, loading, and operating the Nerf Ultra One Motorized Blaster, including important safety information and troubleshooting tips.
	Nerf Hyper MACH-100 Blaster: Operating and Safety Instructions Comprehensive guide for the Nerf Hyper MACH-100 blaster, detailing how to load, fire, clear jams, store the blaster, and important safety precautions. Includes battery information and product compatibility.
	Nerf DinoSquad Rex-Rampage Blaster Instructions Instructions for operating the Nerf DinoSquad Rex-Rampage blaster, including loading, firing, clearing jams, and battery information.
	Nerf Roblox MM2 Shark Seeker Blaster Instructions Step-by-step instructions for loading, firing, and storing the Nerf Roblox MM2 Shark Seeker blaster. Includes safety warnings and product information.

