

[Manuals.plus](#) /

› [Skullcandy](#) /

› Skullcandy Dime 2 Wireless Earbuds User Manual

Skullcandy Dime 2

Skullcandy Dime 2 Wireless Earbuds User Manual

Model: Dime 2 (S2DBW-P751)

1. SETUP

1.1 What's in the Box

- Skullcandy Dime 2 Wireless Earbuds
- Charging Case
- USB Charging Cable
- Ear Gels (S, M, L)



Image: Skullcandy Dime 2 Wireless Earbuds and Charging Case.

1.2 Charging Your Earbuds and Case

Before first use, fully charge your Dime 2 earbuds and charging case. Place the earbuds into the charging case. Connect the USB charging cable to the case and a power source. The LED indicator on the case will show charging status.

- Earbuds provide up to 3.5 hours of listening time.
- The charging case provides an additional 8.5 hours, totaling 12 hours of battery life.



Image: Battery life breakdown for earbuds and charging case.

1.3 Bluetooth Pairing

1. Remove both earbuds from the charging case. They will automatically enter pairing mode.
2. Open the Bluetooth settings on your device (smartphone, tablet, etc.).
3. Select "Dime 2" from the list of available devices.
4. Once connected, you will hear an audio prompt, and the earbud LEDs will stop flashing.

1.4 Secure Fit

For optimal sound quality and comfort, choose the ear gels that best fit your ears. Gently insert the earbuds and twist them slightly to ensure a snug and secure fit.



Image: Skullcandy Dime 2 earbuds with various ear tip options.

1.5 Tile Finding Technology

The Dime 2 earbuds feature built-in Tile technology to help you locate them if misplaced. Download the Tile app on your smartphone and follow the in-app instructions to activate and register your earbuds.

Dime 2



**BUILT-IN TILE™
FINDING TECHNOLOGY**



**12 HOURS
TOTAL BATTERY**



**SECURE NOISE
ISOLATING FIT**



Image: Skullcandy Dime 2 earbuds highlighting Tile finding technology.

2. OPERATING INSTRUCTIONS

2.1 Basic Controls

Each earbud features a multi-function button for controlling audio and calls.



Image: Detail of the earbud control button.

- **Power On/Off:** Earbuds power on automatically when removed from the case and power off when returned to the case.
- **Play/Pause:** Press the button on either earbud once.
- **Track Forward:** Press the button on the RIGHT earbud twice.
- **Track Back:** Press the button on the LEFT earbud twice.
- **Volume Up:** Press the button on the RIGHT earbud once and hold.
- **Volume Down:** Press the button on the LEFT earbud once and hold.
- **Answer/End Call:** Press the button on either earbud once.
- **Reject Call:** Press the button on either earbud once and hold.
- **Activate Voice Assistant:** Press the button on either earbud three times.

2.2 Single Earbud Use

Both earbuds are equipped with a microphone, allowing you to use either the left or right earbud independently for calls or listening to audio. Simply remove one earbud from the case and leave the other in the case or powered off.

3. MAINTENANCE

3.1 Cleaning

Regularly clean your earbuds and charging case to maintain performance. Use a soft, dry, lint-free cloth. For ear gels, remove them and clean with a mild soap solution, then rinse and dry thoroughly before reattaching.

3.2 Water Resistance

The Skullcandy Dime 2 earbuds are rated IPX4 sweat and water resistant. This means they are protected against splashing water from any direction. They are not designed for submersion in water.




Image: Earbud demonstrating sweat and water resistance.

3.3 Battery Care

To prolong battery life, avoid fully discharging the earbuds and case frequently. Store them in a cool, dry place when not in use.

4. TROUBLESHOOTING

4.1 Earbuds Not Charging

- Ensure the charging cable is securely connected to both the case and the power source.
- Verify that the charging contacts on the earbuds and inside the case are clean and free of debris.
- Check if the charging case itself has sufficient battery charge.

4.2 Pairing Issues

- Make sure Bluetooth is enabled on your device.
- Ensure the earbuds are removed from the charging case and are in pairing mode (LEDs flashing).
- Try forgetting "Dime 2" from your device's Bluetooth list and re-pairing.
- If issues persist, try resetting the earbuds (see section 4.5).

4.3 No Sound or Low Volume

- Check the volume level on both your connected device and the earbuds.
- Ensure the earbuds are properly paired and connected.
- Clean any debris from the earbud speakers and ear gels.

4.4 Tile Finding Not Working

- Ensure the Tile app is installed and your earbuds are registered.
- Check that Bluetooth is enabled on your phone and the earbuds are within range.
- Verify that the earbuds have battery charge.

4.5 Resetting Your Earbuds

If you experience persistent issues, a factory reset may resolve them:

1. Disconnect "Dime 2" from your device's Bluetooth settings (forget device).
2. Place both earbuds back into the charging case.
3. Remove both earbuds. While they are attempting to pair, press and hold the button on both earbuds for 6 seconds.
4. The earbuds will power off and then power back on, entering pairing mode.
5. Repeat the Bluetooth pairing process (section 1.3).

5. SPECIFICATIONS

Feature	Specification
Model Name	Dime 2

Model Number	S2DBW-P751
Connectivity Technology	Wireless (Bluetooth 5.2)
Battery Life	Up to 12 Hours Total (3.5 hours in buds + 8.5 hours from case)
Water Resistance Level	IPX4 (Sweat and Water Resistant)
Frequency Range	20 Hz - 20,000 Hz
Bluetooth Range	10 Meters
Item Weight	1.13 ounces (earbuds)
Included Components	USB Charging Cable, Ear Gels (S, M, L)

6. WARRANTY AND SUPPORT

6.1 Warranty Information

The Skullcandy Dime 2 Wireless Earbuds come with a 1-year US warranty. Please retain your proof of purchase for warranty claims.

6.2 Customer Support

For further assistance, troubleshooting, or warranty inquiries, please visit the official Skullcandy support website or contact their customer service.

Official Skullcandy Website: www.skullcandy.com/support

7. OFFICIAL PRODUCT VIDEOS

No official seller-created product videos were found in the provided data for embedding in this manual.