

## KEMEI KM-700H

# KEMEI Professional Hair Clippers KM-700H User Manual

Model: KM-700H

## INTRODUCTION

Thank you for choosing the KEMEI Professional Hair Clippers Model KM-700H. This device is designed for precise hair and beard trimming, offering a professional grooming experience. Please read this manual thoroughly before first use to ensure safe and optimal operation.

## SAFETY INFORMATION

For your safety and to prevent damage to the device, please observe the following precautions:

- Avoid direct contact with eyes during operation.
- Keep the device away from water and do not immerse it in liquids.
- Do not use on infants or children without adult supervision.
- Ensure the device is fully charged before use to maintain optimal performance.
- Do not attempt to disassemble or repair the device yourself. Contact customer service for assistance.

## PACKAGE CONTENTS

Your KEMEI KM-700H package should include the following items:

- KEMEI Professional Hair Clippers (KM-700H)
- 3 Guide Combs (1mm, 2mm, 3mm)
- USB Charging Cable
- Cleaning Brush
- Hair Comb



Image: KEMEI KM-700H Hair Clippers with 3 guide combs, USB charging cable, cleaning brush, and hair comb.

## PRODUCT OVERVIEW

The KEMEI KM-700H features a durable design and advanced technology for efficient grooming.

- **Unique Design:** Features a hanging cutter head, T-zero gapped blades for precise engraving and close cutting.
- **Sharp and Durable Blade:** Made of titanium steel ceramic for high cutting efficiency and safety.
- **Constant Speed Technology:** Equipped with a high-speed powerful rotary motor that prevents dragging or stalling, even with thick hair.
- **Cordless Operation:** Provides up to 180 minutes of use on a 2-hour charge.
- **Full Metal Body:** Ergonomic and durable construction.
- **LCD Display:** Indicates battery level and other operational information.

# PREMIUM DETAILS DISPLAY



Image: Detailed view of the KEMEI KM-700H Hair Clippers, highlighting its compact size (5.9 inches length, 1.5 inches blade width) and LCD display.

**CORDLESS POWERFUL HAIR CLIPPER**  
**No Hair Pulling**  
**Self Grinding Carbon Steel Cutter**

**Durable**      **Safe**  
**Save time**      **Low Noise**  
**6500RPM Powerful Motor**

Image: Internal view of the KEMEI KM-700H motor, emphasizing durability, safety, time-saving, and low noise operation (under 65dB) with a 6500RPM motor.



Image: Close-up view of the KEMEI KM-700H Hair Clippers blade, showing its sharp teeth for precise cutting.



Image: The KEMEI KM-700H Hair Clippers showcasing its full metal body construction.

## SETUP

1. **Initial Charge:** Before first use, fully charge the clippers. Connect the USB charging cable to the clipper and a suitable USB power source (e.g., computer, wall adapter). The LCD display will indicate charging status. A full charge takes approximately 2 hours.

**FAST CHARGING  
FOR LONG TIME USE**

**1200 mAh battery  
USB Charging For 2  
Hours Use 180 minutes**

**USB Charging**

**180 MIN  
Use Time**

**2 Hrs  
2HRS  
Charging**

Image: KEMEI KM-700H Hair Clippers connected to a USB charging cable, illustrating the fast charging capability for extended use (1200 mAh battery, 2 hours charge for 180 minutes use).

2. **Attach Guide Comb:** Select the desired guide comb (1 mm, 2mm, or 3mm) for your preferred hair length. Align the comb with the clipper blade and push it firmly until it clicks into place. Ensure it is securely attached before use.
3. **Inspect Blades:** Before each use, ensure the blades are clean and free from debris. Apply a small amount of lubricating oil if necessary (see Maintenance section).

## OPERATING INSTRUCTIONS

---

Follow these steps for effective and safe trimming:

1. **Power On:** Press the power button to turn on the clippers. The LCD display will illuminate.
2. **Trimming Hair:**
  - For hair cutting, start with a longer guide comb and gradually switch to shorter ones if desired.
  - Hold the clippers with the blade flat against the head or skin.
  - Move the clippers slowly against the direction of hair growth for an even cut.
3. **Trimming Beard/Body Hair:**
  - Use the appropriate guide comb for beard length. For detailing or close cutting, remove the guide comb.
  - Carefully trim beard, mustache, sideburns, or body hair. The T-blade design is suitable for precise lines and edging.

## PERFEFCT FOR PRO BARBERS & HOME USE



Image: Examples of the KEMEI KM-700H Hair Clippers being used for professional and home grooming, including hair, beard, and sideburn trimming.

4. **Power Off:** After use, press the power button to turn off the clippers.

### MAINTENANCE

Regular maintenance ensures the longevity and performance of your clippers.

#### 1. **Cleaning the Blades:**

- After each use, turn off the clippers and remove the guide comb.
- Use the provided cleaning brush to remove any loose hair from the blades.
- The blades are designed to be washable. You can rinse the blade head under running water. Ensure the clipper body is not submerged.

**Kemei**®

Image: The KEMEI KM-700H Hair Clippers blade head being rinsed under running water, demonstrating its waterproof design for easy cleaning.

## 2. Lubricating the Blades:

- After cleaning and drying the blades, apply a small drop of clipper oil (not included, but commonly available) to the teeth of the blades.
- Turn on the clippers for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and smooth operation.

3. **Storage:** Store the clippers in a dry place, away from direct sunlight and out of reach of children.

## TROUBLESHOOTING

If you encounter any issues with your KEMEI KM-700H clippers, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Clipper not turning on or low power.	Battery is low or depleted.	Charge the clippers fully using the provided USB cable. Ensure the charging indicator is active.
Blades pulling hair or not cutting effectively.	Blades are dull, dirty, or improperly aligned.	Clean the blades thoroughly. Apply lubricating oil. If the issue persists, inspect blade alignment. If blades appear damaged or loose, contact customer support.
Excessive noise or vibration.	Blades may be loose or require lubrication.	Ensure blades are securely attached. Lubricate the blades. If the problem continues, contact customer support.

## SPECIFICATIONS

- **Model Number:** KM-700H
- **Power Source:** Battery Powered (1 Lithium Ion battery required)
- **Battery Capacity:** 1200 mAh (approximate, derived from 180 mins use / 2 hrs charge)
- **Charging Time:** Approximately 2 hours
- **Operating Time:** Up to 180 minutes
- **Blade Material:** Titanium Steel Ceramic
- **Motor Speed:** 6500 RPM
- **Item Weight:** 162 Grams (5.71 ounces)
- **Package Dimensions:** 7.8 x 3.86 x 2.05 inches
- **Color:** Silver

## WARRANTY AND SUPPORT

KEMEI is committed to providing quality products. If you encounter any problems while using your KEMEI Professional Hair Clippers, please contact our customer service team for assistance. We are dedicated to resolving any issues you may experience as soon as possible.

For further information or support, please visit the official KEMEI website or contact your retailer.

