

[Manuals.plus](#) /

› [LankyBox](#) /

› LankyBox Giant Mystery Box Instruction Manual (Model 2011)

LankyBox 2011

LankyBox Giant Mystery Box Instruction Manual

Model: 2011

Brand: LankyBox

INTRODUCTION

The LankyBox Giant Mystery Box is a collectible set designed for fans of the popular YouTube channel. This set provides an unboxing experience with various items, including figures, a plush toy, a squishy, a fidget toy, and stickers. The packaging itself is designed for interactive play.

WHAT'S IN THE BOX

Each LankyBox Giant Mystery Box contains the following items:

- Boxy Case (wearable)
- 2 Mystery Figures
- One 6-inch Glow-in-The-Dark Plush
- Squishy Figure
- Pop-It Fidget Toy
- Canny with Pop-Out Sticky
- 3 Stickers



Image: All items from the LankyBox Giant Mystery Box, including figures, plush, squishy, pop-it, Canny, and stickers, displayed outside the Boxy Case.



Image: The back of the LankyBox Giant Mystery Box packaging, detailing the included items and age recommendation.

SETUP

To begin, carefully remove the outer packaging of the LankyBox Giant Mystery Box. The main yellow box

serves as the primary container for all the surprise items. Once the outer wrapping is removed, open the top flaps of the yellow Boxy Case to reveal the individually packaged contents inside. Remove all items from the case.



Image: The LankyBox Giant Mystery Box still in its original retail packaging, featuring the LankyBox logo and character art.

Your browser does not support the video tag.

Video: An official product video from TTPM demonstrating the unboxing process and showcasing the various items found inside the LankyBox Giant Mystery Box.

OPERATING THE CONTENTS

Wearable Boxy Case

The yellow Boxy Case is designed to be worn as a role-play helmet. Simply place the box over your head, aligning your face with the cutout for the character's face. This allows for imaginative play as the character Boxy.



Image: A child wearing the yellow Boxy Case on their head, demonstrating its use as a role-play helmet.

Glow-in-The-Dark Plush

The included plush toy features glow-in-the-dark properties. To activate the glow, expose the plush to a bright light source for a few minutes. The plush will then emit a soft glow in dark environments. The intensity and duration of the glow depend on the exposure to light.

**GLOWS IN THE
DARK!!!**



Image: The Ghosty plush toy glowing in a dark setting, highlighting its special feature.

Squishy Figure and Pop-It Fidget Toy

The squishy figure is designed for tactile sensory play. It can be squeezed and will slowly return to its original shape. The pop-it fidget toy provides a satisfying popping sensation when its bubbles are pressed, offering a calming and engaging activity.

Canny with Pop-Out Sticky

The Canny toy features a pop-out Sticky character. To activate, follow the instructions on the toy to release Sticky from Canny. This provides an element of surprise and interactive play.



Image: Two children interacting with the LankyBox Giant Mystery Box and its various contents, including figures, plush, and the Boxy Case.

MAINTENANCE AND CARE

- **Cleaning Figures and Fidget Toys:** Wipe with a damp cloth and mild soap if necessary. Do not submerge in water.
- **Cleaning Plush Toy:** Surface wash only. Use a damp cloth and mild soap. Air dry. Do not machine wash or tumble dry.
- **Storage:** Store all items in a cool, dry place away from direct sunlight to prevent fading or damage. The Boxy Case can be used for storage.

TROUBLESHOOTING

- **Missing Parts:** If any parts are missing upon opening, please contact customer support.
- **Glow-in-the-Dark Plush Not Glowing:** Ensure the plush has been exposed to sufficient light for activation.
- **Figures or Toys Damaged:** If items are damaged, refer to the warranty information for replacement options.

SPECIFICATIONS

Product Dimensions	8 x 10.5 x 11 inches
Item Weight	2 pounds
Item Model Number	2011
Manufacturer Recommended Age	6 - 15 years
Manufacturer	Bonkers Toys

SAFETY INFORMATION

This product contains small parts and is not suitable for children under 3 years of age due to potential choking hazards. Adult supervision is recommended during play. Keep packaging materials away from children. Do not aim pop-out sticky at eyes or face. Always supervise when children are playing and advise them not to play it near third parties.

WARRANTY AND SUPPORT

For warranty claims, product support, or inquiries regarding your LankyBox Giant Mystery Box, please contact the manufacturer, Bonkers Toys, directly. Retain your proof of purchase for any warranty-related requests. Contact information can typically be found on the product packaging or the manufacturer's official website.