Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bell+Howell 8205

Bell+Howell Wireless Under Cabinet LED Puck Lights with Remote (Model 8205) - Instruction Manual

Model: 8205

1. Introduction

Thank you for choosing the Bell+Howell Wireless Under Cabinet LED Puck Lights. This product provides versatile, battery-powered lighting solutions for various areas in your home, including kitchens, closets, and stairs. Featuring both touch and remote activation, adjustable brightness, and a timer function, these puck lights offer convenient illumination. Please read this manual thoroughly before installation and operation to ensure proper use and longevity of your product.

2. Safety Information

- Keep batteries out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Insert batteries with correct polarity (+/-).
- Remove batteries if the product is not used for an extended period.
- Do not expose the lights to excessive moisture or direct water.
- Do not stare directly into the LED lights when illuminated, as this may cause eye strain.
- This product is for indoor use only.

3. Package Contents

Verify that all items are present in your package:

- 3 x Bell+Howell LED Puck Lights
- 1 x Remote Control
- 9 x AAA Batteries (for puck lights)
- 1 x CR2025 Battery (for remote control, typically pre-installed)
- Adhesive Mounting Pads



Image: Packaging of the Bell+Howell LED Puck Lights, showing three lights and the remote control.

4. Product Features

- **Wireless & Battery Operated:** No wiring required, powered by AAA batteries for flexible placement.
- **Dual Activation:** Control lights via touch or the included remote control.
- **Adjustable Brightness:** Two levels of brightness to suit different lighting needs.
- **Timer Function:** Set lights to automatically turn off after 10, 30, or 60 minutes.
- **Easy Installation:** Mounts effortlessly with adhesive backing or screws (not included).
- **Versatile Application:** Ideal for under cabinets, closets, stairs, shelves, and more.
- **Warm Light:** Provides 3000K warm white illumination.



Image: Detailed view of a single puck light highlighting its components and features.

5. Setup and Installation

5.1. Battery Installation (Puck Lights)

1. Gently twist the back cover of each puck light counter-clockwise to open.
2. Insert 3 AAA batteries into each puck light, ensuring correct polarity (+/-).
3. Replace the back cover by aligning and twisting clockwise until secure.

5.2. Battery Installation (Remote Control)

The remote control typically comes with a CR2025 battery pre-installed. If replacement is needed, slide open the battery compartment on the back of the remote and insert a new CR2025 battery with the positive side facing up.

5.3. Mounting the Puck Lights

The puck lights can be mounted using the included adhesive pads:

1. Clean the desired mounting surface thoroughly to ensure it is free of dust, grease, and moisture.
2. Peel off one side of the protective film from an adhesive pad and firmly attach it to the back of a puck light.
3. Peel off the other side of the protective film from the adhesive pad.
4. Press the puck light firmly onto the cleaned mounting surface for at least 30 seconds.
5. Repeat for all puck lights.

For a more permanent installation, the puck lights can also be mounted using small screws (not included) through the designated holes in the back cover.




Image: Examples of puck light installation in a closet and on stairs.



Image: Puck lights installed under kitchen cabinets for illumination.

6. Operating Instructions

6.1. Touch Activation

- **To Turn On/Off:** Tap the center of the puck light once.
- **To Adjust Brightness:** Tap the center of the puck light again after turning it on to cycle between two brightness levels.

6.2. Remote Control Operation

The remote control allows you to operate the puck lights from a distance of up to 33 feet.



Image: The remote control for the puck lights, showing its various functions.

- **ON Button (●):** Press to turn all paired puck lights ON.
- **OFF Button (●):** Press to turn all paired puck lights OFF.
- **Brightness Adjustment (☀):** Press to cycle between two brightness levels (high and low).
- **Timer Button (10, 30, 60 Min):** Press to activate the auto-off timer. The lights will turn off after the selected duration.

Note: Ensure the remote control is pointed towards the puck lights for optimal signal reception.

7. Maintenance

7.1. Battery Replacement

When the lights dim significantly or stop responding, it's time to replace the batteries. Follow the battery installation steps in Section 5.1 for the puck lights and Section 5.2 for the remote control.

7.2. Cleaning

Wipe the surface of the puck lights with a soft, dry cloth. Do not use abrasive cleaners or immerse the lights in water.

8. Troubleshooting

Problem	Possible Cause	Solution
Lights do not turn on.	• Batteries are dead or incorrectly inserted. • Remote control battery is dead. • Remote control is out of range or obstructed.	• Replace puck light batteries, ensuring correct polarity. • Replace remote control battery. • Move closer to the lights and ensure a clear line of sight.
Lights are dim.	• Batteries are low. • Brightness setting is on low.	• Replace puck light batteries. • Adjust brightness using the remote or by tapping the light.
Remote control is unresponsive.	• Remote control battery is dead. • Remote control is out of range or obstructed.	• Replace remote control battery. • Move closer to the lights and ensure a clear line of sight.

9. Specifications

Model Number	8205
Brand	Bell+Howell
Light Type	LED Puck Light
Color Temperature	3000K (Warm Light)
Power Source	Battery Powered (3x AAA per puck light)
Remote Control Battery	1x CR2025 (included)
Material	Plastic (Chrome finish)
Product Dimensions	8L x 2W x 8H Centimetres (per puck light)
Number of Lights	3
Installation Type	Flush Mount (Adhesive or Screws)

10. Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Bell+Howell website. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09NQMZLRN

More documents and user manuals: **https://manuals.plus/**