Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fischer & Honsel 60761

Fischer & Honsel 60761 Hemp Rope Pendant Light User Manual

Model: 60761 | Brand: Fischer & Honsel

1. Important Safety Instructions

Please read these instructions carefully before installation and use. Keep this manual for future reference.

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with local wiring regulations. Ensure the main power supply is switched off at the circuit breaker before installation, maintenance, or bulb replacement.
- **Bulb Requirements:** Use only E27 base bulbs. Do not exceed the maximum wattage of 40W. Using a higher wattage bulb may cause overheating and damage to the fixture or create a fire hazard.
- **Indoor Use Only:** This product is designed for indoor use (IP20 rating). Do not expose to moisture or direct water contact.
- **Secure Mounting:** Ensure the ceiling structure can safely support the weight of the pendant light (approximately 1.45 kg).
- **Handling:** Handle the lamp with care. Avoid pulling on the rope or electrical cable during installation.

2. Product Overview

The Fischer & Honsel 60761 Pendant Light features a distinctive design with a hemp rope suspension and a metal lampshade. The lampshade has a matte black exterior and a white interior, designed to optimize light reflection.



Image 2.1: The Fischer & Honsel 60761 Hemp Rope Pendant Light, showcasing its design with a black metal shade and natural hemp rope.



Image 2.2: Close-up view of the hemp rope suspension with decorative knots and the matte black metal lampshade.

3. Installation

Follow these steps for safe and correct installation of your pendant light. It is recommended to have a qualified electrician perform the installation.

1. **Prepare for Installation:** Switch off the main power supply at the circuit breaker. Ensure the mounting surface is clean, dry, and structurally sound.
2. **Mount the Ceiling Canopy:** Attach the mounting bracket to the ceiling using appropriate screws and anchors (not included). Connect the electrical wires from the ceiling to the terminal block inside the ceiling canopy, ensuring correct polarity (Live, Neutral, Earth). Secure the ceiling canopy to the mounting bracket.
3. **Adjust Rope Length:** The hemp rope length can be adjusted by tying additional knots or untying existing ones to achieve the desired suspension height. Ensure the electrical cable inside the rope is not strained.
4. **Install the Bulb:** Carefully screw an E27 bulb (max. 40W) into the lamp holder. Do not overtighten.
5. **Final Check:** Once installation is complete, restore power at the circuit breaker and test the light.



Image 3.1: General installation steps for a ceiling light, including mounting the bracket and connecting wires.



Image 3.2: Product dimensions (40 cm diameter, 155 cm total height) and an example of how to shorten the rope using knots.

4. Operating Instructions

This pendant light operates with a standard wall switch connected to your home's electrical system.

- **Power On/Off:** Use the wall switch to turn the light fixture on or off.
- **Bulb Replacement:** Ensure the power is off before replacing the bulb. Allow the old bulb to cool down completely before unscrewing it. Screw in a new E27 bulb (max. 40W) gently until secure.

5. Maintenance

Regular maintenance ensures the longevity and appearance of your pendant light.

- **Cleaning:** Disconnect power before cleaning. Wipe the metal lampshade with a soft, dry cloth. For the hemp rope, use a dry brush or a slightly damp cloth to remove dust. Do not use abrasive cleaners or solvents.

- **Inspection:** Periodically check the electrical connections and the rope for any signs of wear or damage. If any damage is observed, discontinue use and consult a qualified electrician.

6. Troubleshooting

If you encounter issues with your pendant light, refer to the following common problems and solutions:

- **Light Does Not Turn On:**
  - Check if the power supply at the circuit breaker is on.
  - Ensure the wall switch is in the 'ON' position.
  - Verify the bulb is correctly screwed in and not faulty. Replace the bulb if necessary.
  - Check electrical connections at the ceiling canopy (consult a qualified electrician if unsure).
- **Light Flickers:**
  - Ensure the bulb is securely screwed into the socket.
  - Try a different bulb to rule out a faulty bulb.
  - Check for loose wiring connections (consult a qualified electrician).

7. Technical Specifications

Key specifications for the Fischer & Honsel 60761 Pendant Light:

Specification	Detail
Model Number	60761
Brand	Fischer & Honsel
Dimensions (L x W x H)	40 x 40 x 155 cm
Weight	1.45 kg
Material	Metal, Hemp Rope
Color	Matte Black (exterior), White (interior)
Bulb Base	E27
Max. Wattage	40W
Voltage	AC (Alternating Current)
IP Rating	IP20 (Indoor Use)
Components Included	1 pendant light fixture (bulb not included)

Datenblatt

living

FISCHER & HONSEL

4 003694 607612



Serienname: Rope

Artikel-Nr.: 60761 ASIN: **B09NRGTSZX**

Pendelleuchte, Rope | schwarz matt
/ innen weiß glänzend | Hanfseil
Metallschirm schwarz innen weiß
D: 40,00 cm | Ausladung Decke: 155,00 cm
1x E27 max. 40,0W ohne Leuchtmittel

Leuchtmittel: ohne Leuchtmittel
Schutzart: IP20
Schutzklasse: 2
Katalog Seite: 0104 Katalog FH 2021/2022
GTIN-Nummer: 4003694607612
Zolltarifnummer: 094051990

Fischer & Honsel GmbH | Graf-Gottfried-Straße 111 | D-59755 Arnsberg | P +49 (0) 2932 989 - 0 | F +49 (0) 2932 989 - 101
info@fischer-honsel.de | www.fischer-honsel.de

Image 7.1: Technical data sheet providing detailed specifications for the pendant light.

8. Warranty and Support

Fischer & Honsel products are manufactured with quality and care. For warranty information or technical support, please refer to the retailer where the product was purchased or visit the official Fischer & Honsel website. Please retain your proof of purchase for any warranty claims.

For further assistance, you may contact Fischer & Honsel GmbH directly:

- **Manufacturer:** Fischer & Honsel GmbH
- **Address:** Graf-Gottfried-Straßfe 111, D-59755 Arnsberg, Germany
- **Website:** www.fischer-honsel.de
- **Email:** info@fischer-honsel.de

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09NRGTSZX

More documents and user manuals: **https://manuals.plus/**