CUBOT J10

CUBOT J10 Smartphone User Manual

Model: J10

1. Product Overview

The CUBOT J10 is a compact and versatile 4-inch Android 11 smartphone designed for ease of use and portability. It features a Quad-Core processor, 32GB of internal storage (expandable up to 128GB), a 5MP rear camera, and a 2MP front camera. With dual SIM support and Face ID, it offers essential smartphone functionalities in a convenient size.



Figure 1.1: CUBOT J10 Smartphone, showcasing its compact design and sleek appearance.

2. What's in the Box

Upon unboxing your CUBOT J10 Smartphone, please verify that all the following items are included:

- 1 x CUBOT J10 Smartphone

- 1 x Charger
- 1 x USB Cable
- 1 x User Manual
- 1 x CE Card

3. Key Features

- **Compact Design:** 4-inch display for easy one-handed operation and portability.
- **Android 11:** Latest operating system for a smooth and comfortable user experience.
- **Quad-Core Processor:** Ensures smooth operation for daily tasks.
- **Expandable Storage:** 32GB internal storage, expandable up to 128GB with a TF card.
- **Dual SIM Support:** Convenient for managing two numbers or different network plans.
- **Camera System:** 5MP rear camera and 2MP front camera with AI beauty features.
- **Face ID:** High-tech facial recognition for secure unlocking.
- **Long-lasting Battery:** 2350 mAh battery to cover daily usage.
- **Connectivity:** Supports 2.4G WiFi, BLE 4.2, GPS, and Micro USB.




Figure 3.1: Overview of CUBOT J10's core features including processor, memory, and camera capabilities.

4. Physical Overview

The CUBOT J10 is designed for portability and ease of handling. Below are its physical dimensions and key components.

- **Dimensions:** 138 mm (Length) x 65 mm (Width) x 10.8 mm (Thickness)
- **Weight:** 143 g
- **Display:** 4-inch IPS Capacitive Touch Screen (480 x 854 resolution)
- **Cameras:** 2MP Front Camera, 5MP Rear Camera with 0.5A LED Flashlight



Figure 4.1: Detailed view of the CUBOT J10's dimensions and main hardware specifications.



Figure 4.2: The CUBOT J10's compact size makes it easy to carry in a pocket.

5. Setup

5.1. Inserting SIM Cards and TF Card

The CUBOT J10 supports dual Nano SIM cards and one TF (microSD) card for expandable storage. Ensure the phone is powered off before inserting or removing cards.

1. Locate the SIM/TF card slot on the side or back of the device.
2. Carefully open the slot cover.
3. Insert the Nano SIM cards into the designated slots with the gold contacts facing down.
4. If using, insert the TF card into its dedicated slot.
5. Ensure to remove the insulating film from the battery before first use.
6. Close the slot cover securely.



Figure 5.1: Guide for installing SIM cards and the battery, including the important step of removing the insulating film.

5.2. Initial Power On and Charging

1. Press and hold the Power button until the CUBOT logo appears.
2. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.
3. To charge the device, connect the provided USB cable to the phone's Micro USB port and the charger. Plug the charger into a power outlet.
4. A battery icon will appear on the screen indicating charging status.

6. Operating Instructions

6.1. Basic Navigation (Android 11)

The CUBOT J10 runs on Android 11, offering an intuitive user interface.

- **Home Screen:** Swipe left or right to access different home screens.

- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to view notifications and quick settings toggles (Wi-Fi, Bluetooth, etc.).
- **Recent Apps:** Swipe up from the bottom and hold, then release to see recently used applications.



Figure 6.1: The Android 11 interface on the CUBOT J10, showing typical home screen and notification panel views.

6.2. Using the Cameras

The CUBOT J10 is equipped with a 5MP rear camera and a 2MP front camera.

1. Open the "Camera" application from your home screen or app drawer.
2. Tap the shutter button to take a photo.
3. Switch between front and rear cameras using the camera switch icon.
4. Explore different modes like video, portrait, or AI beauty settings if available.

6.3. Face ID Setup and Usage

Face ID allows you to unlock your phone using facial recognition.

1. Go to **Settings** > **Security** > **Face Unlock**.
2. Follow the on-screen instructions to register your face. Ensure you are in a well-lit area.
3. Once registered, you can unlock your phone by simply looking at the front camera when the screen is active.



Figure 6.2: The Face ID feature in action, providing a convenient way to unlock the device.

7. Maintenance

7.1. Battery Care

- Avoid exposing the phone to extreme temperatures (hot or cold).
- Do not let the battery completely drain frequently. Charge it before it reaches 0%.
- Use only the provided charger and USB cable to prevent damage to the battery.

7.2. Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body of the phone.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner.
- Avoid using harsh chemicals, abrasive materials, or aerosol sprays.

7.3. Software Updates

Periodically check for software updates to ensure your device has the latest features and security patches.

- Go to **Settings** > **System** > **System update**.
- Follow the on-screen instructions to download and install any available updates.
- Ensure your phone has sufficient battery life and a stable internet connection before starting an update.

8. Troubleshooting

Problem	Possible Cause / Solution
Phone does not turn on.	Battery might be completely drained. Connect to charger and wait a few minutes before attempting to power on. Ensure insulating film is removed from battery.
Cannot connect to Wi-Fi.	Ensure Wi-Fi is enabled in Quick Settings or Settings. Restart your router. Forget the network and reconnect.
SIM card not detected.	Ensure the SIM card is correctly inserted and fully seated in the tray. Restart the phone.
Apps are running slow.	Close unnecessary background apps. Clear app cache. Consider freeing up storage space. Restart the phone.
Face ID not working.	Ensure your face is well-lit and clearly visible to the front camera. Re-register your face if issues persist.

9. Specifications

Feature	Detail
Brand	CUBOT
Model	J10
Color	Green
Dimensions (L x W x T)	138 mm x 65 mm x 10.8 mm
Weight	143 g
Processor	SC7731E (Quad-Core)
Operating System	Android 11
Storage (RAM + ROM)	1GB RAM + 32GB ROM
Expandable Storage	Supports TF card up to 128GB
SIM Card Support	Dual Nano SIM

Feature	Detail
Battery Capacity	2350 mAh
Display Size	4 inches
Display Type	IPS Capacitive Touch Screen
Display Resolution	480 x 854
Rear Camera	5 MP with 0.5A LED Flashlight
Front Camera	2 MP
Wi-Fi	2.4G WiFi
Bluetooth	BLE 4.2
GPS	Yes
Other Functions	Face ID
Network Support	GSM 850/900/1800/1900 MHz, WCDMA 900/2100 MHz (3G)
Connector Type	Micro USB

10. Warranty and Support

Information regarding specific warranty terms and conditions for the CUBOT J10 Smartphone is not provided in this document. Please refer to the warranty card included in your product packaging or visit the official CUBOT website for detailed warranty information and customer support contacts.
For technical assistance or further inquiries, please contact CUBOT customer service through their official channels.

© 2024 CUBOT. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question