

[Manuals.plus](#) /

› [ResponseBridge](#) /

› ResponseBridge S309 Portable Voice Amplifier User Manual

ResponseBridge S309

ResponseBridge S309 Portable Voice Amplifier User Manual

Model: S309

1. INTRODUCTION

Thank you for choosing the ResponseBridge S309 Portable Voice Amplifier. This device is designed to amplify your voice with clarity and power, making it ideal for various settings such as teaching, presentations, meetings, tour guiding, and outdoor activities. Its compact and lightweight design ensures portability and ease of use.



Figure 1: The ResponseBridge S309 Voice Amplifier being used in different environments like a classroom, meeting, yoga session, and for public speaking.

2. PACKAGE CONTENTS

Please check the box for the following items:

- 1x ResponseBridge S309 Voice Amplifier
- 1x Wired Headset Microphone
- 1x AUX Cable
- 1x Type-C Charging Cable
- 1x US Charger (Power Adapter)
- 1x Adjustable Belt/Strap
- 1x Portable Storage Bag
- 1x User Guide (this manual)



Warm tip:
The bag can hold all the accessories



Package includes:



Wired microphone



Type C charging cable



Adjustable waistband



Charger



AUX cable



Portable bag



User guide

Figure 2: Contents of the ResponseBridge S309 package.

3. PRODUCT OVERVIEW

The ResponseBridge S309 Voice Amplifier is a compact and powerful device designed for clear voice amplification. Familiarize yourself with its components:

Ergonomic design, more comfortable to wear



Figure 3: Front, top, and side views of the amplifier with labeled ports and controls.

- **Power Indicator:** Shows battery status.
- **Mode Switch (M):** Toggles between different input modes (e.g., USB, AUX).
- **Previous/Next Song Buttons:** For media playback.
- **Play/Pause/Mute Button:** Controls media playback and mutes the microphone.
- **Power On/Off Switch:** Turns the device on or off.
- **Volume Control:** Adjusts the output volume.
- **MIC Slot:** 3.5mm input for the wired headset microphone.
- **AUX Slot:** 3.5mm audio input for external devices.
- **USB Slot (U Disk):** For playing audio from a USB flash drive.
- **DC 5V Charging Slot:** Type-C port for charging the device.
- **Back Clip:** For attaching the amplifier to a belt or clothing.
- **Adjustable Headset Microphone:** Ergonomically designed for comfort and clear voice pickup.

4. SETUP

4.1 Charging the Amplifier

1. Connect the Type-C charging cable to the DC 5V charging slot on the amplifier.
2. Plug the other end of the cable into the provided US Charger and then into a power outlet.
3. The Power Indicator lights will show the charging status. A full charge typically takes 2-3 hours.

4.2 Connecting the Headset Microphone

1. Insert the 3.5mm jack of the wired headset microphone into the MIC slot on the amplifier.
2. Position the headset comfortably over your head, ensuring the microphone is close to your mouth (5-10mm is ideal) for optimal voice pickup. The microphone boom is adjustable and rotatable.



Figure 4: Proper adjustment of the headset microphone.

4.3 Wearing the Amplifier

The amplifier can be worn in several ways for convenience:

- **Belt Clip:** Use the back clip to attach the amplifier directly to your belt or waistband.
- **Adjustable Strap:** Attach the provided adjustable strap to the two hooks on the sides of the amplifier. Wear it over your shoulder or around your waist.

SUPPORTS AMPLIFYING

WHILE PLAYING AUDIO



Figure 5: Wearing options for the voice amplifier.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Slide the Power On/Off switch to the "ON" position to turn on the amplifier. Slide it to "OFF" to power down the device.

5.2 Voice Amplification

Once the headset microphone is connected and the amplifier is powered on, speak into the microphone. Your voice will be amplified through the speaker. Adjust the volume using the volume control knob.

5.3 Volume Control

Use the volume control knob on the top of the amplifier to increase or decrease the amplification level. Start with a lower volume and gradually increase it to avoid feedback.

5.4 Mute Function

Press the Play/Pause/Mute button to temporarily mute the microphone output. Press it again to unmute.

5.5 Playing Audio from USB/AUX

The amplifier supports playing audio from a USB flash drive or an external device via the AUX input. Insert your USB drive into the USB slot or connect an external device (e.g., smartphone, MP3 player) to the AUX slot using the provided AUX cable. Use the Mode switch to select the desired input source. The Previous/Next Song and Play/Pause buttons can be used to control media playback.



Figure 6: USB and AUX input ports for media playback.

5.6 Official Product Videos

Your browser does not support the video tag.

Video 1: Detailed demonstration of the ResponseBridge S309 Voice Amplifier, including its adjustable microphone and various features. This video provides a comprehensive overview of the product's functionality and setup.

Your browser does not support the video tag.

Video 2: Professional review of the ResponseBridge S309 Voice Amplifier, showcasing its sound quality and ease of use in a professional context.

Your browser does not support the video tag.

Video 3: Demonstration of the portable voice amplifier in various settings, including for teachers, meetings, and yoga, highlighting its versatility and clear sound output.

Your browser does not support the video tag.

Video 4: Overview of the ResponseBridge S309 Portable Microphone Headset with Speaker, focusing on its components and how they work together to provide amplified sound.

Your browser does not support the video tag.

Video 5: A short preview video from the ResponseBridge Store showcasing the S309 Professional Voice Amplifier, offering a quick visual introduction to the product.

6. MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the amplifier and accessories in the provided portable bag in a cool, dry place when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in constant use.

7. TROUBLESHOOTING

- **No Sound:**
 - Ensure the amplifier is powered on and fully charged.
 - Check if the microphone is securely plugged into the MIC slot.
 - Verify the volume is turned up.
 - Ensure the microphone is not muted.
- **Feedback/Whistling Sound:**
 - Reduce the volume.
 - Increase the distance between the microphone and the amplifier speaker.
 - Adjust the microphone position to avoid pointing directly at the speaker.
- **Audio Playback Issues:**
 - Ensure the correct input mode (USB/AUX) is selected using the Mode switch.
 - Check the connection of the USB drive or AUX cable.
 - Verify the audio files are in a supported format.

8. SPECIFICATIONS

Feature	Detail
Brand	ResponseBridge
Model Number	S309
Output Wattage	8 Watts

Battery Capacity	2000mAh Lithium Polymer
Charging Time	2-3 hours
Work Time	12-15 hours (at 50% volume)
Coverage Area	Up to 12,000 square feet (for 30-120 people)
Dimensions	4.3 x 3.3 x 1.2 inches
Item Weight	0.39 lbs (6.24 ounces)
Connectivity	AUX, USB (for flash drive), Wired Microphone
Material	Acrylonitrile Butadiene Styrene (ABS)
Recommended Uses	Teaching, classes, lectures, meetings, presentations, tour guide, training

9. WARRANTY AND SUPPORT

The ResponseBridge S309 Portable Voice Amplifier comes with a 12-month worry-free warranty. For any questions, technical assistance, or support, please contact our customer service. We aim to provide responsive and friendly customer service within 24 hours.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09NVYQF7R>

More documents and user manuals: <https://manuals.plus/>