Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

1PLUS S10

1PLUS Electric Scooter S10 User Manual

MODEL: S10

1. Setup

Your 1PLUS Electric Scooter S10 is designed for easy assembly and portability. Follow these steps to get started:

Unboxing and Initial Assembly:

Carefully remove all components from the packaging. The scooter comes with the main body folded for compact shipping.



Figure 1: The 1PLUS Electric Scooter S10 in its fully assembled, unfolded state.

To unfold the scooter, release the folding mechanism located on the stem. Carefully raise the handlebar stem until it locks securely into the upright position. Ensure all locking mechanisms are engaged before use.



Figure 2: The scooter features a one-step folding system for easy portability and storage.

First Use - How to Start:

1. Turn on the scooter by pressing the power button. Check the power indicator on the LED display.
2. Step on the deck with one foot, and slowly kick off with the other.
3. When the scooter starts to cruise (must be moving at 1.86 mph / 3 km/h), place both feet on the deck and press the accelerator to engage the motor.

Video 1: Official product video demonstrating the scooter's features, including folding and initial setup. (Source: MT-SPORT INC)

2. Operating

The 1PLUS Electric Scooter S10 offers intuitive controls and advanced features for a smooth riding experience.

Display and Controls:

The ultra-bright LED display provides real-time information. You can select different riding modes for additional security and adjust settings via the companion app.




Figure 3: The Smart LCD Display shows battery level, Bluetooth connection, speed, and selected speed mode.

Performance Features:

Equipped with an upgraded 600W brushless motor, the scooter can reach speeds up to 19 mph. The high-capacity battery provides a maximum travel range of up to 20 miles under specific conditions.



Figure 4: Detailed view of the 600W motor, highlighting its power and climbing capability.

For enhanced safety, the scooter features auto headlights and taillights, ensuring visibility during night rides. The double braking system includes a disc brake and eABS regenerative anti-lock braking.



Figure 5: The scooter's integrated lighting system for safe operation in low-light conditions.

Video 2: Official product video showcasing the 1PLUS High Performance Electric Scooter in action. (Source: MT-SPORT INC)

3. Maintenance

Proper maintenance ensures the longevity and optimal performance of your 1PLUS Electric Scooter S10.

Tires:

The scooter is equipped with 10-inch solid tires, which do not require inflation, repair, or regular maintenance. This design provides maximum comfort and convenience, even on rough surfaces or speed bumps.



Figure 6: The durable 10-inch solid tires require no inflation, offering a hassle-free riding experience.

Brakes:

The scooter features a double braking system with a disc brake and eABS regenerative anti-lock braking. It is important to periodically check and adjust the brakes for optimal stopping power and safety. Refer to the detailed instructions in the full manual for brake adjustment procedures.

4. Troubleshooting

This section addresses common issues you might encounter with your 1PLUS Electric Scooter S10.

Common Issues and Solutions:

- **Charging Port Issues:** If the charging port appears warped or charging is inconsistent, inspect for debris or damage. Contact customer support if the issue persists.

- **Loose Latch/Folding Mechanism:** If the folding latch feels loose, ensure it is properly engaged. Some users have reported needing to adjust or replace the latch for secure folding. Refer to the full manual or contact support for detailed adjustment steps.
- **Brake Adjustment:** If brakes feel too tight (almost instant stop) or too loose (takes too long to stop), they require adjustment. This is a common maintenance task. Adjust the brake cable tension as needed.
- **App Connectivity:** The companion app may require reconnection each time the scooter is powered on. Ensure Bluetooth is enabled on your device and the app is updated to the latest version.

5. Specifications

Feature	Detail
Brand	1PLUS
Model Name	S10
Motor Power	600W Peak
Max Speed	Up to 19 Mph
Max Range	Up to 20 Miles
Tire Type	10-inch Solid Tires
Weight Limit	220 Pounds
Frame Material	Aluminum
Braking System	Disc Braking & eABS Regenerative Anti-lock Braking
Charging Time	5 Hours
Product Dimensions	5"L x 20"W x 40"H

6. Warranty and Support

1PLUS is committed to providing high-quality, family-friendly, and safe products. Your Electric Scooter S10 comes with a comprehensive warranty.

Warranty Information:

The 1PLUS Electric Scooter S10 is covered by a 2-year manufacturer's limited warranty. Specific parts may have a 1-year or 180-day warranty period. Please refer to the detailed information provided in your product documentation for full terms and conditions.

Customer Support:

For any questions, technical assistance, or warranty claims, please visit the official 1PLUS Store or contact their customer service directly.

Visit the 1PLUS Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09NXNLGNB

More documents and user manuals: **https://manuals.plus/**