



[Manuals.plus](#) /

> [Karlxtom](#) /

> Karlxtom Countertop Dishwasher User Manual

Karlxtom TDQR03A

Karlxtom Countertop Dishwasher User Manual

Model: TDQR03A

1. INTRODUCTION

Thank you for choosing the Karlxtom Countertop Dishwasher. This compact and efficient appliance is designed to simplify your dishwashing routine, especially in small living spaces such as apartments, dorms, RVs, boats, campers, and cabins. It offers dual water supply options and multiple washing cycles to meet diverse cleaning needs while conserving water.



Image: The Karluxton Countertop Dishwasher, showcasing its compact design and interior capacity.

2. SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Ensure the dishwasher is placed on a stable, level surface.
- Do not operate the dishwasher if the power cord or plug is damaged.
- Keep children and pets away from the dishwasher during operation.
- Only use detergents specifically designed for dishwashers.
- Do not open the door during a wash cycle, especially when hot water is in use.
- Unplug the appliance before cleaning or performing any maintenance.
- Avoid placing sharp objects pointing upwards in the cutlery basket.

3. PRODUCT OVERVIEW

3.1 Components

The Karlxtom Countertop Dishwasher comes with the following components:

- 1 × Karlxtom Countertop Dishwasher
- 1 × Tableware Basket
- 1 × Storage Rack
- 1 × Cutlery Basket
- 1 × Inlet Hose (61 inches)
- 1 × Drain Hose (61 inches)
- 1 × Fruit Basket
- 1 × Measuring Cup
- 1 × Hose Collar
- 1 × User Guide

3.2 Key Features

- **Compact Design:** Measures 18.05" x 16.86" x 16.75" (H x W x D), holding 4 full place settings.
- **Dual Water Supply Mode:** Supports 5L built-in water tank mode or direct faucet connection.
- **6 Programs:** Normal, Rapid, Glass, Baby Care, Fruit, and Extra Dry.
- **Efficient Cleaning:** 14 water ports on upper and lower spray arms, heats water up to 167°F.
- **Extra Drying Function:** 60 minutes hot air drying and 72 hours automatic ventilation.
- **Easy to Operate:** LED touch screen display and transparent dual-layer glass door with built-in LED lamp.



COMPACT SIZE BUT LARGE CAPACITY

Meets daily needs for a family of 3-4

 4X	 4X	 4X	 4X	 4X	 7X	 7X	 7X
Dinner Plates (10")	Small Plates (8")	Serving Bowls	Cups	Glass	Spoons	Forks	Knives

> Up to 12-inches in diameter

Image: Illustration of the dishwasher's compact size and its capacity to hold dishes for a family of 3-4.

PTC HOT AIR DRYING AND STORAGE

Keep your dishes clean, prevent odors and dry for long periods

60 MINUTES
Hot air drying

72 HOURS
Ventilated storage



Image: Visual representation of the PTC hot air drying and ventilated storage functions, highlighting 60 minutes of hot air drying and 72 hours of ventilated storage.

5 WASHING CYCLES & Extra Drying Function

Meet your different dish washing needs



NORMAL
69 min



SPEED
29 min



GLASS
59 min



BABY CARE
89 min



FRUIT
19 min




Image: Overview of the five washing cycles (Normal, Speed, Glass, Baby Care, Fruit) and the extra drying function.

360° ROTATING POWERFUL WASHING

Enjoy powerful high-pressure spray on this dishwasher



14 WATER PORTS
on lower & upper spray arms

360° CLEANING COVERAGE
all-round flushing thoroughly

Image: Depiction of the 360-degree rotating powerful washing system, showing 14 water ports on the upper and lower spray arms for thorough cleaning.



FRUIT & VEGETABLE WASH

Soaking and thoroughly cleaning

BABY CARE MODE

167°F steam washing for the best care

Image: Close-up showing the fruit and vegetable wash basket with grapes and apples, and the baby care mode for bottles and pacifiers.

PORTABLE COUNTERTOP DISHWASHER

Easy to take it every where



Image: Diagram illustrating the dimensions of the portable countertop dishwasher: 16.75 inches (42.5 cm) width, 18.05 inches (45.8 cm) height, and 16.86 inches (42.8 cm) depth.



5L Built-In Water Tank

No hookups needed, features a 5L (1.3 gal) water tank to wash your dishes wherever & whenever



2 WATER SUPPLY MODES



Faucet Supply

Easy to install, features connect the inlet hose (included) to a faucet



A faucet adapter may be required (not included)

Image: Explanation of the two water supply modes: a 5L built-in water tank for portability and a faucet supply option using an inlet hose.

4. SETUP

4.1 Placement

Place the dishwasher on a flat, stable surface near a power outlet and a water source (if using faucet mode) or a drain.

4.2 Water Supply Modes

The dishwasher offers two convenient water supply options:

1. **Water Tank Mode:** Ideal for portability. Use the included measuring cup to fill the 5L built-in water tank. The water level indicator will signal when the correct level is reached.
2. **Faucet Mode:** For continuous water supply. Connect the included inlet hose directly to your kitchen faucet. A faucet adapter may be required (not included).

4.3 Drainage

Connect the drain hose to the dishwasher and direct the other end into a sink or a bucket for wastewater collection.

5. OPERATING INSTRUCTIONS

5.1 Loading Dishes

Load dishes into the dishwasher, ensuring they do not block the spray arms. Place larger items on the bottom rack and smaller items, cups, and cutlery in the upper basket and cutlery holder.

5.2 Detergent Requirements

Only use detergent specifically made for dishwashers. Pods, liquid, or powder detergents are all acceptable. For detergent tablets, it is recommended to use them with longer cycles to ensure full dissolution.

5.3 Washing Cycles

Select the appropriate washing cycle using the LED touch screen display:

Program	Execution	Time	Detergent	Temperature	Air Drying
Normal	Hot Wash - Cold Rinse - Cold Rinse - Hot Rinse	69 Min	0.28oz/8g	Wash 131°F, Rinse 154°F	60 Min
Rapid	Hot Wash - Cold Rinse - Hot Rinse	29 Min	0.28oz/8g	Wash 122°F, Rinse 144°F	60 Min
Glass	Hot Wash - Cold Rinse - Hot Rinse	59 Min	0.28oz/8g	Wash 131°F, Rinse 154°F	60 Min
Baby Care	Hot Wash - Hot Rinse - Cold Rinse - Hot Rinse	89 Min	0.42oz/12g	Wash 131°F, Rinse 131°F, Rinse 167°F	60 Min
Fruit	Cold Rinse - Cold Rinse	19 Min	None	N/A	N/A

5.4 Extra Drying Function

After a wash cycle (except Fruit mode), the additional Air-Dry Cycle starts automatically for 60 minutes of hot air drying. This mode can also be turned on separately and provides 72 hours of automatic ventilation to prevent odors and keep dishes clean.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your dishwasher.

- **Cleaning the Interior:** Periodically wipe down the interior with a damp cloth to remove any food residue.
- **Filter Cleaning:** Regularly check and clean the filter to prevent blockages and ensure efficient drainage.
- **Exterior Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners.
- **Long-Term Storage:** If not using the dishwasher for an extended period, drain all water, clean the interior, and leave the door slightly ajar to allow for air circulation and prevent odors.

7. TROUBLESHOOTING

If you encounter issues with your Karlxtom Countertop Dishwasher, refer to the following common solutions:

- **Water Stains Inside:** It is normal to find a small amount of water stains inside the dishwasher upon receiving it. This is due to factory testing to ensure proper functionality.
- **Dishwasher Not Starting:** Ensure the power cord is securely plugged in and the door is fully closed. Check if the correct water supply mode is selected and water is available.
- **Dishes Not Clean:** Verify that dishes are loaded correctly and not blocking spray arms. Ensure sufficient detergent is used and the filter is clean.
- **Water Leakage:** Check all hose connections (inlet and drain) for tightness. Ensure the dishwasher is on a level surface.
- **Unusual Noises:** Check for any foreign objects inside the dishwasher that might be interfering with the spray arms or pump.

For persistent issues, please contact Karlxtom customer service.

8. SPECIFICATIONS

Specification	Value
Model Name	TDQR03A
Item Weight	32.1 pounds (14.6 Kilograms)
Product Dimensions	16.73 x 16.85 x 18.03 inches
Voltage	220 Volts (AC)
Wattage	950 watts
Capacity	5 Liters
Number of Settings	4 Place Settings
Option Cycles	5
Noise Level	50.2 dB
Material	Plastic
Display Type	LED
Hose Length	61 Inches (Inlet & Drain)

9. WARRANTY AND SUPPORT

Karlxtom provides a **12-month warranty** for this product. Additionally, a **30-day free trial** is offered. If you are not satisfied within this period, please contact customer service.

For any inquiries, technical support, or warranty claims, please contact Karlxtom customer service. They offer **24 hours, 100% satisfied customer service**.

For the most up-to-date contact information, please refer to the product packaging or the official Karlxtom website.

