

[manuals.plus](#) /

› [T'nB](#) /

› [T'nB Feat 2 TWS Wireless Earbuds User Manual](#)

T'nB EBFEATWH2

T'nB Feat 2 TWS Wireless Earbuds User Manual

Model: EBFEATWH2

INTRODUCTION

Thank you for choosing the T'nB Feat 2 TWS Wireless Earbuds. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your earbuds. Please read it carefully to ensure optimal performance and longevity of your device.



Image: The T'nB Feat 2 TWS Wireless Earbuds shown with their compact charging case open, displaying both earbuds ready for use.

1. SETUP AND FIRST USE

1.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case. Ensure they are correctly seated.
2. Connect the charging case to a power source using a compatible USB cable.
3. The indicator lights on the case and/or earbuds will show charging status.
4. Once fully charged, disconnect the charging case from the power source.



Image: Both T'nB Feat 2 earbuds are securely placed within their open charging case, illustrating how they are stored and charged.

1.2 Pairing with a Bluetooth Device

The earbuds will automatically enter pairing mode when taken out of the charging case.

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case and remove both earbuds. They will automatically power on and attempt to pair with each other.
3. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
4. Search for available devices and select "T'nB Feat 2" (or similar name) from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds' indicator lights will change (e.g., stop flashing).

Note: If pairing fails, place the earbuds back into the case, close it, and then repeat the steps. For subsequent uses, the earbuds will automatically connect to the last paired device when removed from the case.

2. OPERATING INSTRUCTIONS

2.1 Touch Controls

The T'nB Feat 2 earbuds feature intuitive touch controls for various functions:

- **Play/Pause Music:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud (e.g., Siri, Google Assistant).



Image: A close-up view of the T'nB Feat 2 TWS Wireless Earbuds, highlighting their ergonomic design and touch-sensitive surface.

2.2 Wearing the Earbuds

For optimal sound quality and comfort, ensure the earbuds are correctly positioned in your ears. The ergonomic design is intended for a secure and comfortable fit during daily activities and exercise.

3. MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The earbuds are water-resistant. However, they are not designed for submersion. Avoid exposing them to excessive moisture, rain, or sweat for prolonged periods. Dry them thoroughly before placing them back in the charging case.

- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly.

4. TROUBLESHOOTING

Problem	Solution
Earbuds not pairing with device.	<ul style="list-style-type: none"> • Ensure earbuds are charged. • Turn off and on Bluetooth on your device. • Forget "T'nB Feat 2" from your device's Bluetooth list and re-pair. • Place earbuds back in the case, close, wait a few seconds, then remove and try again.
Only one earbud is working.	<ul style="list-style-type: none"> • Ensure both earbuds are charged. • Place both earbuds back in the charging case, close the lid, then open and remove them simultaneously to re-establish the stereo connection.
Low sound quality or no sound.	<ul style="list-style-type: none"> • Check the volume level on both your device and the earbuds. • Ensure earbuds are clean and free from debris. • Move closer to your paired device to avoid interference.
Earbuds not charging.	<ul style="list-style-type: none"> • Ensure the charging cable is securely connected to both the case and the power source. • Check if the charging contacts on the earbuds and inside the case are clean. • Try a different charging cable or power adapter.

5. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	T'nB
Model Number	EBFEATWH2
Connectivity Technology	Wireless (Bluetooth 5.0)
Ear Placement	In-Ear
Form Factor	In-Ear
Control Type	Touch Control
Material	Plastic
Water Resistance Level	Water-resistant
Special Features	Integrated Voice Assistant
Recommended Uses	Call, Exercise

Feature	Detail
Compatible Devices	Bluetooth compatible devices
Included Components	Wireless charging case
Noise Cancellation	None

6. WARRANTY INFORMATION

Specific warranty details are not provided in the product description. Please refer to the warranty card included with your product or visit the official T'nB website for detailed warranty terms and conditions. Typically, electronic products come with a limited manufacturer's warranty covering defects in materials and workmanship for a specified period from the date of purchase.

7. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your T'nB Feat 2 TWS Wireless Earbuds, please contact T'nB customer service. Contact information can usually be found on the product packaging, the official T'nB website, or through your retailer.

Website: www.tnb.com