

## Bluehive B09P2Y7XT1

# Bluehive 4-Port Charging Station User Manual

Model: B09P2Y7XT1

## INTRODUCTION

---

This user manual provides comprehensive instructions for the safe and efficient operation of your Bluehive 4-Port Charging Station. Please read this manual thoroughly before using the device and retain it for future reference.

## PRODUCT OVERVIEW

---

The Bluehive 4-Port Charging Station is designed to efficiently charge up to four electronic devices simultaneously. Its compact and portable design makes it suitable for various environments.

### Key Features:

- 4 USB charging ports for multiple devices.
- Total output of 6.8 Amps for efficient charging.
- Compact and portable design.
- Compatible with various USB-powered devices.

### Product Components:

- Bluehive 4-Port Charging Station unit
- Power adapter
- Device dividers (if applicable)



Image: The Bluehive 4-Port Charging Station shown with multiple smartphones and a tablet docked for charging, illustrating its capacity and design.

## SETUP

---

1. **Unpack the Charging Station:** Carefully remove all components from the packaging.
2. **Place the Station:** Choose a stable, flat surface near a power outlet. Ensure adequate ventilation around the unit.
3. **Connect to Power:** Plug the AC power cord into the charging station's power input port, then plug the other end into a standard 120V AC wall outlet.
4. **Insert Dividers (if applicable):** If your model includes removable dividers, insert them into the designated slots to create separate compartments for your devices.



Image: A close-up view of the Bluehive 4-Port Charging Station with various devices connected, highlighting the charging ports and the overall setup.

## OPERATING INSTRUCTIONS

- 1. Power On:** Once connected to a power outlet, the charging station is ready for use. Some models may have an indicator light to show power status.
- 2. Connect Devices:** Use your device's original USB charging cable or a certified equivalent. Plug one end into a USB port on the charging station and the other end into your device.
- 3. Charging Modes:** The charging station supports various charging modes depending on the connected device's requirements.
  - **10W Fast Charge Mode:** For compatible devices requiring higher wattage, such as certain Samsung Galaxy models (e.g., S20/S21 Ultra, Note 10/10+, S10/S10+/S9/S9+, Note 9/8, S7 edge/S6 edge plus, Note 5).
  - **7.5W Charge Mode:** Optimized for iPhone models (e.g., iPhone 11/11 Pro/11 Pro Max, iPhone XS/XS Max/XR, iPhone X, iPhone 8/8 Plus).
  - **5W Standard Charge Mode:** For any Qi-enabled devices or standard USB charging.
  - **Wireless Charge Mode:** For devices like AirPods/AirPods Pro, Galaxy Buds/Galaxy Buds+, Pixel Buds (requires compatible wireless charging pad, not part of this specific product but mentioned in image). *Note: This charging station primarily uses wired USB ports. If wireless charging is depicted, it refers to a separate compatible accessory.*
- 4. Monitor Charging:** Your device's screen or indicator light will show its charging status. The charging station will automatically detect and deliver the optimal current for each connected device up to its maximum output.
- 5. Remove Devices:** Once charging is complete, safely disconnect your devices.




Image: A diagram illustrating the various charging modes (10W, 7.5W, 5W) and examples of compatible devices for each mode, along with a note about wireless charging compatibility for certain earbuds.

## MAINTENANCE

- **Cleaning:** Disconnect the charging station from the power outlet before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use for extended periods, store the charging station in a cool, dry place away from

direct sunlight and extreme temperatures.

- **Cable Management:** Avoid bending or crimping charging cables excessively to prevent damage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging.	Power cable not securely connected. Faulty USB cable. Device not compatible or port issue.	Ensure the power cable is firmly plugged into the station and the wall outlet. Try a different USB cable. Test with another device or try a different port on the station.
Slow charging.	Using a non-optimal charging cable. Device requires higher wattage than port provides. Too many high-power devices connected simultaneously.	Use the original or a high-quality, certified USB cable. Ensure the device is connected to a port that supports its required wattage (if applicable). Disconnect some devices to allow more power to others.
Blue light flashing at night.	Indicator light behavior.	This may be normal operation for some indicator lights. If disruptive, consider placing the station in a less visible area or covering the light source.

## SPECIFICATIONS

- **Model:** B09P2Y7XT1
- **Brand:** Bluehive
- **Manufacturer:** Trileaf Distribution
- **Number of Ports:** 4 USB Ports
- **Total USB Ports:** 4
- **Hardware Interface:** USB
- **Power Source:** AC
- **Input Voltage:** 120 Volts
- **Wattage:** 10 watts
- **Amperage:** 6.8 Amps (Total Output)
- **Special Feature:** Portable
- **Mounting Type:** Tabletop Mount
- **Product Dimensions:** 18.3 x 6.2 x 16.1 cm; 460 g
- **Compatible Devices:** Laptops, USB A to USB Type C compatible phones, and other USB-powered devices.

## WARRANTY AND SUPPORT

For warranty information or technical support, please contact the manufacturer, Trileaf Distribution, or refer to

the product packaging for specific contact details. Keep your purchase receipt as proof of purchase for warranty claims.

**Manufacturer:** Trileaf Distribution