

Geryst Q52

Geryst Q52 Wireless Earbuds User Manual

Model: Q52

1. INTRODUCTION

Thank you for choosing the Geryst Q52 Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your earbuds to ensure optimal performance and longevity. Please read this manual carefully before use.

Package Contents

- Geryst Q52 Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Multiple Sizes of Eartips
- User Manual



Image: The Geryst Q52 wireless earbuds are shown inside their open charging case, illustrating the product's design and charging contacts.

2. SETUP AND PAIRING

2.1 Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged.

1. Place the earbuds into the charging case. Ensure they are correctly seated; magnetic contacts will hold them in place.
2. Connect the USB charging cable to the charging port on the case and plug the other end into a USB power adapter (not included) or a computer's USB port.
3. The digital display on the charging case will indicate the battery level. The earbuds will show a charging indicator (e.g., LED light) while charging.
4. Charging typically takes 1-2 hours for the earbuds and 2-3 hours for the case.

MULTIFUNCTION CHARGING CASE

The 1800mah large-capacity charging case has a digital display function, allowing you to easily understand the power usage when exercising outdoors.



Image: The multifunction charging case is displayed, highlighting its 1800mAh capacity, digital battery display, and magnetic earbud placement.

2.2 Initial Pairing

The earbuds are designed for easy, one-step pairing.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. Enable Bluetooth on your device (smartphone, tablet, laptop, etc.).
3. Search for available Bluetooth devices and select "Q52" from the list.
4. Once connected, you will hear a confirmation prompt, and the earbud indicator lights will turn off or flash slowly.

The earbuds will automatically reconnect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device and it is within range.

ADVANCED BLUETOOTH 5.1

Use the latest **Bluetooth 5.1** chip to ensure a faster and more stable connection.



Image: An illustration demonstrating the advanced Bluetooth 5.1 chip, auto-pairing feature, and a 20-meter connection distance for stable connectivity.

3. OPERATING THE EARBUDS

The Geryst Q52 earbuds feature intuitive touch controls on each earbud for managing audio playback, calls, and voice assistants.

3.1 Touch Controls

Action	Left Earbud (L)	Right Earbud (R)
Power On/Off	Press and hold for 3 seconds	Press and hold for 3 seconds
Play/Pause	Single tap	Single tap
Next Track	Double tap	Double tap
Previous Track	Triple tap	N/A
Volume Up	N/A	Press and hold for 2 seconds
Volume Down	Press and hold for 2 seconds	N/A

Action	Left Earbud (L)	Right Earbud (R)
Answer/End Call	Single tap	Single tap
Reject Call	Press and hold for 2 seconds	Press and hold for 2 seconds
Activate Voice Assistant (Siri/Google Assistant)	Triple tap	Triple tap



Image: A visual guide detailing the smart touch control functions for both left and right earbuds, including actions for music, calls, and voice assistant.

3.2 Wearing the Earbuds

The Q52 earbuds are designed with ergonomic ear hooks for a secure and comfortable fit, especially during physical activity.

1. Choose the eartips that best fit your ear canal for optimal sound quality and comfort.
2. Gently place the earbud into your ear, then adjust the ear hook over the top of your ear until it feels secure.
3. Ensure a snug fit to maximize noise cancellation and bass response.

DESIGNED FOR SPORTS

Lightweight and fitting silicone ear hooks design




Image: An illustration showing the ergonomic design of the earbuds with silicone ear hooks, emphasizing their lightweight and secure fit for sports activities.

4. MAINTENANCE

4.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove eartips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Do not use harsh chemicals or abrasive materials.
- Ensure charging contacts on both earbuds and case are clean and free of debris for proper charging.

4.2 Water Resistance

The Geryst Q52 earbuds are IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. They are also sweatproof, making them suitable for workouts and outdoor activities.

- Do not intentionally submerge the earbuds for extended periods or in depths greater than specified.
- Ensure the earbuds are completely dry before placing them back into the charging case to prevent damage to the charging contacts.
- The charging case is not waterproof.




Image: The earbuds are shown covered in water droplets, illustrating their IP7 waterproof and sweatproof capabilities, suitable for use during rain or intense exercise.

4.3 Storage

When not in use, store the earbuds in their charging case to protect them from dust, damage, and to keep them charged.

- Store in a cool, dry place, away from extreme temperatures.
- Avoid dropping or subjecting the earbuds and case to strong impacts.

5. TROUBLESHOOTING

If you encounter any issues with your Geryst Q52 earbuds, please refer to the following common solutions:

5.1 Earbuds Not Pairing or Connecting

- **Ensure Earbuds are Charged:** Low battery can prevent pairing.
- **Restart Bluetooth:** Turn off and then turn on Bluetooth on your device.
- **Forget Device:** Go to your device's Bluetooth settings, find "Q52", and select "Forget This Device" or "Unpair". Then, try pairing again from scratch.
- **Reset Earbuds:** Place both earbuds in the charging case, close the lid for 5 seconds, then open it again. This often resets the connection.

- **Distance:** Ensure the earbuds are within 10 meters (33 feet) of your device.

5.2 No Sound or Low Volume

- **Check Volume Levels:** Ensure the volume on both your device and the earbuds is turned up.
- **Re-pair Earbuds:** Disconnect and reconnect the earbuds to your device.
- **Clean Eartips:** Wax or debris can block sound. Clean the eartips and earbud nozzles.
- **Try Different Eartips:** An improper seal can lead to poor sound quality and low volume.

5.3 Earbuds Not Charging

- **Check Cable and Adapter:** Ensure the charging cable and power adapter are working correctly. Try a different cable or adapter.
- **Clean Charging Contacts:** Ensure the metal charging contacts on both the earbuds and inside the case are clean and free of debris.
- **Proper Placement:** Make sure the earbuds are correctly seated in the charging case.

6. SPECIFICATIONS

Model Name	Q52
Brand	Geryst
Connectivity Technology	Bluetooth 5.1, Wireless
Bluetooth Version	5.1
Bluetooth Range	Up to 20 meters (66 feet)
Earbud Battery Life	Up to 5.5 hours (single charge)
Charging Case Battery Life	Up to 48 hours (additional charges)
Water Resistance Rating	IP7 Waterproof, Sweatproof
Control Type	Touch Control
Material	Thermoplastic Elastomer (TPE)
Product Dimensions	1.97 x 1.57 x 1.18 inches
Item Weight	5.6 ounces
Special Features	Microphone Included, Noise Cancellation, Sweatproof

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your

purchase or contact Geryst customer service through the retailer where the product was purchased.
Please retain your proof of purchase for warranty claims.

© 2023 Geryst. All rights reserved.