

[manuals.plus](#) /

› [RASTAR](#) /

› [RASTAR 98500 1/18 Mercedes-AMG F1 Remote Control Car User Manual](#)

## RASTAR 98500


# RASTAR 98500 1/18 Mercedes-AMG F1 Remote Control Car User Manual

Model: 98500

## 1. INTRODUCTION

This manual provides instructions for the operation and maintenance of your RASTAR 98500 1/18 Mercedes-AMG F1 Remote Control Car. Please read this manual thoroughly before operating the product to ensure proper use and to prevent damage.

The RASTAR 98500 is an officially licensed 1:18 scale replica of the Mercedes-AMG F1 car, designed for remote-controlled operation. It features full functions including forward, reverse, stop, turn left, and turn right, operating at a low speed suitable for both indoor and outdoor use.



## 2. SAFETY INFORMATION

Observe the following safety precautions to prevent injury or damage to the product:

- This product is recommended for ages 6-12 years. Adult supervision is advised.
- Do not operate the RC car near people, pets, or obstacles to avoid collisions.
- Keep fingers, hair, and loose clothing away from the wheels and moving parts of the car.
- Do not operate the car in wet conditions or near water to prevent electrical damage.
- Ensure batteries are inserted with correct polarity. Do not mix old and new batteries, or different types of batteries.
- Remove batteries from the car and remote control when not in use for extended periods.
- Do not attempt to modify or disassemble the product.

## 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x RASTAR 98500 Mercedes-AMG F1 RC Car
- 1 x Remote Controller
- 1 x Instruction Manual
- DIY Lables (Stickers)

**Note:** 5 AA batteries are required (3 for the car, 2 for the controller) and are not included in the box.




Image 3.1: Included DIY stickers for customizing the RC car.

## 4. SETUP

---

### 4.1 Battery Installation (RC Car)

1. Locate the battery compartment on the underside of the RC car.
2. Use a screwdriver to open the battery compartment cover.
3. Insert 3 AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

### 4.2 Battery Installation (Remote Controller)

1. Locate the battery compartment on the back of the remote controller.
2. Use a screwdriver to open the battery compartment cover.
3. Insert 2 AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.



Image 4.1: The remote controller, requiring 2 AA batteries.

### 4.3 Pairing the Car and Remote

The car and remote control are typically pre-paired. If they do not connect automatically:

1. Ensure both the car and remote have fresh batteries installed.
2. Turn on the RC car using the power switch (usually on the underside).
3. Turn on the remote controller.
4. The indicator light on the remote should stop flashing and remain solid, indicating a successful connection. If not, turn both off and on again, ensuring they are close to each other.

## 5. OPERATING INSTRUCTIONS

---

Your RASTAR RC car offers full directional control:

- **Forward:** Push the left joystick forward.
- **Reverse:** Pull the left joystick backward.
- **Turn Left:** While moving forward or backward, push the right joystick left.
- **Turn Right:** While moving forward or backward, push the right joystick right.
- **Stop:** Release the left joystick to its neutral position.

The car operates at a low speed (approximately 4 MPH), making it suitable for both indoor and outdoor environments. For optimal performance, operate on smooth, flat surfaces.



Image 5.1: Operating the RC car with the remote control.




Image 5.2: Visual representation of the car's movement capabilities (forward, reverse, left, right).

## 6. MAINTENANCE

---

Proper maintenance will extend the lifespan of your RC car:

- **Cleaning:** Use a soft, dry cloth to wipe down the car after use. Do not use water or chemical cleaners.
- **Storage:** Store the car and remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Always remove batteries from both the car and remote if they will not be used for an extended period to prevent leakage.

- **Inspection:** Periodically check for loose screws or damaged parts. Do not operate if parts are broken.

## 7. TROUBLESHOOTING

---

If you encounter issues, refer to the following table:

Problem	Possible Cause	Solution
Car does not move or respond.	Batteries are dead or incorrectly installed. Car or remote is not turned on. Car and remote are not paired.	Replace batteries with fresh ones, ensuring correct polarity. Ensure both power switches are in the "ON" position. Turn both devices off and on again to re-establish connection.
Car moves slowly or erratically.	Low battery power. Interference from other RC devices or electronics.	Replace batteries in both car and remote. Move to an area with less interference.
Steering is not straight.	Wheel alignment issue.	Check for a steering trim adjustment on the underside of the car or on the remote (if available) and adjust as needed.

## 8. SPECIFICATIONS

---

Feature	Detail
Model Number	98500
Scale	1:18
Product Dimensions	12.5 x 4.6 x 2.4 inches
Item Weight	1.23 pounds
Recommended Age	6 - 12 years
Car Batteries Required	3 x AA (not included)
Controller Batteries Required	2 x AA (not included)
Speed	Approximately 4 MPH (low speed)
Manufacturer	Rastar Group

## 9. WARRANTY AND SUPPORT

---

For warranty information, technical support, or inquiries regarding your RASTAR 98500 Mercedes-AMG F1 RC Car, please refer to the official RASTAR website or contact their customer service directly. Contact details are typically provided on the product packaging or on the manufacturer's official website.

You can visit the RASTAR Store for more information:[RASTAR Official Store](#)

## Related Documents - 98500

	<p><a href="#"><b>Rastar RC Car Instructions and Operation Guide</b></a> Comprehensive instructions, operation guide, features, and maintenance for Rastar RC cars (models 53800, 98500, 93300, 93400, 94800). Learn how to operate, maintain, and troubleshoot your Rastar remote control vehicle.</p>
	<p><a href="#"><b>Rastar RC Car 53800/98500/93300/93400 Instructions and Operation Guide</b></a> Official instructions and operation guide for Rastar 1:18 scale RC cars (models 53800, 98500, 93300, 93400), covering features, functions, maintenance, and safety precautions.</p>
	<p><a href="#"><b>RASTAR 2.4GHz Remote Control Car Instructions - Models 92000-96300</b></a> User manual and operation guide for RASTAR 2.4GHz remote control cars, including setup, features, functions, maintenance, and safety warnings for models 92000, 94500, 94600, 94900, and 96300.</p>
	<p><a href="#"><b>Инструкция по эксплуатации робота RASTAR 77900</b></a> Полное руководство по использованию игрушечного робота RASTAR 77900. Включает настройку, управление, функции, программирование и меры безопасности.</p>
	<p><a href="#"><b>Rastar LaFerrari Ride-on Instruction Manual</b></a> This instruction manual provides detailed information on the Rastar LaFerrari ride-on toy car, covering specifications, assembly, operation, maintenance, troubleshooting, and safety warnings for children aged 37-96 months.</p>
	<p><a href="#"><b>Rastar RC Car 92840, 80445B308D7 Instructions and Operation Guide</b></a> Comprehensive instructions and operation guide for Rastar RC Cars models 92840 and 80445B308D7, covering battery charging, operation, features, and maintenance.</p>