Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY AVR130-GAI

Allimity AVR130 Replaced Remote Control User Manual

For Harman KARDON AV Receiver Model: AVR130

1. Product Overview

The Allimity AVR130 Replaced Remote Control is a direct replacement remote designed specifically for Harman Kardon AVR130 AV receivers. It provides full functionality without the need for complex programming or setup. Simply insert batteries, and the remote is ready for use.
Key features include:

- Direct compatibility with Harman Kardon AVR130 AV receivers.
- No programming or pairing required.
- Easy access to all standard remote control buttons.





Image: Front view of the Allimity AVR130 replacement remote control, showing all buttons and layout.

2. Setup and Battery Installation

This remote control requires two (2) AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use with your Harman Kardon AVR130 AV receiver. No additional programming or setup is necessary.





Image: Back view of the Allimity AVR130 replacement remote control, showing the open battery compartment ready for AAA batteries.

3. Operating Instructions

The Allimity AVR130 replacement remote control is designed to replicate the functions of your original Harman Kardon AVR130 remote. Point the remote directly at your AV receiver and press the desired buttons to control its functions.
Common functions include:

- **Power On/Off:** Use the power button to turn the receiver on or off.
- **Volume Control:** Adjust the volume using the 'VOL+' and 'VOL-' buttons.
- **Input Selection:** Switch between different audio/video inputs (e.g., CD, DVD, HDMI, TV) using the dedicated input buttons.
- **Navigation:** Use the directional arrow buttons and 'OK' button for menu navigation.
- **Sound Modes:** Access various sound modes (e.g., Dolby Surround, DTS Surround) if available on your receiver.

Refer to your Harman Kardon AVR130 AV receiver's original manual for detailed explanations of specific functions and menu navigation.

4. Maintenance and Care

To ensure the longevity and optimal performance of your remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical shocks and drops, which can damage internal components.

5. Troubleshooting

If you experience issues with your Allimity AVR130 replacement remote control, try the following troubleshooting steps:

Remote Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old or depleted batteries with new ones.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the infrared sensor on your Harman Kardon AVR130 receiver.
- **Distance:** Ensure you are within the effective operating range of the remote control.

Specific Buttons Not Working:

- **Battery Check:** Even if some buttons work, low batteries can cause intermittent issues. Replace them.
- **Compatibility:** While designed for AVR130, ensure your specific Harman Kardon model is indeed the AVR130. Some similar models might have slight differences.
- **Cleanliness:** Ensure there is no dirt or debris lodged under the buttons.

Remote Not Compatible (as reported by some users):

While this remote is advertised as compatible with Harman Kardon AVR130, if you find that most keys are not working or it's not compatible with your specific unit, please:

- Double-check your AV receiver's model number to confirm it is precisely the Harman Kardon AVR130.
- Ensure you have followed all battery installation steps correctly.
- Contact the seller or manufacturer for further assistance or to inquire about return/exchange options if compatibility issues persist.

6. Specifications

Feature	Detail
Product Dimensions	6.9 x 1 x 0.5 inches
Item Weight	2 ounces
Compatible Devices	Harman Kardon AVR130 AV receiver
Connectivity Technology	Infrared (IR)
Batteries Required	2 x AAA (not included)
Special Feature	No Programming Required

7. Warranty and Support

For warranty information and customer support regarding your Allimity AVR130 Replaced Remote Control, please refer to the specific terms provided by the retailer or manufacturer at the time of purchase. As this is a replacement product, warranty terms may vary.
If you encounter any issues not covered in this manual or require further assistance, please contact the seller directly through your purchase platform. Provide your order details for prompt support.

© 2024 Allimity. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09P3RBPVV

More documents and user manuals: **https://manuals.plus/**