

Ecoprsio Ecoprsio

Ecoprsio 32-Inch Rustic Brown Entryway Table with Outlets and USB Ports - Instruction Manual

Model: Ecoprsio (B09P3W1H9Y)

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Ecoprsio 32-inch Rustic Brown Entryway Table. Please read these instructions carefully before assembly and use to ensure safe and proper functionality.

SAFETY INFORMATION

- Always unplug the electrical outlet before cleaning or moving the table.
- Do not overload the shelves or drawers.
- Ensure the table is properly assembled and stable before use.
- Keep the electrical outlet and USB ports away from water and heat sources.
- Always follow the manufacturer's instructions for safe use and assembly.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. Refer to the included parts list in your package for specific component identification.

- Tabletop with 2 Drawers
- Metal Frame Components
- 2 Mesh Storage Shelves

- Electrical Outlet Board (2 AC outlets, 2 USB ports)
- Power Cord (6.56 FT)
- Adjustable Foot Pads
- Assembly Hardware (screws, etc.)
- Installation Tool
- Velcro Tape for cable management

SETUP AND ASSEMBLY

Assembly is designed to be straightforward. All parts are labeled with letters, and hardware is numbered for easy identification. An installation tool is included. A hammer may be useful for gently tapping in adjustable footings and drawer stops.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Attach the metal frame components according to the detailed instructions provided in your package. Ensure all screws are finger-tightened initially.
3. Secure the tabletop to the assembled frame.
4. Install the two drawers into their designated slots. The drawers are designed with internal stops to prevent them from falling out when fully extended.
5. Insert the two mesh storage shelves into the lower sections of the frame.
6. Attach the electrical outlet board to either side of the table frame, as preferred.
7. Screw in the adjustable foot pads at the bottom of each leg. Use a hammer if needed to gently tap them into place.
8. Once all components are in place, fully tighten all screws.

1 Outlets

with 3 power outlets and 2 USB ports



2 Velcro Tape


Quick and easy to organize wires



Large Drawer
Storage Space



Black Round
Knobs



Double Mesh
Storage Layers



Adjustable
Foot Pads

Image Description: Diagram showing the dimensions of the Ecoprso Entryway Table. The table measures 32 inches in width, 11.8 inches in depth, and 31.8 inches in height. The drawers are 14.5 inches wide and 4.9 inches high. The power cord is 78.7 inches long. The image also highlights the 120V/12A, 3 AC Outlets, 5V/2.1A, 2 USB Ports, and 6.56FT Power Cord specifications.



Image Description: Detailed view of the table's features. It shows the electrical outlet with 3 power outlets and 2 USB ports, velcro tape for cable organization, a large drawer with storage space, black round knobs, double mesh storage layers, and adjustable foot pads.

OPERATING INSTRUCTIONS

Using the Power Outlets and USB Ports

The table is equipped with an integrated power strip featuring 2 standard AC outlets (120V/12A) and 2 USB ports (5V/2.1A).

- Plug the table's power cord (6.56 FT) into a functional wall outlet.
- Use the AC outlets to power lamps, small appliances, or other electronic devices.
- Use the USB ports to charge mobile phones, tablets, smartwatches, and other USB-powered devices.

- Utilize the included velcro tape to manage and organize the power cord and any connected device cables, preventing clutter.

Drawer Functionality

The two drawers provide enclosed storage for smaller items. They are designed with internal stops to prevent accidental removal when pulled out.

Adjustable Foot Pads

The adjustable foot pads at the base of each leg allow for minor height adjustments to ensure the table remains stable on uneven surfaces. Rotate the pads clockwise or counter-clockwise to raise or lower each corner until the table is level and stable.

MAINTENANCE

To maintain the appearance and longevity of your table:

- **Cleaning:** Wipe with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Promptly wipe up any spills to prevent staining, especially on the engineered wood surfaces.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Electrical Components:** Ensure the power cord and outlets are free from damage. Do not attempt to repair electrical components yourself.

TROUBLESHOOTING

Table Wobbles

Adjust the foot pads at the bottom of each leg until the table is stable on the floor.

Power Outlets/USB Ports Not Working

- Ensure the table's main power cord is securely plugged into a functional wall outlet.
- Check if the wall outlet itself is receiving power (test with another device).
- Avoid overloading the outlets. If too many high-power devices are connected, it may trip a circuit breaker.
- If the issue persists, discontinue use and contact customer support.

Drawers Stick or Don't Slide Smoothly

- Ensure the drawers are correctly aligned within their tracks.
- Check for any obstructions inside the drawer or along the tracks.
- Verify that the table is level using the adjustable foot pads.

SPECIFICATIONS

Feature	Detail
Brand	Ecoprsio
Model Name	Ecoprsio
Product Dimensions (D x W x H)	11.8"D x 32"W x 31.8"H
Color	Rustic Brown
Material Type	Engineered Wood, Metal
Frame Material	Metal
Top Material	Engineered Wood
Number of Drawers	2
Number of Shelves	3 (including top surface)
Power Outlets	2 AC Outlets (120V/12A)
USB Ports	2 USB Ports (5V/2.1A)
Power Cord Length	6.56 Feet
Style	Farmhouse
Indoor/Outdoor Usage	Indoor

WARRANTY AND SUPPORT

Ecoprsio provides customer support for any issues related to quality or assembly. If you encounter any problems with your entryway table, please contact Ecoprsio customer service.

Contact Information: Refer to the contact details provided in your product packaging or visit the official Ecoprsio website for support.


PRODUCT IMAGES



Image Description: Front view of the Ecopsio 32-inch Rustic Brown Entryway Table. It features a rustic brown wooden top with two drawers, a black metal frame, and two lower mesh shelves. An integrated power outlet is visible on the right side, and the power cord extends from the bottom. The table is decorated with a vase of flowers, a fruit bowl, a framed picture, and a lamp on top, with books and decorative items on the shelves.



Image Description: The Ecoprsio 32-inch Rustic Brown Entryway Table placed in a living room or hallway. The table is positioned against a wainscoted wall, next to a window, with potted plants on either side. It is adorned with similar decorative items as the previous image, showcasing its aesthetic integration into a home environment.



120V/12A
3 AC Outlets



5V/2.1A
2 USB Ports



6.56FT
Power Cord

Image Description: The Ecoprsio 32-inch Rustic Brown Entryway Table configured as a coffee bar in a kitchen setting. The tabletop holds a coffee machine, mugs, and other coffee accessories. The lower shelves store wine bottles, a wine rack, and baskets, demonstrating its versatility.



Image Description: The Ecopsio 32-inch Rustic Brown Entryway Table serving as a decorative console in a dimly lit room. The tabletop features a lamp, various decorative objects, and framed art. The shelves below are filled with books, candles, and other ornamental items, highlighting its use for display.



Image Description: The Ecoprsio 32-inch Rustic Brown Entryway Table functioning as an aquarium stand. A fish tank is placed on the tabletop, and the lower shelves hold potted plants and decorative items, illustrating its robust construction and suitability for heavier objects.

Upgraded Power Outlets Design

Expand your daily usage of the Power Plugs

Upgrade Version ✓



Former Version ✗



Image Description: A comparison image showing an "Upgrade Version" and "Former Version" of the power outlets. The upgraded version features wider spacing between AC outlets, allowing for larger plugs, while the former version has closer spacing. Both include USB ports.

PRODUCT VIDEOS

No official seller-provided product videos were found for this model.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09P3W1H9Y>

More documents and user manuals: **<https://manuals.plus/>**