

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Aucma](#) /

> [Aucma BL-601 Blender Instruction Manual](#)

## Aucma BL-601

# Aucma BL-601 Blender Instruction Manual

Model: BL-601

## IMPORTANT SAFETY INFORMATION

---

Please read all instructions carefully before using your Aucma BL-601 Blender. Keep this manual for future reference. Failure to follow these safety instructions may result in electric shock, fire, or serious injury.

- Always unplug the blender from the power outlet before assembling, disassembling, or cleaning.
- Do not immerse the motor unit in water or any other liquid. Wipe with a damp cloth only.
- Blades are sharp. Handle with extreme care when assembling, disassembling, or cleaning.
- Ensure the jar and lid are correctly assembled and the safety lock is engaged before operating.
- Do not operate the blender with an empty jar.
- Never place hands or utensils into the blender jar while the appliance is operating. Use the measuring cup opening in the lid to add ingredients during blending.
- Keep the appliance out of reach of children.
- Do not use the blender for purposes other than its intended use.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

## PRODUCT COMPONENTS

---

Your Aucma BL-601 Blender includes the following parts:

- Motor Unit (Base)
- 1.5L Plastic Jar with Level Indicator
- Lid
- Measuring Cup (fits into lid opening)
- 4-Piece Stainless Steel Blade Assembly (detachable)





*Image: The Aucma BL-601 Blender, showcasing its main components including the motor base and the 1.5-liter plastic jar*

## SETUP

---

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or disposal.
2. **Clean Before First Use:** Wash the 1.5L plastic jar, lid, and 4-piece stainless steel blade assembly in warm, soapy water. Rinse thoroughly and dry. The motor unit should only be wiped with a damp cloth.
3. **Assemble Blade:** Ensure the detachable 4-piece stainless steel blade assembly is securely attached to the bottom of the plastic jar.
4. **Place Jar on Motor Unit:** Position the assembled jar onto the motor unit. Rotate the jar clockwise until it locks securely into place. The blender features a double safety lock, ensuring it will not operate unless the jar is correctly seated.
5. **Connect Power:** Plug the power cord into a standard 110-120V, 50/60Hz electrical outlet.

## OPERATING INSTRUCTIONS

---

Follow these steps for safe and effective blending:

1. **Add Ingredients:** Place your desired ingredients into the 1.5L plastic jar. Do not exceed the maximum fill level indicated on the jar. For best results, cut solid ingredients into smaller pieces.
2. **Secure Lid:** Place the lid firmly onto the jar. Ensure the measuring cup is inserted into the lid's opening.
3. **Select Speed:** The blender offers 2 speeds and a pulse function. Turn the control knob to your desired speed setting (1 or 2) for continuous blending. For short bursts of power, turn the knob to the 'P' (Pulse) setting and release.
4. **Ice-Crush Function:** For crushing ice, use the pulse function with short, powerful bursts until the desired consistency is achieved. Ensure there is sufficient liquid or other ingredients to assist the process.
5. **Adding Ingredients During Blending:** If you need to add ingredients while the blender is operating, remove the measuring cup from the lid and carefully add items through the opening. Replace the measuring cup immediately.
6. **Finish Blending:** Once blending is complete, turn the control knob to the 'OFF' position.
7. **Unplug:** Always unplug the blender from the power outlet after use.

**Important:** To prevent motor overheating, do not operate the blender continuously for more than 1-2 minutes. Allow the motor to rest for several minutes between cycles.

## CLEANING AND MAINTENANCE

---

Proper cleaning and maintenance will ensure the longevity of your blender.

1. **Unplug:** Always ensure the blender is unplugged before cleaning.
2. **Disassemble:** Remove the jar from the motor unit. Carefully detach the blade assembly from the bottom of the jar. Remove the lid and measuring cup.
3. **Wash Parts:** The 1.5L plastic jar, lid, measuring cup, and 4-piece stainless steel blade assembly are dishwasher safe. Alternatively, wash them in warm, soapy water using a brush for the blades to ensure thorough cleaning. Rinse and dry completely.
4. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water or any other liquid.
5. **Cord Storage:** The motor unit features a cord storage function for neat and tidy storage.
6. **Storage:** Store the blender in a dry place, away from direct sunlight and heat.

## TROUBLESHOOTING

---

If you encounter issues with your blender, refer to the following common problems and solutions:

- **Blender does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check that the jar is correctly seated and locked onto the motor unit. The double safety lock prevents operation if not properly assembled.
- **Ingredients are not blending smoothly:**
  - Add more liquid to the mixture.
  - Cut solid ingredients into smaller, more manageable pieces.
  - Use the pulse function for short bursts to dislodge ingredients.
  - Do not overfill the jar.
- **Motor stops during operation or smells burnt:**
  - The motor may be overheating. Turn off the blender, unplug it, and allow it to cool down for at least 15-20 minutes before attempting to use it again.
  - Reduce the load by removing some ingredients or adding more liquid.

## SPECIFICATIONS

---

<b>Brand</b>	Aucma
<b>Model Number</b>	BL-601
<b>Power</b>	600W
<b>Voltage</b>	110-120V
<b>Frequency</b>	50/60Hz
<b>Capacity</b>	1.5 Liters
<b>Number of Speeds</b>	2 + Pulse Function
<b>Blade Material</b>	4-Piece Stainless Steel
<b>Housing Material</b>	Plastic
<b>Jar Material</b>	Plastic
<b>Dimensions (D x W x H)</b>	8.26" x 8.26" x 17.51"
<b>Item Weight</b>	3.3 lbs
<b>Special Features</b>	Ice-Crush Function, Detachable Blade, Double Safety Lock, Cord Storage, Anti-Slip Feet, BPA Free

## WARRANTY AND SUPPORT

---

This Aucma BL-601 Blender comes with a **Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or contact Aucma customer support.

If you require technical assistance, have questions about your product, or need to claim warranty service, please

contact the manufacturer directly using the contact information provided in your product packaging or on the official Aucma website.