Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Playmobil 71029

PLAYMOBIL Adventures of Ayuma Advent Calendar 71029 User Manual

Your guide to magical adventures in the fairy world.

Introduction

Welcome to the enchanting world of PLAYMOBIL Adventures of Ayuma! This Advent Calendar (Model 71029) provides 24 daily surprises, leading up to a complete fairy academy scene with captivating fairy figures and their spirit animals. Designed for children aged 7 to 12, this set offers imaginative play and high-quality, robust components.

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your PLAYMOBIL Advent Calendar. Please read it carefully to ensure a safe and enjoyable experience.



Image: The complete PLAYMOBIL Adventures of Ayuma Advent Calendar set, showcasing the fairies, spirit animals, and winter landscape.

Safety Information

WARNING: CHOKING HAZARD - Small parts. Not suitable for children under 3 years.
This product contains small components that may pose a choking hazard to young children. Adult supervision is recommended during assembly and play, especially for younger users within the recommended age range.

Setup

Follow these steps to set up your PLAYMOBIL Adventures of Ayuma Advent Calendar:

1. **Unboxing:** Carefully remove the Advent Calendar box from its packaging.
2. **Calendar Placement:** Place the Advent Calendar in a suitable location where it can be easily accessed each day.
3. **Background Scene:** The calendar often includes a background scene. Carefully unfold or assemble this scene as instructed on the packaging to create the winter fairy world backdrop.

4. **Daily Surprises:** Each day, from December 1st to 24th, open the corresponding numbered door to reveal a new figure or accessory.
5. **Assembly of Figures:** Some figures or accessories may require minor assembly (e.g., attaching wings to fairies, combining small parts). Refer to the small diagrams or instructions included with each day's surprise if needed.



Image: Individual components of the PLAYMOBIL Adventures of Ayuma Advent Calendar, ready for assembly and play.

Included Components: The set includes figures such as 1 Forest Fairy, 1 Moon Fairy, and various spirit animals like a fawn, skunk, deer, snake, spider, large dragonfly, small dragonfly, 2 fox babies, 1 dino baby, 1 pelican, 1 pelican baby, 2 butterflies, 2 wash bear babies. Accessories include 1 pond, 1 snow platform, 1 waterfall, 1 sleigh, 1 bag, 2 beets, 1 ladle, 1 grass bundle, 2 grass bundles, 1 grass plate, 1 tree, 1 two-part egg, 1 dino egg, 1 branch with lantern, 1 nest with bird eggs, 3 mushrooms in the snow, 4 snow parts for sticking, 1 white algae leaf with flower, 2 tree trunks, 1 tree stump, 1 pelican nest, 1 green plant, various crystals, 1 pair of Forest Fairy wings, 1 Forest Fairy rock, 1 Forest Fairy hat, 1 pair of Bat Fairy wings, 1 Bat Fairy rock, 1 Bat Fairy cape, and 1 Bat Fairy hat.

Operating Instructions

The PLAYMOBIL Adventures of Ayuma Advent Calendar is designed for daily discovery and imaginative play.

1. **Daily Opening:** Starting on December 1st, open one numbered door each day. The number on the door corresponds to the day of the month.
2. **Reveal the Surprise:** Inside each door, you will find a new PLAYMOBIL figure or accessory.
3. **Integrate into Play:** Add the newly revealed item to your growing Ayuma fairy world scene. The figures, such as the Bat Fairy and Forest Fairy, often come with movable wings that can be attached.
4. **Imaginative Play:** Use the figures and accessories to create your own stories and adventures in the winter fairy academy setting.



Image: The packaging of the PLAYMOBIL Adventures of Ayuma Advent Calendar, showing the product's theme and age recommendation.

Maintenance

To ensure the longevity and cleanliness of your PLAYMOBIL set:

- **Cleaning:** All components (excluding stickers) can be cleaned under running water. Avoid using chemical cleaning agents, as these may damage the plastic or paint.
- **Storage:** Store the figures and accessories in a clean, dry place away from direct sunlight and extreme temperatures to prevent discoloration or deformation.
- **Handling:** While robust, avoid excessive force when assembling or playing with the figures to prevent breakage.

Troubleshooting

- **Missing Parts:** If you discover any missing parts upon opening a door, first double-check the packaging and the calendar compartments. Sometimes small parts can shift. If parts are genuinely missing, please contact PLAYMOBIL customer support (see Support section).
- **Difficulty Assembling:** If you encounter difficulty assembling a figure or accessory, refer to any small diagrams provided with the daily surprise. Ensure parts are aligned correctly before applying gentle pressure. Do not force parts together.
- **Damaged Parts:** If a part is damaged, avoid using it to prevent further injury or damage to other components. Contact customer support for assistance.

Specifications

Feature	Detail
Brand	Playmobil
Model Number	71029
Calendar Box Dimensions	40 x 30 x 7.5 cm
Item Weight	0.77 kg (Total)
Individual Item Dimensions (example)	13.5L x 11.5W cm
Recommended Age	7 - 12 years
Material	Plastic
Theme	Christmas, Fantasy, Fairies
Number of Items	1 (Advent Calendar containing 24 surprises)
Publication Date	September 2, 2022

Warranty Information

PLAYMOBIL products are manufactured to high-quality standards. For specific warranty details regarding manufacturing defects or missing parts, please refer to the information provided on the product packaging or the official PLAYMOBIL website. Typically, PLAYMOBIL offers a limited warranty against defects in materials and workmanship.

Support

For further assistance, questions, or to report missing/damaged parts, please contact PLAYMOBIL customer service:

- **Online:** Visit the official PLAYMOBIL website and navigate to the "Customer Service" or "Contact Us" section.
- **Phone:** Check the product packaging for regional customer service phone numbers.
- **Mail:** Contact information for postal inquiries can also be found on the official website.

When contacting support, please have your product model number (71029) and purchase details readily available.

© 2026 PLAYMOBIL. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09P4B2VS2

More documents and user manuals: **https://manuals.plus/**