

Sony KD43X80K

Sony 43 Inch 4K Ultra HD Google TV X80K Series (KD43X80K) Instruction Manual

1. INTRODUCTION AND OVERVIEW

Welcome to the world of immersive entertainment with your new Sony 43 Inch 4K Ultra HD Google TV X80K Series (KD43X80K). This television is designed to deliver a stunning visual and audio experience, powered by advanced technologies such as the 4K HDR Processor X1, TRILUMINOS PRO, and support for Dolby Vision HDR. Enjoy a seamless smart TV experience with Google TV, organizing all your favorite content in one place. This manual will guide you through the setup, operation, and maintenance of your new television.



Image 1.1: The Sony 43 Inch 4K Ultra HD Google TV X80K Series (KD43X80K) displayed in a modern living room environment, showcasing its sleek design and vibrant display.

2. WHAT'S IN THE BOX

Upon unboxing your Sony KD43X80K TV, please ensure all the following components are present:

- Sony 43 Inch 4K Ultra HD Google TV (KD43X80K)
- TV Stand (2 pieces)
- Remote Control
- Power Cable

- Setup Guide and Documentation



Image 2.1: The included remote control for the Sony X80K Series TV, featuring dedicated buttons for popular streaming services and Google Assistant.

3. SETUP

3.1 Attaching the TV Stand

1. Carefully place the TV screen-down on a soft, flat surface to prevent damage.
2. Align the stand pieces with the designated slots on the bottom of the TV.
3. Secure the stand using the provided screws. Ensure they are tightened firmly.

3.2 Connecting Power and Initial Power-On

1. Connect the power cable to the TV and then to a power outlet.
2. Press the power button on the remote control or on the TV itself.
3. Follow the on-screen instructions for initial setup, including language selection, network connection, and Google TV account setup.

3.3 Connecting External Devices

Your Sony KD43X80K TV offers multiple connectivity options. For optimal performance with gaming consoles or other high-bandwidth devices, use HDMI 2.1 ports (typically labeled 3 and 4) and ensure the HDMI signal format is set to 'Enhanced format (VRR)' in the TV settings.



Image 3.1: Rear view of the Sony X80K Series TV, illustrating the layout of the various input and output ports.




Image 3.2: A detailed close-up of the connectivity panel on the back of the Sony X80K Series TV, highlighting HDMI, USB, Ethernet, and other input options.

4. OPERATING INSTRUCTIONS

4.1 Remote Control Functions

The included remote control provides easy access to all TV functions:

- **Power Button:** Turns the TV on/off.

- **Navigation Pad:** Use the directional buttons to navigate menus and the center button to select.
- **Volume +/-:** Adjusts the volume level.
- **Channel +/-:** Changes TV channels.
- **Google Assistant Button:** Press and hold to activate voice commands.
- **Dedicated App Buttons:** Quick access to popular streaming services like Netflix, YouTube, Disney+, and Prime Video.
- **Home Button:** Returns to the Google TV home screen.

4.2 Google TV Interface

Google TV organizes your favorite content from various streaming services into a personalized home screen. You can browse recommendations, access your installed apps, and manage your watchlist.



Image 4.1: The Google TV home screen displayed on the Sony X80K Series TV, showing personalized content recommendations and quick access to various streaming applications.

4.3 Voice Control with Google Assistant

Press and hold the Google Assistant button on your remote to speak commands. You can ask it to find movies, open apps, control smart home devices, and more.

4.4 Picture and Sound Settings

Access the TV's settings menu to customize picture and sound. Adjust brightness, contrast, color, and sharpness for your preferred visual experience. Sound settings allow for adjustments to equalizer, surround sound, and voice enhancement.

5. FEATURES

- **Intelligent TV Processing:** The 4K HDR Processor X1 delivers a smooth, clear picture with rich colors and detailed contrast.
- **Wide Spectrum of Colors:** TRILUMINOS Pro reproduces over a billion accurate colors for natural and precise picture quality.
- **Premium Smart TV:** Google TV with Google Assistant organizes content from Prime Video, Netflix, Disney+, Apple TV, HBO Max, Peacock, and more. Supports AirPlay 2.
- **Enhanced Entertainment:** Experience immersive cinematic content with Dolby Vision and Dolby Atmos support.

- **Works with Alexa:** Control your TV with voice commands through an Alexa-enabled device.
- **Enhanced Gaming Picture Quality:** Exclusive features for PlayStation 5 improve gaming visuals.
- **Flush Surface Design:** A narrow bezel design keeps focus on the screen.
- **Intelligent Motion Handling:** Motionflow XR ensures blur-free picture quality for fast-moving scenes.
- **Upscale All Your Content:** 4K X-Reality PRO upscales content to near-4K resolution, restoring lost texture and detail.



Image 5.1: A visual comparison demonstrating the expanded color gamut provided by TRILUMINOS Pro technology.

Exclusive features for PlayStation®5



Image 5.2: A side-by-side comparison illustrating the blur reduction capabilities of Motionflow XR during fast-paced action scenes.



Image 5.3: A visual representation of the enhanced contrast and detail offered by HDR and Dolby Vision technologies.



Image 5.4: The Sony X80K Series TV paired with a PlayStation 5 console, highlighting its optimized features for gaming.

5.1 Official Product Video: Sony 4K Ultra HD TV X80K Series

Video 5.1: An official video from Sony Electronics showcasing the key features and visual quality of the Sony 4K Ultra HD TV X80K Series.

5.2 Official Product Video: Sony | Top Features Of The X80K 4K HDR LED TV

Video 5.2: An official video from Sony Electronics detailing the top features of the X80K 4K HDR LED TV, including picture processing and smart functionalities.

6. MAINTENANCE

6.1 Cleaning the TV

- **Screen:** Gently wipe the screen with a soft, dry microfiber cloth. For stubborn smudges, lightly dampen the cloth with water or a screen-specific cleaner (avoid harsh chemicals).
- **Frame and Stand:** Use a soft, dry cloth to wipe dust and dirt from the TV frame and stand.
- **Remote Control:** Wipe with a soft, dry cloth. Remove batteries if storing for extended periods.

6.2 Software Updates

Ensure your TV is connected to the internet to receive automatic software updates. These updates provide new features, performance improvements, and security enhancements. You can also manually check for updates in the TV's settings menu.

7. TROUBLESHOOTING

If you encounter any issues with your Sony KD43X80K TV, try the following basic troubleshooting steps:

- **No Power:** Check if the power cable is securely connected to both the TV and the power outlet. Try a different outlet.
- **No Picture/Sound:** Ensure the correct input source is selected. Check all cable connections (HDMI, antenna, etc.).
- **Remote Not Responding:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV.
- **Network Connectivity Issues:** Restart your router and modem. Reconnect the TV to your Wi-Fi network in the settings menu.
- **App Freezing/Slowness:** Close and reopen the app. If the issue persists, try clearing the app's cache or reinstalling it.
- **Factory Reset:** As a last resort, you can perform a factory reset through the TV's settings menu. This will erase all personalized settings and installed apps.

For more detailed troubleshooting, refer to the built-in user manual accessible via the TV's settings or visit the Sony support website.

8. SPECIFICATIONS

Feature	Specification
---------	---------------

Brand	Sony
Model Number	KD43X80K
Screen Size	43 Inches
Display Technology	LED
Resolution	4K (3840 x 2160)
Refresh Rate	60 Hz
Operating System	Google TV
Processor	4K HDR Processor X1
HDR Support	Dolby Vision, HDR10, HLG
Audio Technology	Dolby Atmos
Connectivity	Bluetooth, Ethernet, HDMI (2x 2.1, 2x 2.0), USB (1x 3.0, 1x 2.0), Wi-Fi
Dimensions (with stand)	38"W x 11.38"D x 24.75"H
Item Weight (with stand)	23.4 Pounds




Image 8.1: A diagram illustrating the dimensions of the Sony X80K Series TV, including width, height, and depth with the stand attached.

9. WARRANTY AND SUPPORT

Your Sony KD43X80K TV comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official Sony support website for detailed information regarding warranty terms, conditions, and registration. For further assistance, technical support, or service requests, please contact Sony customer service or visit their online support portal.