

[Manuals.plus](#) /

› [SMAEL](#) /

› SMAEL SL-8007 Sports Dual Display Watch User Manual

SMAEL SL-8007

SMAEL SL-8007 Sports Dual Display Watch User Manual

Model: SL-8007 | Brand: SMAEL

INTRODUCTION

Thank you for choosing the SMAEL SL-8007 Sports Dual Display Watch. This manual provides detailed instructions for setting up, operating, and maintaining your watch to ensure optimal performance and longevity. Please read this manual thoroughly before using your watch.



Image: The SMAEL SL-8007 watch, showcasing its robust design and dual display on a dark background.

KEY FEATURES

- Dual time display (analog and digital) with LED backlight.
- 50M water resistance, suitable for everyday use, splashes, and rain. *(Note: Do not press buttons underwater. Keep away from steam and hot water.)*
- Japanese original digital movement for precise timekeeping.
- Functions include alarm, stopwatch, shock resistance, date, and week display.
- 12/24-hour format options.
- Durable construction with strong PU strap, rubber case, and high-strength hardened glass.



Image: The SMAEL SL-8007 watch worn on a wrist, demonstrating its fit and appearance during outdoor activity.

SETUP AND INITIAL CONFIGURATION

Button Functions:

- **LIGHT:** Activates the LED backlight.
- **MODE:** Cycles through different modes (Time, Alarm, Stopwatch).
- **START:** Used for starting/stopping stopwatch, adjusting settings.
- **RESET:** Used for resetting stopwatch, adjusting settings.

Setting Digital Time and Date:

1. Press the **MODE** button repeatedly until the digital time display starts flashing, indicating setting mode.
2. Use the **RESET** button to select the item you wish to adjust (e.g., seconds, minutes, hours, 12/24H format, month, date, day of week).

3. Use the **START** button to increase the selected value.
4. Once all settings are correct, press the **MODE** button to exit the setting mode.

Setting Analog Time:

1. Pull out the crown (the small knob on the right side of the watch case) to the first position.
2. Rotate the crown to adjust the analog hour and minute hands to the desired time.
3. Push the crown back in to secure the analog time setting.



Image: A detailed view of the watch face, highlighting the dual analog and digital displays and various indicators.

OPERATING INSTRUCTIONS

Using the LED Backlight:

Press the **LIGHT** button (top-left) to illuminate the digital display for easy viewing in low-light conditions. The backlight will remain on for a few seconds.

Alarm Function:

1. Press the **MODE** button until "AL" (Alarm) appears on the digital display.
2. Press **RESET** to select hours or minutes.
3. Use **START** to adjust the alarm time.
4. Press **MODE** to activate/deactivate the alarm or to exit.

Stopwatch Function:

1. Press the **MODE** button until "ST" (Stopwatch) appears.
2. Press **START** to begin timing.
3. Press **START** again to pause.
4. Press **RESET** to clear the stopwatch to zero.

5. To measure split times, press **RESET** while the stopwatch is running. Press **RESET** again to return to the running time.

Water Resistance:

The SMAEL SL-8007 watch is rated for 50 meters (5 ATM) water resistance. This means it is suitable for everyday use, including splashes, rain, and brief immersion in water such as swimming.

- **Do NOT press any buttons underwater.** This can compromise the water resistance seals.
- Avoid exposing the watch to hot water or steam (e.g., hot showers, saunas), as this can damage the waterproof ring.



Image: A visual representation of the watch's 50-meter water resistance capability, suitable for swimming.

MAINTENANCE

Cleaning Your Watch:

- Wipe the watch case and strap regularly with a soft, damp cloth to remove dirt and sweat.
- For stubborn dirt, use a mild soap solution and rinse thoroughly with clean water, ensuring the crown is pushed in.
- Dry the watch completely with a soft, dry cloth after cleaning or exposure to water.

Battery Replacement:

The watch is powered by a battery. When the display dims or the watch stops functioning, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.

Storage:

When not in use for extended periods, store your watch in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **Digital display is blank or dim:** The battery may be low or depleted. Replace the battery.
- **Analog hands are not moving:** Check if the crown is pushed in completely. If it is, the battery for the analog movement might be depleted, or there could be a mechanical issue.
- **Time is inaccurate:** Re-set both the digital and analog time as per the "Setup and Initial Configuration" section. If the issue persists, the battery may be low or the movement may require servicing.
- **Water inside the watch:** Immediately take the watch to a professional watch repair service. Do not attempt to open the watch yourself, as this will void any potential warranty and likely cause further damage. Ensure buttons are not pressed underwater.

SPECIFICATIONS

Feature	Detail
Brand	SMAEL
Model Number	SL-8007
Display Type	Analog-Digital
Movement Type	Quartz (Japan Original Digital Movement)
Water Resistance Depth	50 Meters (5 ATM)
Case Material	Strong Rubber
Strap Material	Strong PU (Plastic)
Mirror Material	High Strength Hardened Glass (Mineral Glass)
Clasp Type	Buckle (Tang Buckle)
Case Diameter	54 Millimeters
Band Width	22 Millimeters
Band Length	23 Centimeters
Additional Features	LED Backlight, Alarm, Stopwatch, Shock Resistant, Date, Week Display, 12/24H Format

BASIC PARAMETERS

BRAND: SMAEL

MODEL: 8007

WATERPROOF: 50M

BOTTOM COVER MATERIAL: STAINLESS STEEL

MIRROR MATERIAL: ACRYLIC

MOVEMENT: QUARTZ
DIGITAL MOVEMENT

GRAM WEIGHT: 78G

DIAL DIAMETER: 54MM

WEARING RANGE: 140MM-230MM



Image: A visual representation of the watch's basic parameters and specifications.

PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video showcasing the SMAEL SL-8007 watch's features, including its dual display, backlight, and water resistance demonstration.

WARRANTY AND SUPPORT

Warranty Information:

This SMAEL watch comes with a standard manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions. Keep your purchase receipt as proof of purchase.

Customer Support:

For any questions, concerns, or technical assistance regarding your SMAEL SL-8007 watch, please contact the retailer or the manufacturer's customer service. Contact details are typically provided in the product packaging or on the official SMAEL website.

PACKAGING SHOW



Image: The SMAEL SL-8007 watch presented in its gift box, as typically received by customers.

© 2023 SMAEL. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

