Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo EUR-CT2103-4TWL

ChooChoo Farmhouse Coffee Table Instruction Manual

Model: EUR-CT2103-4TWL | Brand: ChooChoo

1. Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Caution:** Product contains solid wood and manufactured wood materials that may have sharp edges or splinters. Handle with care.
- Follow assembly instructions carefully to avoid pinch points.
- Do not exceed the weight limit of**120 lbs (54 kg)** on the tabletop.
- Do not exceed the weight limit of**80 lbs (36 kg)** on the bottom shelf.
- Ensure the table is stable and placed on a level surface to prevent tipping.
- Keep small parts and hardware away from children during assembly.
- Assemble the product on a soft, clean surface to prevent scratches.

2. Package Contents

Verify that all parts and hardware are present before beginning assembly. If any parts are missing or damaged, please contact customer support.



Figure 2.1: Exploded view of the coffee table components, showing numbered parts for assembly.

Parts List (Example)

- **(1) Tabletop:** Main surface of the coffee table.
- **(2) Bottom Shelf:** Storage and display shelf.
- **(3, 4) Side Panels:** Structural supports with slatted design.
- **(5, 6) Support Rails:** Connect and stabilize the structure.

Hardware List (Example)

- Screws (various sizes)
- Wooden Dowels
- Cam Locks and Bolts
- Allen Wrench (Hex Key)
- Screwdriver (Phillips head recommended, not always included)

3. Assembly Instructions

Follow the detailed instructions provided in your product packaging. The general steps are outlined below:

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to the table or floor.
2. **Identify Parts:** Lay out all parts and hardware, matching them with the provided parts list and diagram (Figure 2.1).
3. **Assemble Side Panels:** Attach the support rails (5, 6) to the side panels (3, 4) using the specified hardware (e.g., screws, dowels).
4. **Attach Bottom Shelf:** Secure the bottom shelf (2) to the assembled side panels using the appropriate hardware. Ensure all connections are snug but do not overtighten.
5. **Install Tabletop:** Carefully place the tabletop (1) onto the assembled base. Align the pre-drilled holes and secure it with the remaining hardware.
6. **Final Tightening:** Once all parts are assembled, gently tighten all screws and bolts to ensure stability. Do not overtighten to avoid stripping or damaging the wood.



Figure 3.1: The fully assembled ChooChoo Farmhouse Coffee Table, showcasing its design and functionality.

4. Usage

The ChooChoo Farmhouse Coffee Table is designed for use in living room spaces, offering both a functional surface and additional storage.

- **Tabletop:** Use the spacious tabletop for beverages, books, decorative items, or as a convenient surface for daily activities. Ensure items are placed evenly to maintain balance.
- **Bottom Shelf:** The decorative bottom shelf provides additional space for storing magazines, remote controls, baskets, or displaying decor.
- **Placement:** Position the coffee table on a flat, stable floor. Avoid placing it in direct sunlight or near heat sources to prevent material damage.



Figure 4.1: Detailed view highlighting the tabletop finish, sturdy leg construction, and the practical bottom shelf.

5. Care and Maintenance

Proper care will help maintain the appearance and longevity of your coffee table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage.
- **Protection:** Use coasters under drinks and placemats under hot items to protect the tabletop from heat and moisture rings.
- **Inspection:** Periodically check all hardware connections and tighten if necessary to ensure continued stability.
- **Environment:** Maintain a stable room temperature and humidity level to prevent wood from warping or cracking.

6. Troubleshooting

If you encounter any issues, refer to the following common solutions:

- **Wobbling Table:**
  - Ensure the table is on a level surface.
  - Check all assembly hardware and tighten any loose screws or bolts.
- **Scratches or Dents:**
  - Minor scratches may be touched up with a furniture repair pen matching the finish.
  - For deeper damage, professional repair may be required.
- **Difficulty Assembling:**
  - Re-read the assembly instructions carefully.
  - Ensure you are using the correct hardware for each step.
  - Do not force parts together; if they don't fit, recheck alignment.

7. Specifications

Detailed product specifications for the ChooChoo Farmhouse Coffee Table.



Figure 7.1: Key dimensions of the coffee table for planning your space.

Feature	Detail
Brand	ChooChoo
Model Name	ChooChoo Mission Square
Model Number	EUR-CT2103-4TWL
Product Dimensions (D x W x H)	22"D x 39.9"W x 18.1"H (55.9 cm D x 101.3 cm W x 46 cm H)
Tabletop Weight Capacity	120 lbs (54 kg)

Feature	Detail
Bottom Shelf Weight Capacity	80 lbs (36 kg)
Material	Hardwood solids, manufactured wood (natural rubber wood, pine, MDF)
Color	Pure White
Item Weight	17.6 Kilograms (approx. 38.8 lbs)
Assembly Required	Yes

8. Warranty and Support

ChooChoo stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or contact the manufacturer directly.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact the service email address provided in your product manual or visit the official ChooChoo website for customer support.

We are committed to providing a satisfactory experience with your ChooChoo Farmhouse Coffee Table.

© 2025 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09P7ZC7ND

More documents and user manuals: **https://manuals.plus/**