Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo EUR-CT2103-2TRL

ChooChoo Farmhouse Coffee Table Model EUR-CT2103-2TRL Instruction Manual

Your guide to assembly, operation, and maintenance.

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your ChooChoo Farmhouse Coffee Table, Model EUR-CT2103-2TRL. Please read these instructions carefully before beginning assembly and retain them for future reference. This coffee table features a classic farmhouse design with slatted sides and a functional bottom shelf, suitable for various living room decors.



Figure 1: Assembled ChooChoo Farmhouse Coffee Table (Model EUR-CT2103-2TRL)

2. Safety Information

Adhering to these safety guidelines will ensure safe use and longevity of your coffee table:

- **Weight Limits:** Do not exceed the maximum weight recommendation of **120 lbs (54 kg) on the tabletop** and **80 lbs (36 kg) on the bottom shelf**. Exceeding these limits may cause tipping or collapse, leading to injury or damage.
- **Stability:** Ensure the coffee table is placed on a flat, stable, and level surface to prevent wobbling.
- **Secure Assembly:** Verify that all screws and fasteners are securely tightened before use. Periodically check and retighten as necessary to maintain structural integrity.
- **Children and Small Parts:** Keep small parts and assembly hardware away from children during assembly to prevent choking hazards.
- **Hot Items:** Avoid placing hot items directly on the surface without protective coasters to prevent heat damage.

3. Package Contents

Before beginning assembly, carefully unpack all components and hardware. Lay them out on a clean, soft surface to prevent scratches. Refer to the parts list and diagrams included in your product packaging to verify that all items are present and undamaged. All parts and accessories are typically numbered for easy identification.
Typical components include:

- Tabletop (1 piece)
- Bottom Shelf (1 piece)
- Legs / Side Panels (2 pieces)
- Support Bars (various pieces)
- Assembly Hardware (screws, nuts, dowels, cam locks, etc.)
- Assembly Tools (e.g., screwdriver, Allen wrench)



Figure 2: Exploded Assembly Diagram (Refer to your specific manual for detailed part numbers)

4. Setup and Assembly Instructions

Assembly is straightforward and typically requires two people. All necessary hardware and tools are included in the package. Follow the detailed, step-by-step instructions and diagrams provided in your product packaging for the most accurate guidance.

1. **Unpack and Organize:** Carefully remove all parts from the packaging. Identify and separate each component and hardware piece according to the included parts list.
2. **Assemble Side Panels:** Attach the horizontal support bars to the vertical leg pieces to form the two side panels. Ensure the slatted design is oriented correctly.
3. **Connect Side Panels:** Use the designated hardware to connect the two assembled side panels with the remaining support bars, forming the main frame of the table.
4. **Install Bottom Shelf:** Slide the bottom shelf into the grooves or attach it to the designated supports within the

assembled frame. Secure it with screws as indicated in the manual.

5. **Attach Tabletop:** Carefully place the tabletop onto the top of the assembled frame. Align the pre-drilled holes and secure the tabletop using the provided screws.
6. **Final Tightening:** Once all parts are in place and the table is fully assembled, carefully tighten all screws and fasteners. Avoid overtightening, which can strip screws or damage the wood.
7. **Placement:** Position the assembled coffee table in your desired location, ensuring it is stable and level.

Note: *If you encounter difficulty with specific fasteners, such as lock nuts, ensure proper alignment before applying force. Refer to the specific diagrams in your included manual for precise guidance.*

5. Operating Instructions (Usage)

The ChooChoo Farmhouse Coffee Table is designed for functional and decorative use in indoor living room environments. Its spacious surface and lower shelf offer versatile utility.

- **Tabletop Use:** Utilize the main tabletop surface for placing everyday items such as remote controls, beverages (with coasters), books, magazines, or decorative accents.
- **Bottom Shelf Storage:** The lower shelf provides additional space for organizing larger items like storage baskets, blankets, extra reading materials, or display pieces.
- **Even Weight Distribution:** Always distribute items evenly across the tabletop and bottom shelf to maintain stability and prevent stress on any single point.

6. Maintenance

Regular maintenance will help preserve the appearance and structural integrity of your coffee table for years to come:

- **Cleaning:** Wipe the surface with a dry, soft cloth. For stubborn marks, a slightly damp cloth followed immediately by a dry cloth can be used. Avoid using harsh chemicals, abrasive cleaners, or furniture polish containing silicone, as these can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent staining, water rings, or moisture damage to the wood.
- **Protection:** Always use coasters under drinks and placemats or trivets under hot dishes or decorative items that may scratch the surface.
- **Hardware Inspection:** Periodically check all hardware connections (screws, bolts) and tighten them if they become loose. Loose connections can lead to instability and damage.
- **Environmental Factors:** Avoid prolonged exposure to direct sunlight, extreme temperatures, or high humidity, which can cause fading, warping, or cracking of the wood finish.

7. Troubleshooting

This section addresses common issues you might encounter with your coffee table:

- **Wobbling Table:**
  - Ensure the table is placed on a flat, even surface. Uneven flooring can cause instability.
  - Check all assembly screws and bolts. Tighten any loose connections.
- **Difficulty During Assembly:**
  - Re-read the specific step in the included manual carefully.
  - Ensure all parts are correctly oriented as shown in the diagrams. Sometimes a part may appear similar but

has a specific front/back or top/bottom.
    - Do not force parts together. If a part does not fit, double-check the part number and orientation against the manual.
- **Missing or Damaged Parts:**
    - If you find any parts missing or damaged upon opening the package, refer to the contact information in your product manual for assistance. Do not attempt to assemble with missing or damaged components.

8. Specifications

Key specifications for the ChooChoo Farmhouse Coffee Table, Model EUR-CT2103-2TRL:

Feature	Detail
Brand	ChooChoo
Model Number	EUR-CT2103-2TRL
Product Dimensions (D x W x H)	22"D x 39.9"W x 18.1"H
Color	Pure Espresso
Material Type	Wood (Hardwood solids, manufactured wood, pine, MDF)
Finish Type	Painted
Maximum Weight Recommendation (Tabletop)	120 lbs (54 kg)
Maximum Weight Recommendation (Bottom Shelf)	80 lbs (36 kg)
Number of Shelves	1
Assembly Required	Yes (Tools included, 2 people recommended)
Product Care Instructions	Wipe with Dry Cloth
Indoor/Outdoor Usage	Indoor



Figure 3: Product Dimensions

9. Warranty and Support

The ChooChoo Farmhouse Coffee Table comes with a limited warranty. For specific warranty details, including coverage and duration, please refer to the documentation included with your product packaging.

For any questions, concerns, or assistance with assembly, missing parts, or product issues, please contact ChooChoo customer service. The service email address can be found on the manual included in your product packaging.

You can also visit the official ChooChoo store for more information and to explore other products.ChooChoo Store on Amazon

© 2025 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09P7ZN179

More documents and user manuals: **https://manuals.plus/**